

LIST OF CHEMICALS MACH II

IMPORTANT NOTICE

The table „Chemical resistance of plastics“ was listed based on information from various raw material manufacturers. The values refer exclusively to laboratory tests with raw materials. Plastic parts made from them are often subject to influences that cannot be detected in laboratory tests (temperature, pressure, material stresses, exposure to chemical substances, design features, etc.). For these reasons, the values given can only serve as a guideline. In cases of doubt, we strongly recommend carrying out a test. No legal claim can be derived from this information, we exclude any warranty and liability. Chemical and mechanical resistance alone is not sufficient for assessing the serviceability of a product. In particular, the regulations for flammable liquids (explosion protection) must be taken into account.

COPYRIGHT

We would like to thank Bürkle GmbH for granting us the right to use this table. This table is published and maintained by Bürkle GmbH, D-79415 Bad Bellingen, Germany, as a referral guide. This copyright notice may not be removed. The table may be freely distributed and copied as long as the copyright notice remains intact.

LIST OF MATERIALS MACH II

Tank:	PP	Suction hose:	EVA
Sewage pump:	V2A stainless steel	Drain hose:	PVC
Check valve:	PVC	Floor nozzle:	Aluminium/rubber
Screw connections:	PVC	Suction tube:	PVC
C-couplings:	Aluminium	Suction head:	PA

Version 3.11 (11.01.2021); Subject to technical changes, © Bürkle GmbH 2021.

rössle

Industrial vacuum cleaners for sludge

2 of 34

MEDIUM	FORMULA	CAS NO.	CONCEN TRATION	HAZARD INFORMATION	Thermoplastics													Fluoroplastics			Elastomers			Metals			REMARK					
					FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	PEP	PTFE	PVDF	EPDM	FKM / FKM	NBR	SI		AL	V2A	V4A	Hastelloy C	
Formic acid	CH ₂ O ₂	000064-18-6	3 %	Xi		1/1	1/2	3/4	1/2	1/0	1/2	2/4	1/2	1/2	2/2	2/3	0/0	0/0		1/1	1/1	1/1	1/1	3/0	(3)	4/4	0/0	(3)	1/2	1/1	1/1	
Formic acid amide	-> see: Formamide																															
Formic acid ethyl ester	-> see: Ethyl formate																															
Formic acid methyl ester	-> see: Methylformia																															
Aminobenzene	-> see: Aniline																															
Aminobutane	-> see: Buylamine																															
Aminoacetic acid	C ₂ H ₃ NO ₂	000056-40-6	10 %	—		1/1	1/1	1/1	1/1	(1)	0/0	1/1	1/1	0/0	0/0	1/3	1/3	0/0	1/1	1/1	1/1	1/1	1/0	3/3	0/0	(2)	(2)	(2)	0/0			
Aminoethanol, 2-	-> see: Ethanolamine																															
Aminoethanoic acid	-> see: Aminoacetic acid																															
Amonimethane	-> see: Methylamine, (mono-)																															
Aminopropane	-> see: Propylamine, n-																															
Aminopropionic acid, L-2-	-> see: Alanine, (L-)																															
Ammonia	-> see: Ammonium hydroxide																															
Ammonia, sulphuric acid	-> see: Ammonium sulphate																															
Ammonia water	-> see: Ammonium hydroxide																															
Ammonium 2-hydroxyacetate	-> see: Ammonium glycolate																															
Ammonium acetate	C ₂ H ₇ NO ₂	000631-61-8	saturated	Xi		1/1	1/1	1/0	1/1	(2)	1/1	(1)	1/1	1/1	1/1	1/1	0/0	0/0	1/1	1/1	1/1	1/1	1/0	(3)	2/2	0/0	1/1	(2)	(2)	1/1		
Ammonium alum	-> see: Aluminium ammonium sulphate																															
Ammonium aluminium sulphate	-> see: Aluminium ammonium sulphate																															
Ammonium bicarbonate	-> see: Ammonium hydrogen carbonate																															
Ammonium bifluoride	-> see: Ammonium hydrogen difluoride																															
Ammonium carbonate	(NH ₄) ₂ CO ₃	010361-29-2	50 %	Xn		1/1	1/1	1/0	3/0	0/0	1/0	(2)	1/1	1/1	1/0	1/3	1/0	1/1	0/0	1/1	1/1	1/1	1/0	3/0	4/4	0/0	1/1	1/1	1/1	1/1	Hartshorn salt	
Ammonium carbonate	(NH ₄) ₂ CO ₃	010361-29-2	aqueous	Xn		1/1	1/1	1/0	(3)	(2)	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	3/0	4/4	0/0	1/1	1/1	1/1	1/1	Hartshorn salt	
Ammonium chloride	(NH ₄)Cl	012125-02-9	solid	Xn		1/1	1/1	1/0	1/0	(2)	0/0	2/3	1/1	0/0	0/0	1/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/0	1/1	0/0	3/4	1/3L	1/2L	1/1	Ammonia	
Ammonium chloride	(NH ₄)Cl	012125-02-9	aqueous	Xn		1/1	1/1	1/0	1/0	(2)	1/1	2/3	1/1	1/1	1/0	1/3	1/3	1/1	1/1	1/1	1/1	1/1	1/0	1/1	1/1	0/0	3/4	1/3L	1/2L	1/1	Ammonia	
Ammonium dihydrogen phosphate	(NH ₄)H ₂ PO ₄	007722-76-1	any	Xi		1/1	1/1	1/0	(2)	(2)	1/0	(2)	1/1	1/1	1/1	1/0	0/0	1/1	1/1	1/1	1/1	1/0	3/0	1/1	0/0	4/4	(1)	(1)	1/1			
Ammonium iron(II) sulfate	(NH ₄) ₂ Fe(SO ₄) ₂	007783-85-9		Xi		1/1	1/1	(2)	(2)	(2)	0/0	(3)	1/1	1/1	0/0	0/0	0/0	1/1	1/1	1/1	1/1	(1)	(1)	(1)	0/0	4/4	(1)	(1)				
Ammonium iron(III) sulfate	(NH ₄)Fe(SO ₄) ₂	007783-83-7	saturated	Xi		1/1	1/1	1/0	(2)	(2)	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	1/0	(2)	(1)	0/0	(4)	0/0	0/0				
Ammonium fluoride	(NH ₄)F	012125-01-8	saturated	T, C		1/1	1/1	1/0	4/4	(2)	1/0	(2)	1/1	0/0	0/0	1/0	0/0	0/0	0/0	1/1	1/1	(1)	1/0	2/3	1/1	0/0	(4)	(1)	(1)	?		
Ammonium fluoride	(NH ₄)F	012125-01-8	aqueous	T, C		1/1	1/1	1/0	(3)	(2)	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	2/3	1/1	0/0	(4)	1/3	1/3	1/1			
Ammonium glycolate	C ₂ H ₇ NO ₃	035249-89-9		(Xi)		1/1	1/2	(1)	2/3	(2)	1/2	(2)	1/2	1/1	2/2	1/1	0/0	0/0	1/1	1/1	1/1	(1)	1/0	(3)	(1)	0/0	(2)	(2)				
Ammonium heptamolybdate	(NH ₄) ₆ Mo ₇ O ₂₄	012054-85-2		Xi		1/1	1/1	(1)	(2)	(2)	0/0	(1)	1/1	1/1	0/0	0/0	0/0	1/1	0/0	1/1	1/1	(1)	1/0	(3)	(1)	0/0		(1)	(1)	0/0		
Ammonium hydrogen carbonate	CH ₃ NO ₃	001066-33-7	saturated	Xi		1/1	1/1	1/0	(2)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	(3)	(3)	0/0	1/1	1/1	1/1	1/1		
Ammonium hydrogen difluoride	F ₂ H ₂ N	001341-49-7	50 %	T, C		1/1	1/1	2/0	(4)	0/0	0/0	(4)	1/1	0/0	0/0	1/3	0/0	0/0	0/0	1/1	1/1	1/1	1/0	(3)	2/3	0/0	(3)	1/0	1/0			
Ammonium hydrogen sulphide	-> see: Ammonium hydrosulphide																															
Ammonium hydrosulphide	(NH ₄)HS	012124-99-1	any	T, C		1/1	1/1	1/0	(3)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	1/0	(3)	(2)	0/0	(2)	(1)	(1)	1/1		
Ammonium hydroxide	NH ₃ + H ₂ O	001336-21-6	30 %	C, N		1/1	1/2	(3)	4/4	2/4	1/2	1/2	1/2	2/3	1/2	0/0	0/0	0/0	1/1	1/1	1/1	(2)	1/0	(3)	2/3	0/0	1/1	1/1	1/1	1/1		
Ammonium hydroxide	NH ₃ + H ₂ O	001336-21-6	5 %	Xi		1/1	1/1	(2)	3/4	(2)	1/1	1/2	1/1	1/3	2/2	1/1	0/0	0/0	1/1	1/1	1/1	(2)	1/0	(2)	2/3	0/0	1/1	1/1	1/1	1/1		
Ammonium hydroxide	NH ₃ + H ₂ O	001336-21-6		C/Xi, N		1/1	1/1	(3)	4/4	2/4	1/1	1/2	1/1	2/3	2/3	1/2	1/3	2/2	1/1	1/1	1/1	1/3	1/0	(3)	4/4	0/0	1/1	1/1	1/1	1/1		
Ammonium metaphosphate	(NH ₄ PO ₃) _n	068333-79-9		Xi		1/1	1/1	(1)	(2)	(2)	0/0	(1)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	(1)	1/0	(3)	1/1	0/0	(3)	(1)	(1)			
Ammonium molybdate	-> see: Ammonium heptamolybdate																															
Ammonium monophosphate, monobasic	-> see: Ammonium dihydrogen phosphate																															
Ammonium nitrate	(NH ₄)NO ₃	006484-52-2	10 %	O		1/3	0/0	1/0	(1)	(2)	0/0	2/4	1/1	1/1	1/0	1/3	0/0	0/0	1/1	1/1	1/1	1/1	1/0	2/2	1/1	0/0	1/1	1/1	1/1	1/1		
Ammonium nitrate	(NH ₄)NO ₃	006484-52-2	saturated	O		1/3	1/1	1/0	1/0	(2)	1/1	2/4	1/1	1/0	1/0	1/1	1/0	1/1	1/1	1/1	1/1	1/0	2/2	1/1	0/0	(2)	1/1	1/1	1/1	1/1		
Ammonium nitrite	(NH ₄)NO ₂	013446-48-5	aqueous	O, Xn		(1)	(1)	(2)	(2)	(2)	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	(3)	1/0	0/0	(2)	(1)	(1)				
Ammonium oxalate	C ₂ H ₈ N ₂ O ₄	014258-49-2		Xn		1/1	1/2	(1)	1/1	(2)	1/2	(2)	1/2	1/1	1/1	1/1	0/0	0/0	1/1	1/1	1/1	(1)	1/0	(3)	(1)	0/0	1/1	1/1	1/1	0/0		
Ammoniumperoxodisulfat	(NH ₄) ₂ S ₂ O ₈	007727-54-0	saturated	O, Xn		0/0	0/0	4/4	(2)	0/0	0/0	(2)	1/1	0/0	0/0	1/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	(3)	4/4	0/0	4/4	(4)	3/4	0/0		
Ammoniumperoxodisulfat	(NH ₄) ₂ S ₂ O ₈	007727-54-0	aqueous	O, Xn		0/0	0/0	4/4	(2)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	(3)	4/4	0/0	4/4	(4)	3/4	0/0		
Ammonium persulphate	-> see: Ammonium peroxodisulphate																															
Ammonium phosphate, primary	-> see: Ammonium dihydrogen phosphate																															
Ammoniumpolyphosphat	-> see: Ammonium metaphosphate																															
Ammonium rhodanide	-> see: Ammonium thiocyanate																															
Ammonium sulphate	(NH ₄) ₂ SO ₄	007783-20-2	10 %	Xn		1/1	1/1	1/0	1/1	(2)	(1)	1/0	1/1	1/1	1/0	1/3	0/0	0/0	1/1	1/1	1/1	1/1	1/0	2/3	1/1	0/0	1/1	1/1	1/1	1/1	sulphuric acid ammonia	
Ammonium sulphate	(NH ₄) ₂ SO ₄	007783-20-2	saturated	Xn		1/1	1/1	1/0	1/1	(2)	1/1	2/0	1/1	1/0	1/0	1/1	1/0	1/1	1/1	1/1	1/1	1/1	1/0	2/3	1/1	0/0	1/1	1/1	1/2	1/1	sulphuric acid ammonia	
Ammonium sulphide	(NH ₄) ₂ S	012135-76-1	any	T, C	X	1/1	1/1	1/0	4/4	0/0	1/1	(2)	1/1	0/0	0/0	1/3	1/0	0/0	0/0	1/1	1/1	1/1	1/0	(3)	1/2	0/0	1/1	(1)	(1)	?		
Ammonium sulphide	(NH ₄) ₂ S	012135-76-1	aqueous	T, C	X	1/1	1/1	1/0	(3)	0/0	0/0	(2)	1/1	0/0	0/0	1/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	(3)	3/2	0/0	1/1	(1)	(1)	1/1		

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	Thermoplastics														Fluoroplastics				Elastomers				Metals				Hastelloy C	REMARK
					FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A			
Ammonium sulphocyanide	-> see: Ammonium thiocyanate																															
Ammonium thiocyanate	CH ₃ N ₂ S	001762-95-4		Xn		1/1	1/1	(3)	1/0	(2)	1/1	1/0	1/1	1/3	0/0	1/0	0/0	1/1	1/1	1/1	1/1	(1)	1/0	(3)	1/0	0/0	(2)	(1)	(1)			
Ammonium nitrate	-> see: Ammonium nitrate																															
Amylacetate, n-	C ₇ H ₁₄ O ₂	000628-63-7		—	X	1/2	2/3	2/0	4/4	1/3	2/3	(1)	3/4	4/4	4/4	4/4	4/4	1/1	1/1	1/1	1/3	3/4	4/4	4/4	0/0	1/1	1/1	1/1	0/0			
Amyl alcohol, n-	C ₅ H ₁₂ O	000071-41-0		Xn	X	1/1	1/2	1/0	1/0	1/0	2/3	1/0	1/1	1/3	3/0	2/3	3/0	0/4	1/1	1/1	1/1	1/1	3/0	2/4	3/0	0/0	1/2	1/1	1/1	0/0		
Anym chloride	C ₃ H ₇ Cl	000543-59-9		F, Xn	X	3/4	4/4	1/0	4/4	0/0	4/4	(2)	4/4	4/4	4/4	4/4	0/0	1/1	1/1	1/1	1/1	1/1	4/4	1/0	4/4	0/0	3/4	3/4L	3/4L	0/0		
Amyl hydrosulphide	-> see: Pentanthiol, 1-																															
Amyl mercaptan	-> see: Pentanthiol, 1-																															
α-pentylcinnamaldehyde	C ₁₄ H ₁₈ O	000122-40-7		Xi		0/0	0/0	0/0	(4)	0/0	(4)	(3)	(3)	0/0	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	(4)	(3)	(4)	0/0	(1)	(1)	(1)		Fragrance	
Pineapple juice	—	—		—		1/1	1/1	1/0	(2)	1/0	0/0	(2)	1/1	1/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	(1)	(1)	(2)	(1)	0/0	(2)	(1)	(1)			
Aniline	C ₆ H ₇ N	000062-53-3		T		1/2	1/3	3/4	4/4	0/0	2/3	1/3	2/3	4/4	4/4	4/4	0/4	2/4	1/1	1/1	1/4	4/4	2/4	4/4	0/0	1/0	1/0	1/0	1/1			
Aniline chlorohydrate	C ₆ H ₅ ClN	000142-04-1	saturated	T		1/3	0/0	(3)	(3)	0/0	0/0	(3)	1/3	0/0	0/0	1/0	0/0	0/0	0/0	1/1	1/1	1/1	3/0	2/2	3/3	0/0	4/4	4/4	4/4			
Aniline hydrochloride	-> see: Aniline chlorohydrate																															
Anilinium chloride	-> see: Aniline chlorohydrate																															
Anise	—	—		?		0/0	0/0	(2)	(2)	(2)	0/0	(2)	(2)	0/0	0/0	0/0	0/0	1/1	0/0	1/1	(1)	(1)	(2)	(2)	(2)	0/0	(1)	(1)	(1)			
Anise oil	C ₇ H ₈ O	000100-66-3	100 %	Xi	X	1/4	3/4	1/0	4/4	0/0	2/3	(2)	3/3	4/4	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(3)	4/4	4/4	4/4	0/0	1/0	(1)	(1)	0/0		
Anise oil	—	084775-42-8		Xi		0/0	0/0	(3)	(3)	0/0	(4)	(2)	(3)	0/0	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(3)	4/4	(3)	4/4	0/0	(1)	(1)	(1)	0/0		
Anon	-> see: Cyclohexanone																															
Antimony (III) chloride	-> see: Antimony trichloride																															
Antimony (V) chloride	-> see: Antimony pentachloride																															
Antimony pentachloride	SbCl ₅	007647-18-9		C		0/0	0/0	4/4	(3)	0/0	0/0	4/4	1/1	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(2)	(2)	(2)	4/4	0/0	(3)	(4)	(4)	0/0		
Antimony trichloride	SbCl ₃	010025-91-9	90 %	C		1/1	1/1	4/4	1/0	0/0	0/0	4/4	1/1	0/0	0/0	1/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/1	3/0	0/0	4/4	4/4	4/4	0/0		
Antimony trichloride	SbCl ₃	010025-91-9	anhydrous	C		0/0	0/0	4/4	1/0	0/0	0/0	4/4	1/1	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(2)	1/0	1/0	1/0	0/0	1/1	4/4	4/4			
Antimony trichloride	SbCl ₃	010025-91-9	aqueous	C		0/0	0/0	4/4	(3)	0/0	0/0	4/4	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	(1)	1/1	1/0	1/1	3/0	0/0	4/4	4/4	4/4			
Apple juice	—	—		—		1/1	1/1	(1)	1/0	1/0	0/0	(2)	1/1	1/0	0/0	0/0	0/0	1/1	1/1	1/1	(1)	(1)	(1)	(1)	0/0	(2)	(1)	(1)				
Orange juice	—	—		—		1/1	1/1	1/0	1/0	1/0	0/0	(2)	1/1	1/0	0/0	0/0	0/0	1/1	1/1	1/1	(1)	1/0	(1)	(2)	0/0	(2)	1/1	1/1				
Orange peel oil	—	008028-48-6		Xn		(3)	(3)	1/0	(3)	0/0	(4)	1/0	(3)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(3)	4/4	(2)	(3)	0/0	(1)	(1)	(1)		mainly +-Limes	
Arcton 12	-> see: Dichlorodifluoromethane																															
Arcton 21	-> see: Dichlorodifluoromethane																															
Arcton 22	-> see: Chlorodifluoromethane																															
Arsenic anhydride	-> see: Arsenic pentoxide																															
Arsenic pentoxide	As ₂ O ₅	001303-28-2		T, N		1/1	1/1	(3)	(2)	0/0	0/0	(4)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	0/0	1/1	(2)	(2)	(3)	(3)	0/0	(3)	(1)	(1)			
Arsenic acid	H ₃ AsO ₄	022538-92-7	aqueous	T, N		1/1	0/2	(3)	1/0	0/0	0/0	4/4	1/1	1/1	0/0	1/3	3/0	0/0	1/1	1/1	1/1	1/1	1/0	2/2	1/1	0/0	4/4	1/0	1/1	1/1		
Arsenic acid	H ₃ AsO ₄	022538-92-7	80 %	T, N		1/1	0/2	(3)	1/0	0/0	0/0	4/4	1/1	1/1	0/0	1/3	3/0	0/0	1/1	0/0	1/1	1/1	1/0	2/2	1/1	0/0	4/4	1/0	1/1	1/1		
Arsenic anhydride	-> see: Arsenic pentoxide																															
Ascorbic acid	C ₆ H ₈ O ₆	000050-81-7	aqueous	—		1/1	1/1	(2)	(2)	(1)	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	(1)	(1)	(1)	(1)	0/0	1/1	(1)	(1)	0/0		
Ether	-> siehe: Ethylether																															
Atropine sulphate	C ₃₄ H ₄₈ N ₂ SO ₁₀ ·H ₂ O	000055-48-1		T+		1/1	1/1	(2)	(1)	(2)	0/0	(1)	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	(1)	(2)	(2)	(1)	0/0	(2)	(1)	(1)			
Caustic baryte	-> see: Barium hydroxide																															
Caustic potash	-> see: Potassium hydroxide																															
Caustic lime	-> see: Calcium oxide																															
Caustic soda	-> see: Sodium hydroxide																															
Azafluorene, 9-	-> siehe: Carbazole																															
Valerian drops	—	—		?		0/0	0/0	(2)	(2)	(2)	0/0	(2)	(2)	4/4	0/0	0/0	0/0	1/0	0/0	1/1	1/1	(1)	(3)	(3)	(2)	0/0	(2)	(1)	(1)			
Barium bromide	BaBr ₂	010553-31-8		Xn		1/1	1/1	(2)	(2)	1/0	0/0	(2)	1/1	1/1	0/0	0/0	0/0	1/1	1/1	1/1	1/1	(1)	1/0	(1)	1/1	0/0	(2)	(2L)	(2L)			
Barium carbonate	BaCO ₃	000513-77-9	saturated	Xn		1/1	1/1	1/1	(1)	1/1	1/1	(1)	1/1	1/1	0/0	1/0	1/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/1	1/1	1/1	No chemical effect expected due to low solubility	
Barium chloride	BaCl ₂	010361-37-2	saturated	T		1/1	1/1	1/0	1/0	1/0	1/1	(2)	1/1	1/1	1/0	1/3	1/0	1/1	1/1	1/1	1/1	1/1	1/1	1/0	1/1	0/0	1/1	1/2L	1/1L	1/1		
Barium chloride	BaCl ₂																															

MEDIUM	FORMULA	CAS NO.	CONCEN TRATION	HAZARD INFORMATION	Thermoplastics													Fluoroplastics			Elastomers			Metals			REMARK			
					FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	PEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI		AL	V2A	V4A
Benzoic acid	C ₇ H ₆ O ₂	000065-85-0	saturated	Xn, Xi		1/1	1/1	3/4	4/4	1/0	1/2	2/4	1/3	2/2	3/3	1/2	1/0	1/1	1/1	1/1	1/1	3/0	1/1	3/0	1/1	1/1	1/1	1/1		
Benzoic acid	C ₇ H ₆ O ₂	000065-85-0	aqueous	Xn, Xi		1/1	1/1	3/4	4/4	1/0	1/2	2/4	1/3	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	3/0	1/1	3/0	0/0	1/2	1/1	1/1	1/1
Benzoic acid sodium salt	-> see: Sodium benzoate																													
Benzoic acid aldehyde	-> see: Benzaldehyde																													
Benzoic acid benzyl ester	-> see: Benzyl benzoate																													
Benzoic acid chloride	-> see: Benzoyl chloride																													
Benzoic acid ethyl ester	C ₉ H ₁₀ O ₂	000093-89-0		Xn		2/2	3/3	(2)	4/4	0/0	2/3	(2)	2/3	4/4	4/4	4/4	0/0	4/4	1/2	1/1	1/0	(3)	(3)	(3)	4/4	0/0	(1)	(1)	(1)	
Benzene	C ₆ H ₆	000071-43-2		F, T	X	3/4	3/4	2/0	4/4	4/4	2/3	1/2	3/4	4/4	4/4	4/4	0/0	0/4	1/2	1/1	1/1	1/3	4/4	3/3	4/4	0/0	1/1	1/1	1/1	0/0
Benzene-1,2-dicarboxylic acid	-> see: Phthalic acid																													
Benzene carboxylic acid	-> see: Benzoic acid																													
Benzene hexachloride (BHC)	-> see: Hexachlorocyclohexane																													
Benzenesulfonic acid	C ₆ H ₅ SO ₃	000098-11-3	saturated	C		1/1	1/1	(4)	(3)	(4)	0/0	(4)	2/4	0/0	1/0	2/0	0/0	0/0	0/0	1/1	1/1	1/4	4/4	1/0	4/4	0/0	3/4	0/0	1/0	0/0
Benzoyl chloride	C ₇ H ₅ ClO	000098-88-4	100 %	C		0/0	3/3	4/4	(4)	0/0	(4)	(3)	3/4	0/0	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/0	(3)	4/4	0/0	1/0	(2L)	(2L)	0/0
Benzyl acetate	C ₉ H ₁₀ O ₂	000140-11-4		Xn/Xi		1/1	1/2	(2)	3/4	0/0	1/2	(2)	1/2	4/4	4/4	4/4	0/0	4/4	1/2	1/1	1/0	(3)	(3)	1/0	4/4	0/0	1/1	1/1	1/1	
Benzyl alcohol	C ₇ H ₈ O	000100-51-6		Xn		3/4	4/4	4/4	0/0	4/4	1/0	4/4	4/4	4/4	2/3	0/0	4/4	1/1	1/1	1/1	1/1	3/0	1/0	4/4	0/0	1/1	1/1	1/1	1/1	3/3
Benzyl benzoate	C ₁₄ H ₁₂ O ₂	000120-51-4		Xn		0/0	0/0	(2)	(3)	0/0	(3)	(2)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(2)	4/4	(3)	4/4	0/0	(1)	(1)	(1)	
Benzylcarbinol	-> see: Phenylethanol																													
Benzyl chloride	C ₇ H ₇ Cl	000100-44-7	100 %	T/Xi		0/0	4/4	1/0	4/4	0/0	4/4	(2)	4/4	4/4	4/4</															

MEDIUM	FORMULA	CAS NO.	CONCEN TRATION	HAZARD INFORMATION	FLAMMABLE	Thermoplastics														Fluoroplastics				Elastomers				Metals				REMARK
						HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FKM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C		
Brake fluid	—	—	—	?		1/0	1/0	1/0	4/4	0/0	1/1	(3)	1/1	3/0	0/0	1/0	3/0	4/4	0/0	(1)	1/0	(3)	1/0	4/4	4/4	0/0	(1)	(1)				
Bromine	Br ₂	007726-95-6		T+, C		4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	2/4	4/4	4/4	1/2	1/1	1/3	1/1	4/4	(2-3)	4/4	0/0	(4)	4/4	4/4	4/4		
Bromine benzene	-> see: Bromobenzene																															
Bromobenzene	C ₆ H ₅ Br	000108-86-1		Xn	X	3/4	4/4	1/0	4/4	(2)	4/4	1/0	4/4	4/4	4/4	4/4	0/0	2/4	1/1	1/0	1/1	4/4	3/0	4/4	0/0	1/1	(1)	(1)				
Bromochloromethane	CH ₂ BrCl	000074-97-5	100 %	Xn		(4)	(4)	4/4	4/4	1/0	(4)	(3)	4/4	4/4	0/0	4/4	4/4	4/4	0/0	(1)	1/0	(3)	4/4	3/0	4/4	0/0	(3)	0/0	0/0	0/0		
Bromine vapours	Br ₂	007726-95-6		T		(4)	(4)	4/4	(3)	4/4	(4)	4/4	4/4	0/0	0/0	0/0	0/0	0/0	(1)	1/0	(1)	4/4	(2-3)	4/4	0/0	(3)	(4)	(4)	4/4			
Bromine potassium	-> see: Potassium bromide																															
Bromomethane	CH ₃ Br	000074-83-9	tech. pure	T		3/0	4/4	1/0	(3)	0/0	0/0	1/0	4/4	4/4	0/0	4/4	4/4	0/0	0/0	1/0	1/0	1/1	4/4	1/0	4/4	0/0	4/4	1/1L	1/1L	0/0		
Bromoform	CHBr ₃	000075-25-2		T		4/4	4/4	4/4	4/4	4/4	4/4	(4)	4/4	4/4	4/4	0/0	2/3	1/1	(1)	(2)	4/4	(4)	4/4	0/0	0/0	(3)	0/0	0/0	0/0	0/0		
Bromopental fluoride	BrF ₅	007789-30-2		F, T, C		0/0	0/0	4/4	(4)	(4)	(4)	4/4	(3)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(2)	(3)	4/4	4/4	4/4	0/0	(3)	(4)	(4)			
Bromic acid	HBrO ₃	007789-31-3	concentrated	C		0/0	0/0	(4)	(4)	(4)	0/0	4/4	3/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(2)	(4)	(2)	4/4	0/0	(4)	(4)	(4)	0/0			
Bromine trifluoride	BrF ₃	007787-71-5		T, C		0/0	0/0	4/4	(4)	4/4	(4)	4/4	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(2)	(3)	4/4	4/4	4/4	0/0	(3)	(4)	(4)				
Bromotrifluoromethane	CBrF ₃	000075-63-8		N		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	3/0	1/0	0/0	(3)	0/0	0/0				
Bromine water	Br ₂ +H ₂ O	007726-95-6	saturated	T		4/4	4/4	4/4	(4)	4/4	4/4	4/4	4/4	0/0	3/4	0/0	0/0	0/0	0/0	1/1	1/1	1/1	4/4	(2-3)	4/4	0/0	(4)	4/4	4/4	0/0		
Hydrobromic acid	HBr	010035-10-6	40 %	C		1/0	1/1	4/4	4/4	(4)	4/4	4/4	1/1	4/4	0/0	1/1	3/3	0/0	1/1	1/1	1/1	3/0	1/0	4/4	0/0	(4)	(4)	(4)	0/0			
Hydrobromic acid	HBr	010035-10-6	50 %	C		1/1	1/2	4/4	4/4	(4)	4/4	4/4	1/2	4/4	0/0	1/1	3/3	0/0	1/1	1/1	1/1	1/1	3/0	1/0	4/4	0/0	(4)	(4)	(4)	0/0		
Hydrobromic acid	HBr	010035-10-6	diluted	C		1/1	1/1	4/4	4/4	3/0	4/4	4/4	1/1	4/4	0/0	1/3	3/0	0/0	0/0	1/1	1/1	1/1	3/0	1/0	4/4	0/0	(4)	(4)	(4)	0/0		
Butadiene, 1,3-	C ₄ H ₆	000106-99-0		F+, T	X	3/4	4/4	1/0	4/4	1/0	4/4	(2)	4/4	4/4	4/4	3/4	0/0	0/0	1/1	1/1	1/1	1/1	4/4	3/0	4/4	0/0	1/1	(1)	(1)	4/4		
Butane	C ₄ H ₁₀	000106-97-8	tech. pure	F+	X	1/0	1/1	1/0	1/0	1/0	1/0	2/0	1/1	4/4	1/0	1/0	3/0	1/0	0/0	1/1	1/1	1/0	4/4	1/0	1/0	0/0	1/1	(1)	(1)	1/1		
Butanal	-> see: Butyraldehyde																															
Butanediol	-> see: Butylene glycol																															
Butanedioic acid	-> see: Succinic acid																															
Butanol	C ₄ H ₁₀ O	000071-36-3	techn. pure	Xn	X	1/1	1/3	1/0	2/3	1/0	1/2	1/2	1/2	1/2	2/3	2/3	4/4	1/3	1/1	1/1	1/1	1/1	2/0	3/4	1/0	0/0	1/1	(1)	(1)	0/0		
Butanol, secondary	-> see: Butyl alcohol, secondary																															
Butanol, tertiary	-> see: Butyl alcohol, tertiary																															
Butanol-2	-> see: Butyl alcohol, secondary																															
Butanone	-> see: Methyl ethyl ketone																															
Butanoic acid	-> see: Butyric acid																															
Butanetriol	C ₄ H ₁₀ O ₃	—	100 %	—		(4)	1/1	(1)	(2)	(2)	0/0	(1)	1/1	0/0	0/0	3/3	4/4	0/0	0/0	1/1	1/1	(1)	1/0	1/0	1/0	0/0	(1)	(1)	(1)	Isomer not specified in the source		
Butene	C ₄ H ₈	—	tech. pure	F+	X	4/4	0/0	1/0	(1)	1/0	0/0	1/0	4/4	0/0	0/0	1/0	0/0	0/0	0/0	1/1	1/0	1/0	3/0	1/0	3/0	0/0	1/1	(1)	(1)	0/0	Isomer not specified in the source	
Butenal, trans-2-	-> see: Crotonaldehyde																															
Butenedioic acid, cis-	-> see: Maleic acid																															
Butoxyethanol, 2-	-> see: Butyl glycol																															
Butter	—	—		—		1/0	1/0	1/0	1/0	1/0	0/0	1/1	1/1	1/1	0/0	0/0	0/0	1/1	0/0	1/1	1/1	(1)	3/0	1/0	1/1	0/0	(1)	(1)	(1)			
Buttersäure	C ₄ H ₈ O ₂	000107-92-6		C		3/4	4/4	3/3	4/4	0/0	4/4	4/4	4/4	4/4	2/2	2/4	4/4	4/4	1/1	1/1	1/1	1/1	4/4	3/4	4/4	0/0	1/2	1/2	1/1	1/1		
Butyric acid ethyl ester	-> see: Ethyl butyrate																															
Butyl acetate	-> see: Acetic acid butyl ester																															
Butyl acrylate	C ₇ H ₁₂ O ₂	000141-32-2	100 %	Xi	X	1/2	2/3	2/0	4/4	1/3	2/3	(2)	3/4	4/4	4/4	4/4	4/4	4/4	1/1	1/1	1/1	1/3	4/4	4/4	4/4	0/0	1/1	1/1	1/1	1/0		
Butyl alcohol	-> see: Butanol																															
Butyl alcohol, secondary	C ₄ H ₁₀ O	000078-92-2		Xn	X	1/1	1/2	(1)	2/3	1/0	1/2	(1)	1/2	2/2	2/3	2/2	0/0	0/0	1/1	1/1	1/1	1/1	3/0	(1)	(2)	0/0	1/1	(1)	(1)			
Butyl alcohol, tertiary	C ₄ H ₁₀ O	000075-65-0		F, Xn	X	1/1	1/2	(1)	2/3	1/0	1/2	(1)	1/2	1/1	2/3	1/2	0/0	0/0	1/1	1/1	1/1	1/1	3/0	(1)	(2)	0/0	1/1	(1)	(1)			
Butylamine	C ₄ H ₁₁ N	000109-73-9		F, C	X	0/0	0/0	0/0	(3)	0/0	0/0	3/4	2/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	4/4	4/4	0/0	(1)	(1)	(1)	0/0		
Butyl carbinol	-> see: Amyl alcohol, n-																															
Butyl cellosolve	-> see: Butyl glycol																															
Butylene	-> see: Butene																															
Butylen glycol	C ₄ H ₁₀ O ₂	—	tech. pure	—		1/1	1/1	1/0	1/0	1/0	0/0	1/0	1/1	0/0	0/0	1/3	0/0	0/0	0/0	1/1	1/1	1/1	1/0	4/4	(1)	0/0	1/1	(1)	(1)	0/0	Isomer not specified in the source	
Butyl ether	-> see: Dibutyl ether																															
Butyl ethylene	-> see: Hexene, 1-																															
Butyl glycol	C ₄ H ₁₄ O ₂	000111-76-2	100 %	Xn	X	0/0	1/0	1/0	(2)	1/0	0/0	1/0	1/0	0/0	0/0	4/4	4/4	0/0	0/0	1/1	1/0	1/1	3/0	3/4	3/4	0/0	1/1	(1)	(1)	0/0		
Butylphenol	C ₁₀ H ₁₄ O	—	100 %	Xi		0/0	1/1	(3)	(3)	0/0	(3)	(4)	1/1	0/0	0/0	3/4	4/4	0/0	0/0	(1)	1/1	1/1	4/4	3/0	4/4	0/0	1/1	1/1	1/1	1/1	Isomer not specified in the source	
Para tertiary butylphenol	C ₁₁ H ₁₆ NO	000098-54-4	tech. pure	C, Xn		3/0	0/0	(3)	(3)	0/0	(3)	(4)	1/0	0/0	0/0	3/0	0/0	0/0	0/0	(1)	1/0	1/1	4/4	3/0	4/4	0/0	1/1	1/1	1/1			
Butyl stearate	-> see: Stearic acid butyl ester																															

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	Thermoplastics										Fluoroplastics			Elastomers			Metals			REMARK							
					FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM		FPM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C
Butyraldehyde	C ₄ H ₈ O	000123-72-8		F, Xn	X	0/0	0/0	(3)	(3)	0/0	(4)	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(2)	(3)	3/0	4/4	0/0	(1)	(1)				
Cadmium bromide	CdBr	007789-42-6		T		1/1	1/1	(3)	(2)	(2)	0/0	(3)	(1)	1/1	0/0	0/0	0/0	1/1	0/0	1/1	1/1	(1)	(2)	(2)	(2)	0/0	4/4	0/0	0/0		
Calcium acetate	C ₄ H ₆ CaO ₄	000062-54-4	aqueous	—		1/1	1/1	(2)	(1)	(2)	0/0	(3)	(1)	1/1	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	4/4	3/3	0/0	(2)	(1)	(1)	0/0		
Calcium bicarbonate	Ca(HCO ₃) ₂	—	saturated	—		1/1	1/1	1/1	(1)	(1)	0/0	1/1	1/1	0/0	0/0	1/0	1/0	0/0	1/1	1/1	1/1	1/1	1/0	(1)	(1)	0/0	(2)	(1)	0/0		
Calcium bisulphite	Ca(HSO ₃) ₂	013780-03-5	saturated	Xn		1/1	1/1	(3)	(2)	0/0	0/0	4/4	1/1	0/0	0/0	1/0	0/0	0/0	0/0	1/1	1/1	1/1	4/4	1/0	3/3	0/0	(3)	1/1	1/3	1/1	
Calcium bisulphite	Ca(HSO ₃) ₂	013780-03-5	aqueous	Xn		1/1	1/1	(3)	(2)	0/0	0/0	4/4	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	4/4	1/0	3/3	0/0	(3)	1/1	1/3	1/1		
Calcium bromide	CaBr ₂	007789-41-5		?		1/1	1/1	(2)	(1)	(2)	0/0	(3)	1/1	1/1	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/1	(1)	(1)	(1)	0/0	(3)	0/0	0/0	0/0	
Calcium carbide	CaC ₂	000075-20-7		F	X	1/1	1/1	(2)	(2)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(1)	(2)	(2)	(2)	0/0	(3)	(1)	(1)	0/0	Carbide, reacts with water to form acetylene - highly flammable!
Calcium carbonate	CaCO ₃	000471-34-1	saturated	—		1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	No chemical effect expected due to low solubility	
Calcium chlorate	Ca(ClO ₃) ₂	010137-74-3	saturated	O, (T)		0/0	0/0	(3)	(2)	0/0	1/1	(3)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	(1)	1/1	(2)	(1)	(3)	0/0	1/1	(1)	1/0	1/1		
Calcium chloride	CaCl ₂	010043-52-4	alcoholic	F, Xi		1/0	0/0	4/4	(2)	0/0	1/0	(3)	1/1	0/0	0/0	0/0	4/4	0/0	0/0	1/1	1/0	(1)	(2)	(2)	(2)	0/0	(3)	1/2L	1/2L	1/1	
Calcium chloride	CaCl ₂	010043-52-4	aqueous	Xi		1/1	1/1	1/0	1/0	1/0	1/1	(3)	1/1	1/1	1/0	1/3	1/0	1/1	1/1	1/1	1/1	1/1	1/0	1/1	1/1	0/0	3/3	1/2L	1/2L	1/1	
Calcium hydrate	-> see: Calcium hydroxide																														
Calcium hydrogen carbonate	-> see: Calcium bicarbonate																														
Calcium hydrogen sulphite	-> see: Calcium bisulphite																														
Calcium hydroxide	CaH ₂ O ₂	001305-62-0	aqueous	(Xi)		1/1	1/1	1/0	4/4	1/0	1/1	1/1	1/1	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/1	1/0	1/0	0/0	3/4	1/1	1/1	0/0
Calcium hydroxide	CaH ₂ O ₂	001305-62-0	concentrated	C		1/1	1/1	1/0	4/4	1/0	1/1	1/1	1/1	2/2	2/2	1/1	1/0	0/0	1/1	1/1	1/1	1/3	1/0	1/1	1/0	0/0	3/4	1/1	1/1	0/0	
Calcium hypochlorite	Ca(OCl) ₂	007778-54-3	saturated	O, C		1/1	1/1	1/4	3/4	3/0	1/2	1/0	1/1	2/3	1/1	2/3	3/0	1/1	1/1	1/1	1/1	1/3	(2)	2/3	4/4	0/0	4/4	3/0	2/0	1/1	Bleaching powder
Calcium hypochlorite	Ca(OCl) ₂	007778-54-3	aqueous	O, C/Xi		0/0	0/0	4/4	1/0	3/0	0/0	1/0	1/1	1/3	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	2/3	4/4	0/0	4/4	3/0	2/0	1/1	Bleaching powder	
Calcium nitrate	Ca(NO ₃) ₂	010124-37-5	50 %	O		1/1	1/1	(2)	1/0	(2)	1/1	(3)	1/1	1/1	0/0	1/0	0/0	0/0	1/1	1/1	1/1	1/0	1/0	4/4	0/0	1/0	1/1	1/1	1/1	1/1	
Calcium nitrate	Ca(NO ₃) ₂	010124-37-5	aqueous	O		1/1	1/1	(2)	(1)	(2)	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/0	1/1	0/0	1/0	1/1	1/1	1/1	1/1	
Calcium oxide	CaO	001305-78-8	Powder	C		1/0	1/1	(2)	(2)	(2)	0/0	0/0	1/1	1/1	0/0	1/0	1/0	1/1	1/1	1/1	1/1	(1)	1/0	1/0	1/0	0/0	(3)	1/1	1/1		
Calcium phosphate	Ca ₅ (PO ₄) ₂	007758-87-4	aqueous	—		1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	(1)	1/1	1/1	0/0	No chemical effect expected due to low solubility
Calcium phosphate	Ca ₅ (PO ₄) ₂	007758-87-4		—		1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	(1)	1/1	1/1	0/0	No chemical effect expected due to low solubility
Calcium sulphate	CaSO ₄	007778-18-9	saturated	—		1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/3	1/1	0/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/1	1/1	0/0	Plaster
Calcium sulphide	CaS	020548-54-3	aqueous	C		0/0	0/0	(2)	(2)	0/0	0/0	(1)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/0	1/0	0/0	1/0	(1)	(1)	0/0		
Calcium sulphide	CaS	020548-54-3		C		0/0	3/3	(2)	(2)	0/0	0/0	(1)	1/1	0/0	0/0	1/0	0/0	0/0	1/1	1/1	1/1	1/0	1/0	3/3	0/0	0/0	(1)	(1)	0/0		
Camphor	C ₁₀ H ₁₆ O	000464-48-2	-49-2	F, Xn	X	3/4	3/4	(2)	(3)	0/0	0/0	(2)	1/0	1/3	0/0	4/4	4/4	1/1	0/0	(1)	1/0	(3)	4/4	3/4	1/0	0/0	(1)	1/0	1/0	1/0	
Camphor oil	—	008008-51-3		Xn		4/4	4/4	(2)	(3)	0/0	0/0	(2)	4/4	0/0	0/0	4/4	4/4	0/0	0/0	(1)	(2)	(3)	4/4	3/0	1/0	0/0	(1)	(1)	(1)	1/0	made from Cinnamomum Camphora
Paracymene	-> see: Cymene, p-																														
Capronaldehyde	-> see: Hexanal																														
Carbazole	C ₁₂ H ₉ N	000086-74-8		Xn		1/1	1/1	(2)	4/4	0/0	1/1	(1)	1/1	1/1	4/4	4/4	0/0	4/4	1/1	1/1	(2)	(2)	(2)	(3)	(2)	0/0	(1)	(1)	(1)	0/0	
Carbinol	-> see: Methanol																														
Carbolineum	—	008001-58-9	aqueous	(Xn)		1/0	1/0	1/0	(3)	1/0	0/0	1/0	1/0	0/0	0/0	1/0	0/0	0/0	0/0	(1)	1/0	(2)	3/0	1/0	3/3	0/0	(2)	(1)	(1)	0/0	
Carbolic acid	-> see: Phenol																														
Carbon disulfide	-> see: Carbon disulphide																														
Carbonyl chloride	-> see: Phosgene																														
Carnauba wax	—	008015-86-9		—		1/1	1/1	1/1	(1)	1/0	0/0	(1)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	0/0	1/1	1/1	(1)	(3)	(1)	(1)	0/0	1/1	(1)	(1)	
Caesium bromide	CsBr	007787-69-1		Xi		1/1	1/1	(2)	(2)	(2)	0/0	(1)	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	(1)	(1)	(2)	(1)	0/0	(2)	0/0	0/0		
Cellosolve	-> see: Ethyl glycol																														
Cellosolve acetate	-> see: Ethylene glycol monoethyl ether acetate																														
Cetyl alcohol	C ₁₆ H ₃₄ O	036653-82-4	100 %	Xi		1/1	1/1	4/4	(2)	1/0	0/0	(1)	1/1	0/0	1/0	1/1	3/3	1/1	1/1	1/1	1/1	1/1	1/0	1/0	1/0	0/0	(1)	1/1	1/1		
Cetylic acid	-> see: Palmitic acid																														
Quinine	C ₂₀ H ₂₄ N ₂ O ₂	000130-95-0		Xn		1/1	1/1	(2)	(2)	(2)	0/0	(1)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	(1)	(2)	(2)	(1)	0/0	(2)	(1)	(1)	0/0	
Chlorine	Cl ₂	007782-50-5	10 % wet	T		3/4	3/4	4/4	2/3	4/4	2/4	4/4	4/4	4/4	4/4	1/2	0/0	4/4	1/1	1/1	1/1	(2)	2/0	3/0	4/4	0/0	4/4	4/4	4/4	0/0	
Chlorine	Cl ₂	007782-50-5	97 %	T		4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	0/0	1/1	1/0	1/1	4/4	1/1	4/4	0/0	(3)	1/0	1/0	1/1	
Chlorosulfonic acid	-> see: Chlorosulfonic acid																														
Chlorine-1-propene, 3-	-> see: Allyl chloride																														
Chlor-2-propanone, 1-	-> see: Chloroacetone																														
Chloroacetone	C ₃ H ₅ ClO	000078-95-5		(F, Xi)	X	0/0	0/0	(3)	(4)	(4)	(4)	(3)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(2)	(3)	1/0	4/4	4/4	0/0	(4)	0/0	0/0	0/0	
Chloroacetophenone, p-Chloral	C ₈ H ₇ ClO	000099-91-2		(Xn)		1/1	1/1	(2)	4/4	0/0	1/1	(2)	1/1	4/4	4/4	4/4	0/0	0/0	1/1	1/1	(2)	(2)	(3)	4/4	4/4	0/0	(1)	0/0	0/0		
	-> see: Trichloroacetaldehyde																														

8 of 34

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	Thermoplastics														Fluoroplastics				Elastomers				Metals				Hastelloy C	REMARK
					FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMMA	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A			
Chloric acid	HClO ₃	007790-93-4	10 %	(O), C		1/0	0/0	4/4	(3)	0/0	0/0	4/4	4/4	0/0	0/0	1/3	0/0	0/0	0/0	0/0	0/0	1/1	1/1	3/0	3/0	4/4	0/0	4/4	4/4	4/4	1/1	
Chloric acid	HClO ₃	007790-93-4	20 %	(O), C		3/0	1/4	4/4	(3)	(4)	0/0	4/4	1/4	0/0	0/0	1/3	0/0	0/0	0/0	0/0	0/0	1/1	1/0	3/0	3/0	4/4	0/0	4/4	4/4	4/4	?	
Chlorosulfonic acid	ClHSO ₃	007790-94-5	tech. pure	C+		4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	3/0	4/4	4/4	0/0	0/0	1/0	3/4	4/4	4/4	4/4	0/0	3/3	3/4	3/4	1/0		
Chlorotoluene	C ₇ H ₇ Cl	—		Xn		0/0	0/0	(2)	4/4	0/0	(4)	(1)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/0	1/1	4/4	1/0	4/4	0/0	(3)	1/0	1/0	1/1	Isomer not specified in the source
Chlorotoluene, alpha-	-> see: Benzyl chloride																															
Chlorine trifluoride	ClF ₃	007790-91-2		(O, T)		0/0	0/0	4/4	(4)	4/4	(4)	4/4	(4)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(2)	(4)	4/4	(4)	4/4	0/0	(4)	(4)	(4)			
Chlorotrifluoromethane	CClF ₃	000075-72-9		?		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	3/0	1/0	0/0	(3)	0/0	0/0	0/0	0/0		
Chlorinated water	Cl ₂ x H ₂ O	007782-50-5		(T)		3/0	0/4	4/4	4/4	4/4	4/4	4/4	3/4	4/4	0/0	3/3	3/0	3/3	1/1	(1)	1/1	1/1	3/0	1/0	4/4	0/0	4/4	2/0L	2/0L	0/0	0/0	
Hydrochloric acid gas	HCl	007647-01-0	anhydrous	T, C		1/1	0/0	4/4	(3)	4/4	0/0	4/4	1/1	0/0	0/0	1/3	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/0	4/4	0/0	(4)	2/2L	2/2L	0/0		
Hydrochloric gas	-> see: Hydrogen acid																															
Hydronium chloride	-> see: Hydrochloric acid																															
Chlorozinc	-> see: Zinc chloride																															
Chromium (III) potassium sulphate dodecahydrate	-> see: Chrome alum																															
Chromium (VI) oxide	-> see: Chromic acid																															
Chrome alum	KCr(SO ₄) ₂ x 12H ₂ O	007788-99-0	saturated	Xn		1/1	0/0	(2)	1/0	(2)	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/0	1/1	0/0	(3)	1/3	1/3	1/1	
Chromium salts	—	—	any	T/Xn		0/0	0/0	0/0	(2)	(2)	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	(1)	(1)	(1)	0/0	K	K	K	K		
Chromic acid	CrO ₃	001333-82-0	10 %	O, T, C, N		1/1	1/1	4/4	2/3	3/0	1/1	4/4	1/1	1/1	4/4	1/2	0/0	0/3	1/1	1/1	1/1	1/1	4/4	1/1	4/4	0/0	1/3	1/2	1/2	1/1		
Chromic acid	CrO ₃	001333-82-0	20 %	O, T, C, N		0/0	1/3	4/4	3/4	(4)	0/0	4/4	3/3	1/0	1/0	1/0	1/0	0/0	0/0	1/1	1/1	1/1	4/4	1/1	4/4	0/0	1/3	(2)	(2)	1/1		
Chromic acid	CrO ₃	001333-82-0	50 %	O, T, C, N		3/4	3/4	4/4	3/4	(4)	2/3	4/4	3/3	3/3	4/4	1/3	1/0	3/3	1/1	1/1	1/1	1/1	4/4	1/0	4/4	0/0	(3)	2/3	2/3	1/1		
Chromic acid potassium salt	-> see: Potassium chromate																															
Chromosulphuric acid	CrO ₃ + H ₂ SO ₄	065272-71-1	concentrated	O, T, C, N		4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	0/0	0/0	4/4	4/4	1/1	0/0	1/1	4/4	4/4	1/0	4/4	4/4	4/4	2/3	2/3	0/0		
Chromium trioxide	-> see: Chromic acid																															
2-Hydroxypropane-1,2,3-tricarboxylic acid	-> see: Citric acid																															
Citric acid tributyl ester	-> see: Tributyl citrate																															
Clophen A60	—	011096-82-5		Xn, N		0/0	0/0	1/0	(3)	0/0	0/0	(2)	4/4	0/0	0/0	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(2)	4/4	2/3	4/4	0/0	1/0	1/0	1/0	0/0	ppolychlorinated biphenyls, PCBs; Bayer
Cobalt (II) chloride	CoCl ₂	007646-79-9	aqueous	Xn		1/1	1/1	(2)	(2)	(2)	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	1/0	1/0	1/0	0/0	(3)	0/0	0/0		
Cobalt dichloride	-> see: Cobalt (II) chloride																															
Colamine	-> see: Ethanolamine																															
Crotonaldehyde	C ₄ H ₆ O	004170-30-3	tech. pure	F, T	X	1/0	0/0	(2)	(4)	0/0	(4)	(2)	1/0	0/0	0/0	4/4	0/0	0/0	0/0	(1)	1/0	1/3	1/0	3/0	4/4	0/0	1/0	1/1	1/1	0/0		
Cumol	-> see: Cumene																															
Cumene	C ₉ H ₁₂	000098-82-8		Xi	X	2/3	3/4	(2)	4/4	0/0	4/4	(2)	3/4	4/4	4/4	4/4	0/0	0/0	1/2	1/1	(1)	(2)	4/4	1/0	4/4	0/0	1/1	1/1	1/1	0/0		
Curry	—	—		?		0/0	0/0	(2)	(2)	(2)	0/0	(1)	(2)	3/3	0/0	0/0	0/0	1/1	0/0	1/1	(1)	(1)	(2)	(2)	(2)	0/0	(1)	(1)	(1)		could lead to discolouration	
Ethyl cyanoacetate	-> see: Ethyl cyanoacetate																															
Cyanide	-> see: Potassium cyanide																															
Cyan potassium	-> see: Potassium cyanide																															
Cyannosodium	-> see: Sodium cyanide																															
Prussic acid	-> see: Hydrogen cyanide																															
Cyclanon	—	—		(Xn, Xi)		1/1	1/1	1/0	(2)	(1)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(1)	(2)	(2)	1/1	0/0	3/4	(1)	(1)	0/0	Polyquaternary compounds, dyeing auxiliaries; BASF	
Cyclohexane	C ₆ H ₁₂	000110-82-7		F	X	3/4	3/4	1/0	3/3	1/0	4/4	1/1	3/4	4/4	4/4	2/3	1/0	1/3	1/2	1/1	1/1	1/1	4/4	1/0	1/0	0/0	1/1	1/1	1/1	0/0		
Cyclohexanol	C ₆ H ₁₂ O	000108-93-0	tech. pure	Xn		1/1	1/1	1/1	3/0	0/0	1/2	1/0	1/3	3/3	1/0	1/1	4/4	1/3	0/0	(1)	1/1	1/3	4/4	4/4	3/3	0/0	1/1	(1)	(1)	0/0		
Cyclohexanone	C ₆ H ₁₀ O	000108-94-1	tech. pure	Xn	X	1/3	3/4	1/0	4/4	(4)	3/4	1/0	2/4	4/4	4/4	4/4	4/4	4/4	0/0	(1)	1/1	1/3	4/4	4/4	4/4	0/0	1/0	(1)	(1)	0/0		
Cyclohexylmethane	-> see: Methylcyclohexane																															
Cymene, p-	C ₁₀ H ₁₄	000099-87-6		F, Xn/Xi	X	0/0	0/0	(2)	4/4	0/0	(4)	(2)	(3)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	1/0	4/4	0/0	1/1	1/1	1/1	0/0		
Steam	H ₂ O	—	up to 150°C	?		4	4	4/4	0/0	0	0	(3)	(3)	0	0	0	0	0	0	0	0	1	0	1	3	4/4	0	(1)	1/1	1/1		
DDT (emulsion)	C ₁₄ H ₉ Cl ₅	000050-29-3		T		0/0	0/0	(2)	(3)	0/0	0/0	2	1/1	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	(2)	(3)	(3)	0/0	(2)	(2)	(2)	0/0			
Decahydronaphthalene	C ₁₀ H ₁₈	000091-17-8		Xn		1/3	3/4	1/0	4/4	3/0	4/4	1/0	3/4	4/4	4/4	1/2	3/0	3/4	1/1	1/1	1/1	1/1	4/4	1/1	4/4	0/0	1/1	(1)	(1)	0/0		
Decalin	-> see: Decahydronaphthalene																															
Decane	C ₁₀ H ₂₂	000124-18-5		Xn	X	0/0	0/0	(1)	(2)	(1)	(3)	1/1	(3)	0/0	0/0	0/0	0/0	0/0	0/0	1/1	(1)	(1)	4/4	1/0	3/3	0/0	1/1	(1)	(1)			
Decanedioic acid dibenzyl ester	-> see: Dibenzyl sebacate																															
Decanedioic acid dibutyl ester	-> see: Dibutyl sebacate																															
Decanedioic acid diethyl ester	-> see: Diethyl sebacate																															
Dehydroacetic acid	C ₈ H ₈ O ₄	000520-45-4																														

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	Thermoplastics										Fluoroplastics					Elastomers					Metals					REMARK	
					FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A		Hastelloy C
Desmodur 44	C ₁₅ H ₁₆ N ₂ O ₂	000101-68-8		Xn		0/0	0/0	0/0	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	0/0	4/4	0/0	(1)	(1)	(1)			
Dextrin	(C ₆ H ₁₀ O ₅) _n x H ₂ O	009004-53-9	aqueous	—		1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1		
Dextrose	-> see: Glucose																														
Diacetone alcohol	C ₆ H ₁₂ O ₂	000123-42-2		Xi	X	0/0	0/0	(3)	(3)	0/0	0/0	1/0	2/2	0/0	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	1/0	4/4	4/4	0/0	(2)	(1)	(1)		
Diamide	-> see: Hydrazine																														
Diaminoethane	-> see: Ethylenediamine																														
Diazane	-> see: Hydrazine																														
Dibenzyl ether	C ₁₄ H ₁₄ O	000103-50-4		Xi		0/0	0/0	(2)	(3)	0/0	0/0	(1)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	2/0	4/4	4/4	0/0	(1)	(1)	(1)		
Dibenzyl sebacate	C ₂₄ H ₃₆ O ₄	??		?		0/0	0/0	(2)	(3)	0/0	0/0	(2)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	2/0	(4)	4/4	0/0	(1)	(1)	(1)		Plasticiser
Dibromoethane-1,2	C ₂ H ₄ Br ₂	000106-93-4		T		(4)	(4)	(2)	(4)	(4)	(4)	(2)	4/4	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	1/2	4/4	(3)	4/4	0/0	(3)	1/0L	1/0L	0/0	
Dibromotetrafluoromethane	C ₂ Br ₂ F ₄	000124-73-2		?		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	4/4	3/0	3/0	0/0	(3)	0/0	0/0			
Dibutylamine	C ₈ H ₁₉ N	000111-92-2		Xn	X	0/0	0/0	(2)	(3)	0/0	(3)	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	4/4	4/4	0/0	(1)	(1)	(1)		
Dibutyl ether	C ₈ H ₁₈ O	000142-96-1	tech. pure	Xi	X	3/4	1/4	(2)	(3)	1/0	(4)	(1)	3/4	0/0	3/0	4/4	0/0	0/0	0/0	(1)	1/1	1/1	4/4	4/4	4/4	0/0	1/1	(1)	(1)	0/0	
Dibutyl phthalate	C ₁₆ H ₂₂ O ₄	000084-74-2	FR, 80°C	T		0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	(1)	0	0	0	4/4	0	0	0	0	0/0	Plasticiser
Dibutyl phthalate	C ₁₆ H ₂₂ O ₄	000084-74-2		T		1/3	3/3	1/0	4/4	1/0	0/2	1/0	2/2	4/4	1/0	4/4	4/4	0/4	1/1	(1)	1/1	1/3	3/0	2/3	4/4	0/0	(1)	1/1	1/1	0/0	Plasticiser
Dibutyl sebacate	C ₁₈ H ₃₄ O ₄	000109-43-3	tech. pure	—		1/0	1/3	1/0	(3)	0/0	0/0	(2)	1/0	4/4	0/0	4/4	4/4	4/4	0/0	(1)	1/1	1/0	3/0	4/4	4/4	0/0	(1)	(1)	(1)		Plasticiser
Dichloroide, 1,2-	-> see: Dichlorobenzene, 1,2-																														
Dichloroide, 1,4-	-> see: Dichlorobenzene, 1,4-																														
Dichlorobenzene, 1,2-	C ₆ H ₄ Cl ₂	000095-50-1		Xn		3/3	3/4	(1)	4/4	0/0	3/4	(2)	3/4	4/4	4/4	4/4	4/4	1/3	(1)	1/1	1/1	4/4	1/0	4/4	0/0	(1)	0/0	0/0	0/0		
Dichlorobenzene, 1,4-	C ₆ H ₄ Cl ₂	000106-46-7		Xn		2/3	3/4	1/0	4/4	0/0	2/3	(2)	3/4	4/4	4/4	4/4	0/0	1/3	(1)	1/0	1/1	4/4	1/0	4/4	0/0	(1)	0/0	0/0	0/0		
DCB, o-	-> see: Dichlorobenzene, 1,2-																														
DCB, p-	-> see: Dichlorobenzene, 1,4-																														
Dichlorodifluoromethane	CCl ₂ F ₂	000075-71-8	tech. pure	N		4/4	3/4	1/0	4/4	0/0	0/0	1/0	4/4	4/4	1/0	2/0	4/4	3/3	0/0	3/3	1/0	3/4	3/0	3/0	3/3	0/0	(3)	0/0	0/0	0/0	
Dichlorodifluoromethane	CCl ₂ F ₂	000075-71-8		N		4/4	3/4	1/0	4/4	0/0	0/0	1/0	4/4	4/4	1/0	2/0	4/4	3/3	0/0	3/3	1/0	3/4	3/0	3/0	3/3	0/0	(3)	0/0	0/0	0/0	
Dichlorodiphenyltrichloroethane	-> see: DDT (emulsion)																														
Dichloroacetic acid	C ₂ H ₂ Cl ₂ O ₂	000079-43-6	50 %	C		1/1	1/1	4/4	(4)	4/4	0/0	4/4	1/1	0/0	0/0	1/3	0/0	0/0	0/0	(1)	1/1	1/1	4/4	4/4	4/4	0/0	(4)	0/0	0/0	1/1	
Dichloroacetic acid	C ₂ H ₂ Cl ₂ O ₂	000079-43-6	tech. pure	C		1/3	3/3	4/4	(4)	4/4	0/0	4/4	1/3	0/0	0/0	1/3	0/0	0/0	0/0	(1)	1/1	1/1	4/4	4/4	4/4	0/0	(4)	0/0	0/0	1/1	
Dichloroacetic acid methyl ester	-> see: Methyl dichloroacetate																														
Dichlorethane, 1,2-	-> see: Ethylene chloride																														
Dichlorethane, 1,1-	-> see: Vinylidene chloride																														
Dichloroethylene	C ₂ H ₂ Cl ₂	—	tech. pure	F+, Xn	X	4/4	4/4	3/0	(4)	4/4	(4)	4/4	3/0	4/4	0/0	4/4	4/4	0/0	0/0	(1)	1/0	1/1	4/4	3/4	4/4	0/0	(3)	1/1L	1/1L	0/0	Isomer not specified in the source
Dichloroethylene, 1,1-	-> see: Vinylidene chloride																														
Dichlorofluoromethane	CHCl ₂ F	000075-43-4	100 %	N		0/0	3/0	1/0	3/0	0/0	0/0	1/0	4/4	4/4	3/0	4/4	4/4	3/3	0/0	(3)	1/0	(3)	4/4	4/4	4/4	0/0	(3)	0/0	0/0		
Dichlorohexafluorocyclobutane	C ₄ Cl ₂ F ₆	000356-18-3		?		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	(3)	1/0	0/0	(3)	0/0	0/0			
Dichloroisopropyl ether	C ₆ H ₁₂ Cl ₂ O	—		(Xn)		(4)	(4)	(2)	(3)	0/0	(4)	(3)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(3)	4/4	4/4	4/4	0/0	(3)	0/0	0/0		Isomer not specified in the source
Dichlormethane	CH ₂ Cl ₂	000075-09-2		Xn		4/4	4/4	3/4	4/4	4/4	3/4	3/0	3/4	4/4	4/4	4/4	4/4	4/4	2/2	1/1	1/1	1/3	4/4	3/3	4/4	0/0	4/4	(1/1L) ¹⁾	(1/1L) ¹⁾	1/1	¹⁾ Water-free! If even traces of hydrochloric acid (HCl) are split off by moisture, there is a risk of pitting, crevice and stress corrosion cracking.
Dichloropropane	C ₃ H ₆ Cl ₂	—	100 %	F, T/Xn	X	0/0	0/0	(3)	-4	(4)	(4)	(2)	4/4	4/4	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	4/4	(3)	4/4	0/0	(3)	0/0	0/0	0/0	Isomer not specified in the source
Dichlorotetrafluoroethane	C ₂ Cl ₂ F ₄	000076-14-2		?		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	3/0	1/0	0/0	(3)	0/0	0/0			
Dicyclohexylamine (DCHA)	C ₁₂ H ₂₃ N	000101-83-7		C, Xn		0/0	0/0	(2)	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	4/4	4/4	0/0	(1)	(1)	(1)		
Dicyclohexyl phthalate	C ₂₀ H ₂₆ O ₄	000084-61-7	tech. pure	(Xn)		0/0	0/0	(1)	(3)	0/0	0/0	(2)	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	0/0	(3)	4/4	4/4	4/4	0/0	(1)	(1)		Plasticiser
Diesel fuel	—	—		Xn, N		1/3	0/0	1/1	3/3	1/1	0/0	1/1	1/3	0/0	0/0	1/0	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	1/1	0/0	1/1	(1)	(1)	0/0	
Diesel oil	—	068334-30-5	100 %	(Xn)		1/3	1/4	1/1	3/3	1/1	0/0	1/1	1/3	3/4	0/0	1/3	3/3	1/1	0/0	(1)	1/1	1/1	4/4	1/1	1/1	0/0	1/1	(1)	(1)	0/0	
Diethanolamine (DEA)	C ₄ H ₁₁ NO ₂	000111-42-2	100 %	Xi		0/0	1/0	(2)	(3)	0/0	0/0	(2)	1/2	1/0	0/0	0/0	0/0	1/1	0/0	(1)	1/0	1/3	3/0	(3)	4/4	0/0	1/1	(1)	(1)	0/0	
Diethylamine	C ₄ H ₁₁ N	000109-89-7	tech. pure	F, C, Xn	X	0/0	0/0	(2)	(3)	0/0	0/0	(2)	1/2	0/0	0/0	3/0	0/0	0/0	0/0	(1)	1/0	1/4	2/0	4/4	4/4	0/0	(1)	1/1	1/1	0/0	
Diethylbenzene	C ₁																														

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	Thermoplastics										Fluoroplastics					Elastomers					Metals					Hastelloy C	REMARK
					FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMMA	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A		
Diethylmalonate	C ₇ H ₁₂ O ₄	000105-53-3		Xi		1/1	1/1	(2)	3/4	0/0	1/2	(2)	1/1	4/4	3/3	2/4	0/0	0/0	1/1	1/1	(1)	(3)	(2)	(4)	(3)	0/0	(1)	(1)	(1)		
Diethylmethane	-> see: Pentane																														
Diethyl sebacate	C ₁₄ H ₂₆ O ₄	000110-40-7		Xi		0/0	0/0	(2)	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	2/0	3/0	4/4	0/0	(1)	(1)	(1)		Plasticiser
Diethyl succinate	-> see: Succinic acid diethyl ester																														
Diffuorochloroethane	C ₂ H ₃ ClF ₂	000075-68-3		?		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	4/4	1/0	0/0	(3)	0/0	0/0		
Diffuoroethane	C ₂ H ₂ F ₂	000075-37-6		(E), F+		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	4/4	1/0	0/0	(3)	0/0	0/0		
Diffuoromethane	CH ₂ F ₂	000075-10-5		?		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	4/4	1/0	0/0	(3)	0/0	0/0		
Diffuorotetrachloroethane	C ₂ Cl ₄ F ₂	000076-12-0		?		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	4/4	3/0	0/0	(3)	0/0	0/0			
Diglycol	-> see: Diethylene glycol																														
Diglycolic acid	C ₄ H ₆ O ₅	000110-99-6	aqueous	Xn		1/1	1/1	(3)	(2)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	1/0	1/1	4/4	0/0	3/4	1/4	1/4	1/1	
Diglycolic acid	C ₄ H ₆ O ₅	000110-99-6	30 %	Xn, Xi		1/1	1/1	(3)	1/0	(2)	0/0	(3)	1/1	0/0	0/0	1/3	0/0	0/0	0/0	1/1	1/1	1/0	1/0	1/1	4/4	0/0	3/4	1/4	1/4	1/1	
Dihexyl phthalate	-> see: Dicyclohexyl phthalate																														
Dihydroxybenzene, 1,3-	-> see: Resorcinol																														
Dihydroxybenzene, 1,4-	-> see: Hydroquinone																														
Dihydroxysuccinic acid	-> see: Tartaric acid																														
Dihydroxydiethylamine	-> see: Diethanolamine																														
Diisobutylene (DIB)	C ₈ H ₁₆	025167-70-8		F	X	0/0	0/0	(1)	(3)	(2)	(4)	(1)	1/2	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	0/0	4/4	1/0	3/3	0/0	1/1	1/1	1/1		
Diisobutylketone	C ₈ H ₁₆ O	000108-83-8	tech. pure	Xi	X	1/4	1/3	(3)	(3)	(4)	(4)	1/0	1/4	0/0	0/0	4/4	0/0	0/0	0/0	(1)	1/1	1/3	3/0	4/4	4/4	0/0	(1)	(1)	(1)	0/0	
Diisooctyl phthalate (DOP)	C ₂₄ H ₃₈ O ₄	000117-81-7	tech. pure	Xn		4/4	4/4	1/0	4/4	1/0	1/0	(2)	4/4	4/4	1/0	4/4	4/4	0/0	0/0	1/1	1/0	(2)	3/0	2/3	4/4	0/0	(1)	(1)	(1)		Plasticiser
Diisopropyl ether	-> see: Isopropyl ether																														
Diisopropyl ketone	C ₇ H ₁₄ O	000565-80-0		F	X	0/0	0/0	(3)	(3)	(4)	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	1/0	4/4	4/4	0/0	(1)	(1)	(1)		
Dimethylamine	C ₂ H ₇ N	000124-40-3	tech. pure	F+, Xn	X	1/3	1/3	1/0	4/4	0/0	0/0	(2)	1/3	0/0	0/0	3/4	4/4	0/0	0/0	(1)	1/1	3/0	3/0	4/4	4/4	0/0	(1)	(1)	(1)	1/1	
Dimethylaniline	C ₈ H ₁₁ N	—		T		0/0	0/0	(3)	4/4	0/0	0/0	(2)	4/4	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	3/0	4/4	4/4	0/0	(1)	(1)	(1)	0/0	Isomer not specified in the source
Dimethylbenzene	-> see: Xylene																														
Dimethylcarbinol	-> see: Isopropyl																														
Dimethyl ether	C ₂ H ₆ O	000115-10-6	Gas	F+	X	0/0	3/0	1/0	(3)	1/0	0/0	(2)	4/4	4/4	0/0	3/0	4/4	0/0	0/0	0/0	1/0	(3)	3/0	4/4	4/4	0/0	1/1	(1)	(1)	0/0	
Dimethylformamide (DMF)	C ₃ H ₇ NO	000068-12-2		T, F	X	1/1	1/3	1	4/4	1/0	1/1	1/2	1/1	4/4	4/4	3/4	0/0	4/4	2/2	1/1	1/1	4/4	2/0	4/4	4/4	0/0	(1)	1/1	1/1	1/1	
Dimethyl ketone	-> see: Acetone																														
Dimethylpentanone-3, 2,4-	-> see: Diisopropyl ketone																														
Dimethyl phthalate (DMP)	C ₁₀ H ₁₀ O ₄	000131-11-3	100 %	(Xn)		4/4	1/3	(2)	4/4	0/0	0/0	(2)	2/3	4/4	0/0	4/4	4/4	4/4	0/0	(1)	1/1	(2)	3/0	2/0	4/4	0/0	(1)	(1)	(1)	0/0	Plasticiser
Dimethylpropane	-> see: Pentane																														
Dimethyl sulphoxide (DMSO)	C ₂ H ₆ SO	000067-68-5		Xi		1/1	1/1	(2)	4/4	0/0	1/1	1/0	1/1	1/2	4/4	4/4	0/0	0/0	1/2	1/1	(1)	(3)	(3)	(3)	(4)	0/0	(1)	(1)	(1)		
Disodium hydrogen phosphate	-> see: Disodium phosphate																														
Disodium phosphate	Na ₂ HPO ₄	007558-79-4		(Xi)		1/1	1/1	1/0	(2)	1/0	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/1	1/0	(1)	0/0	(1)	1/1	1/1	0/0	
Disodium sulphate	-> see: Sodium sulphate																														
Dinonyl phthalate (DNP)	C ₂₆ H ₄₂ O ₄	000084-76-4	tech. pure	Xn		3/0	0/0	(2)	3/0	0/0	0/0	(2)	1/3	0/0	0/0	4/4	0/0	0/0	0/0	(1)	1/0	(2)	(3)	4/4	4/4	0/0	(1)	(1)	(1)		Plasticiser
Diocetyl adipate	C ₂₂ H ₄₂ O ₄	000103-23-1		?		0/0	0/0	(2)	(3)	0/0	0/0	(2)	4/4	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(2)	(3)	(3)	4/4	0/0	(1)	(1)	(1)		Plasticiser
Diocetyl phthalate	-> see: Diisooctyl phthalate																														
Diocetyl sebacate	C ₂₆ H ₅₀ O ₄	002432-87-3		—		0/0	0/0	(2)	(3)	0/0	0/0	(2)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	2/0	3/0	4/4	0/0	(1)	(1)	(1)		Plasticiser
Dioxane	C ₄ H ₈ O ₂	000123-91-1		F, Xn	X	2/2	2/3	1/0	4/4	1/0	2/3	1/2	3/3	4/4	2/3	3/4	4/4	4/4	1/3	1/1	1/1	3/3	2/0	4/4	4/4	0/0	1/1	1/0	1/0	0/0	
Dioxane, 1,4-	-> see: Dioxane																														
Dipentene	-> see: Limonene, DL-																														
Dipentyl phthalate	-> see: Phthalic acid amyl ester																														
Diphenylamine	C ₁₂ H ₁₁ N	000122-39-4		T		0/0	0/0	0/0	(3)	0/0	0/0	(2)	(3)	0/0	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	(3)	(3)	(4)	0/0	(1)	(1)	(1)	0/0	
Diphenyleneimine	-> see: Carbazole																														
Diphenyl ether	C ₁₂ H ₁₀ O	000101-84-8		Xn/Xi		0/0	1/0	3/0	(3)	(4)	0/0	1/1	4/4	4/4	0/0	0/0	4/4	4/4	0/0	(1)	1/0	(2)	4/4	3/0	4/4	0/0	(1)	(1)	(1)	0/0	
Diphenylmethane diisocyanate (MDI)	-> see: Desmodur 44																														
Diphenyl oxide	-> see: Diphenyl ether																														
Diphosphorus pentoxide	-> see: Phosphorus pentoxide																														
Diphenyl	—	008004-13-5		?		0/0	0/0	1/1	(3)	4/4	0/0	1/1	4/4	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	3/0	4/4	0/0	(1)	(1)	(1)		Mixture of diphenyl and diphenyl ether, Bayer
Dipropylene glycol	C ₈ H ₁₈ O ₃	025265-71-8		Xi		1/1	1/1	(2)	2/3	0/0	1/1	1/0	1/1	1/1	2/2	2/3	0/0	0/0	1/1	1/1	(1)	(2)	4/4	3/0	3/3	0/0	(1)	(1)	(1)		
Dipropyl ketone	C ₇ H ₁₄ O	000123-19-3		—	X	0/0	0/0	(3)	(4)	(4)	(4)	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	(3)	(4)	4/4	0/0	(1)	(1)	(1)		
Dipropylmethane, n-	-> see: Heptane, n-																														
Di-sulphur dichloride	-> see: Sulphur chloride																														

MEDIUM	FORMULA	CAS No.	CONCENTRATION	HAZARD INFORMATION	Thermoplastics										Fluoroplastics				Elastomers				Metals				Hastelloy C	REMARK		
					FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI			AL	V2A
Dinitrogen tetroxide	-> see: Nitrogen tetroxide																													
Disulphite	-> see: Sodium disulphite																													
Divinylsulphide	-> see: Thiophene																													
Dodecanol	-> see: Lauryl alcohol																													
Dodecyl alcohol	-> see: Lauryl alcohol																													
Dodecyl chloride	-> see: Lauryl chloride																													
Dolcymene	-> see: Cymene, p-																													
Eau de Labarraque	-> see: Sodium hypochlorite																													
Edetic acid	-> see: Ethylenediaminetetraacetic acid																													
Iron (II) ammonium sulphate	-> see: Ammonium iron (II) sulphate																													
Iron (II) chloride	FeCl ₂	007758-94-3	saturated	Xn		1/1	1/1	3/0	1/0	(2)	1/0	(3)	1/1	1/1	1/0	1/1	1/0	1/1	1/1	1/1	(1)	1/1	(1)	0/0	4/4	(2)	1/1	1/1	1/1	1/1
Iron (II) sulphate	FeSO ₄	007720-78-7	saturated	(Xn)		1/1	1/1	(2)	1/0	0/0	1/0	(3)	1/1	1/0	0/0	1/0	0/0	1/1	1/1	1/1	(1)	(1)	(1)	0/0	4/4	1/1	1/1	1/1	1/1	1/1
Iron (II) sulphate	FeSO ₄	007720-78-7	aqueous	(Xn)		1/1	1/1	(2)	(2)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	(1)	(1)	1/0	0/0	4/4	1/1	1/1	1/1	1/1	1/1
Iron (II) sulphate	FeSO ₄	007720-78-7		Xn		1/1	1/1	(2)	1/0	(2)	0/0	(3)	1/1	1/1	0/0	0/0	1/1	1/1	1/1	1/1	(1)	1/0	(1)	0/0	4/4	1/1	1/1	1/1	1/1	1/1
Iron (III) chloride	FeCl ₃	007705-08-0	saturated	Xn		1/1	1/1	3/0	1/0	0/0	1/0	4/4	1/1	1/1	1/0	1/1	1/0	1/1	1/1	1/1	1/1	(1)	1/1	0/0	4/4	4/4	4/4	4/4	1/1	1/1
Iron (III) nitrate	-> see: Ferric nitrate																													
Iron (III) sulphate	Fe ₂ (SO ₄) ₃	010028-22-5	saturated	Xi		1/1	1/1	(2)	(2)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	(1)	(1)	(1)	0/0	4/4	1/1	1/1	1/1	1/1
Iron alum	-> see: Ammonium iron (III) sulphate																													
Iron ammonium alum	-> see: Ammonium iron (III) sulphate																													
Ferric nitrate	Fe(NO ₃) ₃	010421-48-4	aqueous	(O, Xn)		1/1	1/1	(2)	(2)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	(1)	(1)	1/0	0/0	4/4	1/1	1/1	1/1	1/1
Ferric nitrate	Fe(NO ₃) ₃	010421-48-4	saturated	O, Xn		1/1	1/1	1/0	1/0	0/0	1/0	(3)	1/1	1/1	0/0	1/1	1/0	1/1	1/1	1/1	1/1	(1)	(1)	1/0	0/0	4/4	1/1	1/1	1/1	1/1
Iron vitriol	-> see: Iron (II) sulphate																													
Glacial acetic acid	-> see: Acetic acid																													
Elaol	-> see: Dibutyl phthalate																													
Emulsifiers	—	—		?		0/0	0/0	(2)	0/0	0/0	0/0	0/0	1/1	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	(2)	(2)	(3)	0/0	0/0	K	K		
Developer fluids	—	—		?		1/1	1/1	4/4	1/0	1/0	0/0	1/0	1/1	0/0	1/0	1/1	1/0	0/0	0/0	1/1	(1)	2/0	1/0	3/3	0/0	1/1	1/0	1/0	0/0	
Limescale	—	—	10% in Water	?		0/0	0/0	0/0	0/0	0/0	0/0	0/0	1/1	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0
Epichlorohydrin	C ₂ H ₅ ClO	000106-89-8	100 %	F, T	X	1/0	1/0	4/4	(4)	0/0	(4)	1/0	2/2	0/0	0/0	4/4	4/4	0/0	0/0	(1)	1/0	(3)	3/0	4/4	4/4	0/0	(3)	0/0	0/0	0/0
Epoxypropane	-> see: Propylene oxide																													
Epsom salt	-> see: Magnesium sulphate																													
Natural gas	—	—		F+	X	0/0	0/0	0/0	1/0	1/0	0/0	1/0	(2)	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	4/4	1/0	1/0	0/0	1/1	(1)	(1)	0/0	mainly methane
Peanut oil	—	008002-03-7		—		0/0	0/0	0/0	(2)	1/0	0/0	(2)	1/1	1/1	0/0	0/0	0/0	1/1	0/0	(1)	1/1	(1)	4/4	1/0	1/0	0/0	(1)	(1)	(1)	0/0
Crude oil / petroleum	—	008002-05-9		(Xn)		0/0	0/0	1/0	(3)	1/0	0/0	1/0	1/0	0/0	0/0	0/0	0/0	0/0	(1)	1/0	1/1	4/4	1/0	3/3	0/0	(1)	(1)	(1)	0/0	Kerosene, lamp oil
Vinegar	C ₂ H ₄ O ₂	000064-19-7		(Xi)		1/1	1/3	4/4	1/2	1/1	1/0	1/3	1/1	1/0	1/0	1/0	3/0	1/1	1/1	1/1	1/1	1/0	3/3	3/3	0/0	1/3	1/2	1/2	1/1	Wine vinegar, acetic acid
Acetic ester	-> see: Ethyl acetate																													
Acetic acid	C ₂ H ₄ O ₂	000064-19-7	50 %	C		1/1	1/1	4/4	1/2	0/0	1/1	3/4	1/1	2/2	2/2	1/2	0/0	0/0	1/2	1/1	1/1	1/1	4/4	4/4	4/4	0/0	1/3	1/1	1/1	1/1
Acetic acid	C ₂ H ₄ O ₂	000064-19-7	100 %	C+	X	0/0	0/0	4/4	4/4	4/4	(3)	4/4	1/3	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	4/4	4/4	4/4	0/0	1/3	1/2	1/2	1/1	1/1
Acetic acid	C ₂ H ₄ O ₂	000064-19-7	90 %	C+	X	1/1	1/2	4/4	4/4	4/4	1/3	4/4	1/2	4/4	3/4	1/2	4/4	4/4	1/1	1/1	1/1	1/1	4/4	4/4	4/4	0/0	1/3	1/2	1/2	1/1
Acetic acid	C ₂ H ₄ O ₂	000064-19-7	10 %	Xi		1/1	1/1	4/4	1/2	1/1	3/0	1/4	1/1	1/1	1/0	1/3	1/0	1/3	1/1	1/1	1/1	(2)	(3)	3/3	0/0	1/3	1/1	1/1	1/1	1/1
Acetic acid	C ₂ H ₄ O ₂	000064-19-7	5 %	Xi		1/1	1/3	4/4	1/2	1/1	1/1	1/3	1/1	1/1	1/1	1/1	3/0	1/1	1/1	1/1	1/1	1/0	3/3	3/3	0/0	1/3	1/2	1/1	1/1	1/1
Acetic acid Silver salt	-> see: Silver acetate																													
Acetic alumina	C ₄ H ₇ AlO ₅ x H ₂ O	000142-03-0	saturated	Xi		1/1	1/0	(2)	(2)	(2)	0/0	1/0	1/1	0/0	0/0	1/0	1/0	1/1	1/1	1/1	1/1	(1)	1/0	4/4	3/3	0/0	(1)	1/1	1/1	
Acetic acid allyl ester	-> see: Allyl acetate																													
Acetic acid amide	-> see: Acetamide																													
Acetic anhydride	C ₄ H ₆ O ₃	000108-24-7	tech.pure	C	X	4/4	3/3	3/3	4/4	0/0	4/4	(2)	1/3	4/4	4/4	4/4	4/4	0/0	0/0	1/0	1/1	4/4	3/0	4/4	4/4	0/0	(2)	1/1	1/1	1/1
Acetic acid benzyl ester	-> see: Benzyl acetate																													
Acetic acid butyl ester	C ₈ H ₁₂ O ₂	000123-86-4	100 %	—	X	2/2	2/3	1/0	4/4	3/0	3/3	(2)	3/4	4/4	4/4	4/4	4/4	4/4	1/2	1/1	1/1	1/4	3/0	4/4	4/4	0/0	1/1	(1)	(1)	4/4
Acetic acid chloride	-> see: Acetyl chloride																													
Acetic acid ethyl ester	-> see: Ethyl acetate																													
Acetic acid isobutyl ester	-> see: Isobutyl acetate																													
Acetic acid isopropyl ester	-> see: Isopropyl acetate																													
Acetic acid methyl ester	C ₃ H ₈ O ₂	000079-20-9	tech. pure	F	X	1/0	1/1	1/0	4/4	3/0	(4)	2/0	1/3	4/4	0/0	4/4	4/4	4/4	0/0	1/0	1/1	1/4	3/0	4/4	4/4	0/0	(1)	1/1	1/1	0/0
Acetic acid-n-amyl ester	-> see: Amyl acetate, n-																													
Acetic acid pentyl ester	-> see: Amyl acetate, n-																													

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	FLAMMABLE	Thermoplastics														Fluoroplastics				Elastomers				Metals				Hastelloy C	REMARK
						HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FKM / FKM	NR	SI	AL	V2A	V4A				
Ethanal	-> see: Acetaldehyde																																
Ethane carboxylic acid	-> see: Propionic acid																																
Ethanediamine	-> see: Ethylenediamine																																
Ethanedicarboxylic acid	-> see: Succinic acid																																
Ethanediol	-> see: Ethylene glycol																																
Ethanedioic acid	-> see: Oxalic acid																																
Ethanol	C ₂ H ₅ O	000064-17-5	40 %	—	X	1/1	1/2	1/0	1/2	1/1	1/2	1/2	1/1	2/3	1/2	1/1	0/0	1/1	1/1	1/1	1/0	1/0	1/1	1/1	1/1	1/1	1/1	1/1					
Ethanol	C ₂ H ₅ O	000064-17-5	50 %	—	X	1/1	1/1	1/0	1/1	1/1	1/0	1/2	1/1	1/0	1/0	1/0	3/0	0/0	0/0	1/1	1/1	1/1	1/0	(2)	1/1	0/0	1/1	1/1					
Ethanol	C ₂ H ₅ O	000064-17-5	96 %	F	X	1/0	1/3	1/1	1/0	1/3	1/1	1/2	1/2	1/1	3/4	1/2	1/3	3/0	1/3	1/1	1/1	1/0	3/0	3/3	0/0	1/1	1/1	1/1					
Ethanolamine	C ₂ H ₇ NO	000141-43-5		Xn/Xi		0/0	0/0	(3)	(3)	0/0	0/0	(3)	1/2	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	3/0	4/4	4/4	0/0	(1)	(1)					
Ethanoic acid	-> see: Acetic acid																																
Ethanethiol	C ₂ H ₅ S	000075-08-1		F, Xn	X	0/0	0/0	(2)	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	(3)	(3)	4/4	0/0	(1)	(1)					
Ethene	-> see: Ethylene																																
Ether	-> see: Ethyl ether																																
Ethyne	-> see: Acetylene																																
Ethynylcarbiol	-> see: Propargyl alcohol																																
Ethoxyacetanilide, 4-	-> see: Phenacetin																																
Ethoxyethanol	-> see: Ethyl glycol																																
Ethoxyethyl acetate, 2-	-> see: Ethylene glycol monoethyl ether acetate																																
Ethyl(hydroxymethyl)-propanediol	-> see: Trimethylolpropane																																
Ethyl acetate	C ₄ H ₈ O ₂	000141-78-6	100 %	F	X	1/3	3/4	1/0	4/4	4/4	4/4	1/1	1/3	4/4	4/4	4/4	4/4	4/4	4/4	1/2	1/1	1/1	3/3	3/0	4/4	4/4	0/0	1/1					
Ethyl acrylate	C ₈ H ₈ O ₂	000140-88-5	100 %	F, Xn	X	4/4	4/4	1/0	(4)	(4)	(4)	(2)	4/4	0/0	0/0	4/4	4/4	0/0	0/0	1/1	1/0	3/0	4/4	4/4	4/4	0/0	(1)	1/0					
Ethyl alcohol	-> see: Ethanol																																
Ethylbenzol	-> see: Ethylbenzene																																
Ethyl benzoate	-> see: Benzoic acid ethyl ester																																
Ethylbenzene	C ₈ H ₁₀	000100-41-4		F, Xn	X	2/3	3/4	(2)	4/4	0/0	3/4	1/0	3/4	4/4	4/4	4/4	4/4	4/4	2/3	1/1	1/0	1/1	4/4	(2)	4/4	0/0	(1)						
Ethyl butyrate	C ₈ H ₁₆ O ₂	000105-54-4		F	X	2/3	2/4	(2)	4/4	0/0	3/4	(2)	2/4	4/4	4/4	4/4	0/0	0/0	1/2	1/1	(1)	(2)	(3)	(4)	4/4	0/0	(1)						
Ethylcarbinol	-> see: Propanol																																
Ethyl cellosolve	-> see: Ethyl glycol																																
Ethyl chloroacetate	C ₄ H ₇ ClO ₂	000105-39-5	tech. pure	T/Xi		1/1	1/1	(3)	4/4	(4)	(4)	(3)	1/1	4/4	0/0	3/4	3/4	0/0	0/0	(1)	1/1	1/4	3/0	4/4	4/4	0/0	3/4						
Ethyl chloride	-> see: Chloroethane																																
Ethyl cyanoacetate	C ₅ H ₇ NO ₂	000105-56-6		Xn/Xi		1/1	1/1	0/0	3/4	0/0	1/1	(2)	1/1	2/4	3/3	3/4	0/0	0/0	1/1	1/1	(1)	(3)	(2)	(3)	(3)	0/0	(2)						
Ethylene	C ₂ H ₄	000074-85-1		F+	X	0/0	0/0	1/0	(2)	0/0	0/0	1/0	(2)	0/0	0/0	0/0	0/0	0/0	0/0	1/1	(1)	(2)	(3)	3/0	3/3	0/0	(1)						
Ethylene(di)bromide	-> see: Dibromoethane-1,2																																
Ethylene(di)chloride	-> see: Dichloroethane-1,2																																
Ethylene chlorohydrin	-> see: Chloroethanol																																
Ethylene chloride	C ₂ H ₄ Cl ₂	—		F, T	X	3/3	2/4	3/0	4/4	4/4	4/4	1/0	3/4	4/4	4/4	4/4	4/4	4/4	1/1	1/1	1/1	1/1	4/4	3/0	4/4	0/0	1/3						
Ethylenediamine	C ₂ H ₈ N ₂	000107-15-3	tech. pure	C, Xn	X	1/1	1/3	1/0	(3)	0/0	1/0	1/0	1/1	0/0	0/0	3/0	4/4	0/0	0/0	(1)	1/1	1/4	1/0	4/4	3/3	0/0	1/1						
Ethylenediaminetetraacetic acid (EDTA)	C ₁₀ H ₁₆ N ₂ O ₈	000060-00-4		Xi		1/1	1/1	(2)	(2)	(2)	0/0	1/0	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	(1)	(1)	(2)	(1)	0/0	(3)						
Ethylene dichloride	-> see: Ethylene chloride																																
Ethylenedinitrilotetraacetic acid	-> see: Ethylenediaminetetraacetic acid																																
Ethylene glycol	C ₂ H ₆ O ₂	000107-21-1		Xn		1/1	1/1	3/3	2/3	1/0	1/1	1/1	1/1	1/1	1/1	1/1	3/3	1/1	1/1	1/1	1/1	1/0	1/2	1/1	0/0	1/1							
Ethylene glycol ethyl ether	-> see: Ethyl glycol																																
Ethylene glycol monobutyl ether	-> see: Butyl glycol																																
Ethylene glycol monobutyl ether	-> see: Ethyl glycol																																
Ethylene glycol monoethyl ether acetate	C ₆ H ₁₂ O ₃	000115-15-9		Xn	X	1/1	1/2	0/0	3/4	0/0	1/2	(2)	1/2	4/4	4/4	3/4	0/0	0/0	1/2	1/1	(1)	(2)	2/0	4/4	4/4	0/0	(1)						
Ethylene glycol monomethyl ether	-> see: Methyl glycol																																
Ethylene oxide	C ₂ H ₄ O	000075-21-8		F+, T	X	2/3	3/3	3/0	3/4	1/0	3/4	1/0	3/3	4/4	1/1	3/4	0/0	0/0	1/1	1/1	(1)	1/1	4/4	4/4	4/4	0/0	1/1						
Ethylene tetrachloride	-> see: Perchloroethylene																																
Ethylene trichloride	-> see: Trichloroethylene																																
Ethylethanamine, N-	-> see: Diethylamine																																
Ethyl ether	C ₄ H ₁₀ O	000060-29-7	tech. pure	F+, Xn	X	3/4	4/4	1/1	4/4	1/0	4/4	1/2	4/4	4/4	4/4	4/4	4/4	4/4	1/2	1/1	1/1	1/4	4/4	4/4	4/4	0/0	1/1						
Ethyl formate	C ₃ H ₆ O ₂	000109-94-4		F	X	0/0	0/0	0/0	(4)	0/0	(4)	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(3)	(3)	(4)	4/4	0/0	(1)						
Ethyl glycol	C ₄ H ₁₀ O ₂	000110-80-5	100 %	T	X	0/0	4/4	(3)	(2)	0/0	0/0	1/0	2/4	4/4	1/0	4/4	4/4	4/4	0/0	1/1	1/0	1/1	3/0	4/4	4/4	0/0	(1)						
Ethyl glycol acetate	-> see: Ethylene glycol monoethyl ether acetate																																

Two values are given for each medium:
left number = value at +20°C / right number = value at +50°C

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	Thermoplastics														Fluoroplastics				Elastomers				Metals				Hastelloy C	REMARK
					FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A			
Ethylhexanol-1	C ₈ H ₁₈ O	000104-76-7		Xn/Xi		0/0	1/3	(2)	(2)	(1)	1/0	1/0	1/0	3/0	0/0	1/0	4/4	0/0	0/0	0/0	(1)	1/1	(1)	1/0	1/0	1/0	0/0	(1)	(1)	(1)		
Ethyl lactate	C ₆ H ₁₀ O ₃	000097-64-3		—	X	1/1	1/1	(2)	3/4	0/0	1/1	(2)	1/1	3/4	3/3	3/4	0/0	0/0	1/1	1/1	(1)	3/0	(3)	(3)	(3)	0/0	(1)	(1)	(1)			
Ethyl malonate	-> see: Diethylmalonate																															
Ethyl mercaptan	-> see: Ethanethiol																															
Ethyl methyl ketone	-> see: Methyl ethyl ketone																															
Ethyl silicate	-> see: Tetraethylorthosilicate																															
Eucalyptus oil	—	008000-48-8		?		0/0	0/0	(2)	(3)	0/0	0/0	(2)	(2)	4/4	0/0	0/0	0/0	3/3	0/0	(1)	(1)	(2)	4/4	(3)	(4)	0/0	(1)	(1)	(1)			
Desiccator grease	—	—		—		0/0	1/3	1/0	(2)	(1)	0/0	(1)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(1)	(3)	(2)	(2)	0/0	(1)	(1)	(1)	0/0		
Ferrichloride	-> see: Iron (III) chloride																															
Potassium hexacyanoferrate(III)	C ₆ FeK ₃ N ₆	013746-66-2	any	Xn		1/1	1/1	1/0	(1)	(1)	0/0	2/0	1/1	1/1	0/0	1/3	1/1	0/0	1/1	1/1	1/1	1/1	(1)	(1)	(1)	0/0	1/1	1/1	1/1	1/1		
Ferrous chloride	-> see: Iron (II) chloride																															
Potassium hexacyanoferrate(II)	C ₆ FeK ₄ N ₆ x 3H ₂ O	014459-95-1	saturated	—		1/1	1/1	1/0	(2)	(1)	0/0	2/0	1/1	0/0	0/0	1/1	1/1	0/0	1/1	1/1	1/1	1/1	(1)	(1)	(1)	0/0	(1)	1/1	1/1			
Potassium hexacyanoferrate(II)	C ₆ FeK ₄ N ₆ x 3H ₂ O	014459-95-1	diluted	—		1/0	1/1	1/0	(1)	(1)	0/0	2/0	1/1	0/0	0/0	1/3	1/0	0/0	1/1	1/1	1/1	1/1	(1)	(1)	(1)	0/0	1/1	1/1	1/1			
Fat/Grease, mineral	—	—		(—)		0/0	0/0	1/0	(2)	(1)	0/0	1/1	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	(4)	(1)	1/0	0/0	(1)	1/1	1/1			
Fat/Grease, vegetable	—	—		—		0/0	0/0	1/0	(2)	1/0	0/0	1/1	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	1/0	0/0	(1)	1/1	1/1			
Fat/Grease, animal	—	—		—		0/0	0/0	1/0	(2)	1/0	0/0	1/1	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	1/0	0/0	(1)	1/1	1/1			
Fatty/Greasy alcohol sulphonates	—	—	aqueous	(Xn, Xi)		1/1	0/0	1/0	(2)	1/0	0/0	1/1	1/3	0/0	0/0	1/3	0/0	0/0	0/0	(1)	1/1	1/1	(2)	(2)	1/1	0/0	3/4	1/0	1/0	0/0	Fatty alcohol sulphates, wetting agents/surfactants	
Fat/Grease, edible oil	—	—		—		0/0	1/0	1/0	1/0	1/0	1/0	1/1	3/0	0/0	1/0	1/0	3/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	1/1	0/0	(1)	1/1	1/1	1/1		
Fatty acid C16	-> see: Palmitic acid																															
Spruce needle oil	—	008008-80-8		?		1/2	2/4	(2)	2/3	0/0	2/3	(2)	1/2	4/4	3/3	3/4	0/0	3/4	1/2	1/1	(1)	(2)	4/4	1/0	3/3	0/0	(1)	(1)	(1)		Pinus sylvestris	
Fish oil	—	—		—		0/0	0/0	1/0	(2)	1/0	0/0	(1)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	3/4	1/0	1/0	0/0	(1)	(1)	(1)			
Fixing salt	-> see: Sodium thiosulphate																															
Aircraft engine fuels (JP)	—	—		(Xn)		0/0	0/0	(1)	(3)	0/0	0/0	1/0	1/4	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(2)	4/4	1/0	1/0	0/0	(1)	(1)	(1)			
Fluid 101, 100°C	—	—		?		0	0	0	0	0	0	0	(3)	0	0	0	0	0	0	0	0	0	0	3	0	0	0	0	0		Brake fluid, polyglycol base	
Fluorine	F ₂	007782-41-4		O, T+, C+		4/4	4/4	4/4	4/4	4/4	3/4	4/4	4/4	4/4	4/4	1/2	0/0	4/4	1/1	1/1	1/1	4/4	4/4	3/0	4/4	0/0	4/4	(4)	(4)	0/0		
Fluorammonium	-> see: Ammonium fluoride																															
Fluorobenzene	C ₆ H ₅ F	000462-06-6		F, (Xn)	X	0/0	0/0	(2)	(4)	0/0	(4)	(2)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(2)	4/4	3/0	4/4	0/0	(1)	0/0	0/0			
Fluorochloroalkanes (FCKW)	—	—		N		0/0	0/0	(2)	(3)	0/0	0/0	1/0	(3)	4/4	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(3)	(3)	0/0	(3)	0/0	(3)	0/0	0/0		Resistance varies depending on type	
Fluorides	—	—		T		1/1	1/1	(2)	1/1	(2)	1/1	(1)	1/1	2/2	1/1	1/1	0/0	1/1	1/1	(1)	(1)	(2)	(2)	(1)	0/0	0/0	K	K				
Fluoropotassium	-> see: Potassium fluoride																															
Fluorosilicic acid	-> see: Silicofluoric acid																															
Fluorocarbons (FKW)	—	—		?		0/0	0/4	(2)	(3)	(2)	0/0	(2)	(3)	4/4	0/0	0/0	0/0	0/4	1/1	0/0	1/1	0/0	(3)	(3)	(3)	0/0	(1)	0/0	0/0		Resistance varies depending on type	
Fluorosilicic acid	-> see: Silicofluoric acid																															
Fluorotrichloromethane	-> see: Trichlorofluoromethane																															
Hydrogen fluoride	HF	007664-39-3	anhydrous	T+, C+		0/0	0/0	4/4	4/4	4/4	0/0	4/4	(2)	0/0	4/4	0/0	0/0	0/0	0/0	(1)	1/0	0/0	3/4	(3)	4/4	0/0	4/4	(3)	(3)		Hydrofluoric acid, anhydrous	
Hydrogen fluoride solution	-> see: Hydrofluoric acid																															
Hydrofluoric acid	-> see: Hydrofluoric acid																															
Liquid soaps	—	—		?		1/1	1/1	1/0	(2)	(2)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	(2)	(2)	(2)	0/0	(3)	0/0	0/0				
Hydrofluoric acid	HF	007664-39-3	4 %	T, C		1/1	1/2	4/4	2/3	4/4	1/2	4/4	1/2	2/3	2/3	2/3	0/0	0/0	1/1	1/1	1/1	1/1	(3)	1/3	(2)	0/0	4/4	0/0	0/0	?		
Hydrofluoric acid	HF	007664-39-3	50 %	T+, C		1/1	1/1	4/4	4/4	4/4	1/1	4/4	1/1	4/4	3/4	2/3	2/0	3/3	1/1	1/1	1/1	1/1	3/4	1/3	3/4	0/0	4/4	4/4	4/4	?		
Hydrofluoric acid	HF	007664-39-3	70 %	T+, C		0/0	1/3	4/4	4/4	4/4	0/0	4/4	1/3	4/4	4/4	1/4	3/0	0/0	0/0	(1)	1/1	1/1	3/4	(3)	4/4	0/0	4/4	4/4	4/4	?		
Hydrofluoric acid	HF	007664-39-3	100 %	T+, C+		0/0	0/0	4/4	4/4	4/4	0/0	4/4	(2)	0/0	4/4	0/0	0/0	0/0	0/0	(1)	1/0	0/0	3/4	(3)	4/4	0/0	4/4	(3)	(3)	?		
Hydrofluoric acid, anhydrous	-> see: Hydrogen fluoride																															
Formaldehyde solution	CH ₂ O	000050-00-0	10 %	Xn		1/1	1/1	3/3	1/2	1/0	1/2	1/2	1/1	3/4	2/3	2/3	3/3	1/3	1/1	1/1	1/1	1/1	1/0	3/0	(2)	0/0	1/1	1/1	1/1	1/1		
Formaldehyde solution	CH ₂ O	000050-00-0	30 %	T		1/1	1/1	3/3	1/2	1/0	0/0	1/2	1/1	4/4	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	3/0	1/0	0/0	1/1	1/1	1/1	1/1		
Formaldehyde solution	CH ₂ O	000050-00-0	40 %	T		1/2	2/3	1/3	1/2	1/0	1/2	1/2	1/2	4/4	2/3	2/3	3/3	0/4	1/1	1/1	1/1	1/1	1/0	3/0	(3)	0/0	1/1	1/1	1/1	1/1		
Formalin	-> see: Formaldehyde solution																															
Formamide	CH ₃ NO	000075-12-7	tech. pure	T/Xi		1/1	1/1	1/0	(3)	0/0	0/0	1/0	1/1	1/0	0/0	4/4	4/4	0/0	0/0	1/0	1/1	(3)	3/0	2/3	4/4	0/0	1/1	1/1	1/1	1/1		
Formin	-> see: Hexamethylenetetramine																															
Formylic acid	-> see: Formic acid																															
Photo emulsions	—	—		?		1/0	0/0	1/0	(2)	(2)	0/0	1/0	1/1	0/0	0/0	1/0	0/0	0/0	0/0	(1)	1/1	1/1	(2)	(2)	(1)	0/0	(2)	0/0	0/0			
Photo developers	—	—		?		1/3	1/1	4/4	(2)	1/0	0/0	1/3	1/2																			

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	FLAMMABLE	Thermoplastics										Fluoroplastics				Elastomers				Metals				Hastelloy C	REMARK		
						HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL			V2A	V4A
Freon 11	-> see: Trichlorofluoromethane																														
Freon 112	-> see: Difluorotetrachloroethane																														
Freon 113	-> see: Trichlorotrifluoroethane																														
Freon 114	-> see: Dichlorotetrafluoroethane																														
Freon 114 B2	-> see: Dibromotetrafluoromethane																														
Freon 115	-> see: Chloropentafluoroethane																														
Freon 12	-> see: Dichlorodifluoromethane																														
Freon 13	-> see: Chlorotrifluoromethane																														
Freon 13 B1	-> see: Bromotrifluoromethane																														
Freon 14	-> see: Tetrafluoromethane																														
Freon 142b	-> see: Difluorochloroethane																														
Freon 152a	-> see: Difluoroethane																														
Freon 21	-> see: Dichlorofluoromethane																														
Freon 218	-> see: Perfluoropropane																														
Freon 22	-> see: Chlorodifluoromethane																														
Freon 31	-> see: Chlorofluoromethane																														
Freon 32	-> see: Difluoromethane																														
Freon C 318	-> see: Octafluorocyclobutane																														
Freon C316	-> see: Dichlorohexafluorocyclobutane																														
Frigen 12	-> see: Dichlorodifluoromethane																														
Frigen 21	-> see: Dichlorofluoromethane																														
Frigen 22	-> see: Chlorodifluoromethane																														
Antifreeze (KFZ)	—	—		Xn		1/1	1/1	3/3	(1)	1/0	0/0	1/1	1/1	1/1	0/0	0/0	0/0	0/0	(1)	1/0	1/1	1/0	1/2	1/1	0/0	(1)	1/1	1/1	1/1	Glycol-water mixtures	
Fruit juices	—	—		—		1/1	1/1	1/0	1/0	1/0	1/0	1/1	1/1	1/0	0/0	1/1	1/1	0/0	0/0	1/1	1/1	1/1	1/0	1/1	1/1	0/0	(2)	1/1	1/1	1/1	
Fruit sugar	-> see: Fructose																														
Fructose	C ₆ H ₁₂ O ₆	000057-48-7	any	—		1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/1	1/1	0/0	1/1	1/1	1/1	1/1	
Furan	C ₄ H ₄ O	000110-00-9		F+, T+	X	0/0	0/0	(3)	4/4	0/0	(4)	(2)	(3)	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(3)	4/4	4/4	4/4	0/0	(1)	(1)	(1)	0/0		
Furanal	-> see: Furfural																														
Furancarbinol, 2-	-> see: Furfuryl alcohol																														
Furanmethanol, 2-	-> see: Furfuryl alcohol																														
Furfural	-> see: Furfural																														
Furfural alcohol	-> see: Furfuryl alcohol																														
Furfuran	-> see: Furan																														
Furfural	C ₅ H ₄ O ₂	000098-01-1		T		1/3	3/4	3/3	(3)	1/0	0/0	2/0	4/4	0/0	0/0	0/0	0/0	4/4	0/0	(1)	(1)	1/2	3/0	4/4	4/4	0/0	1/1	1/1	1/1	0/0	
Furfuryl alcohol	C ₅ H ₆ O ₂	000098-00-0	tech. pure	Xn		1/1	1/3	1/0	(3)	1/0	0/0	1/0	1/3	0/0	4/4	4/4	4/4	3/4	0/0	(1)	1/1	1/3	3/0	(3)	4/4	0/0	(1)	(1)	(1)	0/0	
Furylaldehyde, 2-	-> see: Furfural																														
Furylmethanal, 2-	-> see: Furfural																														
Gallotannin	-> see: Tannin																														
Gallic acid	C ₇ H ₆ O ₅ x H ₂ O	000149-91-7		Xi		1/1	1/1	1/0	(3)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	1/1	0/0	(1)	1/1	1/4	3/0	1/0	3/0	0/0	1/0	1/1	1/1	1/1	
Fermentation amyl alcohol	-> see: Isoamyl alcohol																														
Fermentation mash	—	—		?		1/1	1/1	(2)	(2)	(1)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	(2)	(1)	1/0	4/4	0/0	(2)	(1)	(1)	0/0	
Gas oil (straight-run)	—	—		(Xn)		0/0	0/0	(1)	(2)	1/0	0/0	(2)	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	1/0	0/0	1/1	(1)	(1)		
Gasoline	—	008006-61-9		(F, Xn)	X	0/0	0/0	(1)	3/4	(2)	0/0	1/2	3/4	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	3/0	0/0	1/1	(1)	(1)		
Gas water	—	—		?		0/0	0/0	(2)	(2)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	(3)	(2)	(2)	0/0	(2)	0/0	0/0		
Gelatine	—	009000-70-8	any	—		1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/0	1/0	0/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/1	1/1	1/1	0/0	
Genantin	—	—		Xn		0/0	0/0	3/3	(2)	1/0	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/0	1/2	1/1	0/0	1/1	1/1	1/1		Antifreeze, basis glycol; Clariant
Tanning extracts, vegetable	—	—	tech. common	?		1/1	1/1	1/0	(3)	0/0	0/0	4/4	1/1	0/0	0/0	1/0	0/0	0/0	0/0	(1)	1/1	1/1	3/0	1/0	3/3	0/0	1/0	1/1	1/1	1/1	
Tanning extracts	—	—		?		1/1	1/1	1/0	(3)	0/0	0/0	4/4	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	3/0	1/0	3/3	0/0	1/0	1/1	1/1	1/1	
Tannic acid	-> see: Tannin																														
Gear oil, EP (hypoid), 110°C	—	—		?		0	0	1	1	1	0	4	(3)	0	0	0	0	0	0	0	(2)	0	4/4	0	4/4	0	(1)	1	1		
Plaster	-> see: Calcium sulphate																														
Glauber's salt	-> see: Sodium sulphate																														
Glucaric acid	-> see: Sugar acid																														
Glucose	C ₆ H ₁₂ O ₆	000050-99-7	any	—		1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	
Glucose syrup	-> see: Starch syrup																														

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	FLAMMABLE	Thermoplastics														Fluoroplastics				Elastomers				Metals				REMARK
						HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FKM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C		
Glycerine	C ₃ H ₈ O ₃	000056-81-5	any	Xi		1/1	1/1	1/0	3/3	1/0	1/1	1/0	1/1	1/1	1/1	1/1	1/1	1/1	1/0	1/1	1/0	1/1	1/1	1/1	1/1	1/1	1/1					
Glycerol trinitrate	-> see: Nitroglycerin																															
Glycine	-> see: Aminoacetic acid																															
Glycol	-> see: Ethylene glycol																															
Glycol dinitrate	-> see: Nitroglycol																															
Glycolic acid	C ₂ H ₄ O ₃	000079-14-1	37 %	Xn		1/1	0/0	4/4	(2)	0/0	0/0	(3)	1/1	0/0	0/0	1/0	0/0	0/0	1/1	1/1	1/3	1/0	2/0	1/0	0/0	1/0	1/3	1/3	1/1			
Glycolic acid	C ₂ H ₄ O ₃	000079-14-1	70 %	C, Xn		1/1	1/1	4/4	(2)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(2)	1/0	3/0	(2)	0/0	(2)	1/3	1/3	1/1			
Glycocoll	-> see: Aminoacetic acid																															
Glycol chlorohydrin	-> see: Chloroethanol																															
Glysanтин	—	—		Xn		1/1	1/1	3/3	(2)	1/0	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/2	1/1	0/0	1/1	1/1	1/1	Antifreeze, basis glycol; BASF			
Glycerol triacetate	-> see: Triacetin																															
Firedamp	—	—		F+	X	0/0	0/0	1/0	(2)	(1)	0/0	(1)	(2)	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(1)	4/4	1/0	1/0	0/0	1/1	(1)	(1)	mainly methane			
Uric acid	C ₅ H ₄ N ₄ O ₃	000069-93-2		Xi		1/1	1/1	(2)	1/0	1/0	0/0	1/0	1/0	0/0	0/0	1/0	0/0	1/1	1/1	1/1	1/1	1/0	(1)	(1)	0/0	4/4	1/1	1/1	0/0			
Urea	CH ₄ N ₂ O	000057-13-6	aqueous	Xi		1/1	1/1	1/0	1/1	1/0	0/0	1/1	1/1	0/0	0/0	1/0	0/0	1/1	1/1	1/1	1/1	1/0	1/1	1/1	0/0	1/1	1/0	1/1	1/1	Urea, carbamide, etc.		
Urea	CH ₄ N ₂ O	000057-13-6		Xi		1/1	1/1	1/0	1/1	1/0	1/2	1/1	1/1	1/2	3/3	2/4	3/3	1/1	1/1	1/1	1/1	1/0	1/1	1/1	0/0	1/1	1/0	1/1	1/1	Urea, carbamide, etc.		
HD oil engine oil, aromatics-free	—	—		?		1/0	1/3	1/0	1/1	1/1	0/0	1/1	1/3	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(2)	4/4	(1)	3/3	0/0	1/1	1/1	1/1				
Yeast	—	—	any	—		1/1	1/1	1/0	(1)	1/0	0/0	1/1	1/1	0/0	0/0	1/0	1/0	1/1	1/1	1/1	1/0	1/0	1/1	0/0	1/1	1/1	(1)	(1)				
Heating oil	—	—		Xn		3/3	3/4	1/0	3/3	1/0	2/3	1/1	1/3	3/4	1/2	1/1	3/3	1/1	1/1	1/1	1/1	4/4	1/1	1/1	0/0	1/1	1/1	1/1	1/1			
Helium	He	007440-59-7		—		0/0	0/0	1/0	(1)	1/1	0/0	1/1	1/0	0/0	0/0	0/0	0/0	1/1	(1)	1/1	(1)	1/0	1/0	1/0	0/0	1/1	1/1	1/1				
Hendecanol	-> see: Undecyl alcohol																															
Henkel-P3-solution	—	—		?		1/1	1/1	(2)	(2)	(1)	0/0	(1)	1/1	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(1)	(2)	(2)	1/0	0/0	0/0	1/1	1/1	Cleaning agents			
Heptan, n-	C ₇ H ₁₆	000142-82-5		F, Xn	X	2/3	3/4	1/0	1/2	1/0	3/3	1/2	2/4	4/4	1/2	2/3	4/4	1/0	1/1	1/1	1/1	4/4	1/1	1/1	0/0	1/1	1/1	1/1	0/0			
Heptanol, 1-	C ₇ H ₁₆ O	000111-70-6		Xn		0/0	0/0	(2)	(2)	(1)	0/0	(1)	(2)	0/0	0/0	0/0	0/0	1/3	0/0	(1)	(1)	(1)	4/4	(1)	1/0	0/0	(1)	(1)				
Heptanon	C ₇ H ₁₄ O	—		(Xn)	X	0/0	0/0	(3)	(4)	(4)	(4)	(2)	(3)	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	(4)	(4)	4/4	0/0	(1)	(1)	(1)	Isomer not specified in the source			
Heptanon-4	-> see: Dipropylketone																															
Heptyl alcohol	-> see: Heptanol, 1-																															
Hexachlorobenzene (HCB)	C ₆ Cl ₆	000118-74-1		T		0/0	0/0	(3)	(4)	0/0	(4)	1/0	(3)	0/0	0/0	0/0	0/0	1/1	0/0	(1)	(2)	0/0	4/4	(3)	4/4	0/0	(1)	0/0	0/0			
Hexachlorobutadiene (HCBd)	C ₄ Cl ₆	000087-68-3		T		0/0	0/0	(3)	4/4	0/0	(4)	1/0	(3)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(2)	(3)	4/4	1/0	4/4	0/0	(3)	0/0	0/0			
Hexachlorocyclohexane (HCH)	C ₆ H ₆ Cl ₆	000319-84-6		T		0/0	0/0	(3)	(4)	0/0	0/0	(3)	(3)	0/0	0/0	0/0	0/0	0/0	(1)	(2)	0/0	4/4	1/0	4/4	0/0	(3)	0/0	0/0				
Hexadecanol	-> see: Cetyl alcohol																															
Hexadecanoic acid	-> see: Palmitic acid																															
Hexadecyl alcohol	-> see: Cetyl alcohol																															
Hexahydrobenzene	-> see: Cyclohexan																															
Hexahydrophenol	-> see: Cyclohexanol																															
Hexahydropyridine	-> see: Piperidine																															
Hexahydrotoluene	-> see: Methylcyclohexane																															
Hexaldehyde	-> see: Hexanal																															
Hexamethylenetetramine	C ₆ H ₁₂ N ₄	000100-97-0		F, Xn	X	0/0	0/0	(2)	(2)	1/0	0/0	(2)	(2)	1/1	0/0	0/0	0/0	1/1	0/0	(1)	(1)	(2)	(2)	(2)	(3)	0/0	(1)	1/1	1/1	0/0		
Hexamine	-> see: Hexamethylenetetramine																															
Hexane, n-	C ₆ H ₁₄	000110-54-3		F, Xn	X	2/3	4/4	1/0	(2)	1/0	3/4	1/1	2/3	4/4	1/2	2/4	4/4	1/1	1/1	1/1	1/1	4/4	1/1	1/1	0/0	1/1	1/1	1/1	0/0			
Hexanal	C ₆ H ₁₂ O	000066-25-1		F, Xi	X	0/0	0/0	0/0	(4)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	3/0	4/4	4/4	0/0	(1)	(1)				
Hexanedioic acid	-> see: Adipic acid																															
Hexanol, (1-)	C ₆ H ₁₄ O	000111-27-3		Xn		1/0	1/0	(2)	(2)	(1)	0/0	(1)	1/2	0/0	3/0	1/0	3/0	1/3	0/0	(1)	1/0	(1)	4/4	1/0	1/0	0/0	(1)	(1)	(1)	0/0		
Hexanone-2	-> see: Methyl butyl ketone																															
Hexanetriol	C ₆ H ₁₄ O ₃	—	100 %	?		1/1	1/1	(2)	(2)	(1)	0/0	(1)	1/1	1/0	0/0	1/1	3/3	1/1	0/0	(1)	1/1	(1)	1/0	1/0	1/0	0/0	(1)	(1)	(1)	0/0	Isomer not specified in the source	
Hexen, 1-	C ₆ H ₁₂	000592-41-6		F, Xn	X	0/0	0/0	1/0	(2)	(1)	(4)	(1)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	4/4	1/0	3/3	0/0	1/1	1/1	1/1			
Hexylaldehyde	-> see: Hexanal																															
Hexyl alcohol	-> see: Hexanol, (1-)																															
Hexylene	-> see: Hexen, 1-																															
Staghorn salt	-> see: Ammonium carbonate																															
Wood alcohol	-> see: Methanol																															
Wood oil	—	008001-20-5		—		0/0	0/0	(1)	(2)	1/0	0/0	(1)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	4/4	(1)	1/0	0/0	1/1	(1)	(1)			
Wood tar oil	-> see: Creosote																															

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	FLAMMABLE	Thermoplastics																Fluoroplastics				Elastomers				Metals				REMARK
						HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FKM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C				
Honey	—	—		—		1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	(1)	1/1	0/0	(1)	(1)	(1)	0/0		
Gibbsite	-> see: Aluminium hydroxide																																	
Hydraulic fluids, HFA	—	—	50°C	?		0	0	0	0	0	0	(3)	0	0	0	0	0	0	0	(1)	0	4	0	1	0	(2)	0	0						
Hydraulic fluids, HFB	—	—	50°C	?		0	0	0	0	0	0	(3)	0	0	0	0	0	0	0	(1)	0	4	0	1	0	(2)	0	0						
Hydraulic fluids, HFC	—	—	60°C	?		0	0	0	0	0	0	(3)	0	0	0	0	0	0	(1)	0	0	0	1	0	(2)	0	0							
Hydraulic fluids, HFD-R	—	—	100°C	?		0	0	0	0	0	0	(3)	0	0	0	0	0	0	0	0	0	0	4	0	(2)	0	0							
Hydraulic fluids, HFD-S	—	—	100°C	?		0	0	0	0	0	0	(3)	0	0	0	0	0	0	0	0	0	0	4	0	(2)	0	0							
Hydraulic oils (mineral oil based)	—	—	?			0/0	0/0	0/0	0/0	(1)	0/0	1/0	1/3	0/0	0/0	0/0	0/0	0/0	(1)	(1)	0/0	4/4	(1)	1/0	0/0	1/1	1/1							
Hydrazine	N ₂ H ₄	000302-01-2	10 %	T	X	1/1	1/0	4/4	(4)	0/0	0/0	2/0	1/1	0/0	0/0	1/0	0/0	0/0	1/0	1/0	1/3	1/0	3/4	4/4	0/0	1/0	1/3	1/3	1/3	1/1				
Hydrazine hydrate	N ₂ H ₆ O	010217-52-4	aqueous	(T, C)	(X)	1/1	1/0	4/4	(4)	0/0	0/0	2/0	1/1	0/0	0/0	1/0	0/0	0/0	1/0	1/0	1/3	1/0	3/4	4/4	0/0	1/0	1/3	1/3	0/0					
Hydrazinium hydroxide	-> see: Hydrazine hydrate																																	
Hydrazinobenzene	-> see: Phenylhydrazine																																	
Hydroquinone	C ₆ H ₆ O ₂	000123-31-9	saturated	Xn		0/0	1/3	4/4	(3)	1/0	0/0	(3)	1/0	4/4	0/0	1/0	0/0	1/3	0/0	(1)	1/1	(3)	4/4	4/4	4/4	0/0	(1)	1/0	1/0	0/0				
Hydrosulphite	-> see: Sodium dithionite																																	
Hydroxy-4-methyl-2-pentanone, 4-	-> see: Diacetone alcohol																																	
Hydroxybenzaldehyde, 2-	-> see: Salicylaldehyde																																	
Hydroxybenzoic acid, 2-	-> see: Salicylic acid																																	
Hydroxybenzene	-> see: Phenol																																	
Hydroxybenzenecarboxylic acid, 2-	-> see: Salicylic acid																																	
Hydroxyacetic acid	-> see: Glycolic acid																																	
Hydroxylamine sulphate	-> see: Hydroxylammonium sulphate																																	
Hydroxylammonium sulphate	H ₃ N ₂ SO ₆	010039-54-0	12 %	Xn		1/1	1/1	0/0	(2)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	1/0	1/0	1/3	0/0	(4)	1/1	1/1	1/1					
Hydroxylammonium sulphate	H ₃ N ₂ SO ₆	010039-54-0	any	Xn		1/1	0/0	0/0	(2)	0/0	0/0	(3)	1/1	0/0	0/0	1/0	0/0	0/0	(1)	(1)	(2)	1/0	1/0	1/3	0/0	(4)	1/1	1/1	1/1					
Hydroxymethoxybutane	-> see: Methoxybutanol																																	
Hydroxymethylfuran, 2-	-> see: Furfuryl alcohol																																	
Hydroxymethylfurfural, 5-	-> see: Oxymethylfurfural, 5-																																	
Hydroxymethyl tetrahydrofuran, 2-	-> see: Tetrahydrofurfuryl alcohol																																	
Hydroxypropane	-> see: Propanol																																	
Hydroxypropane, 2-	-> see: Isopropyl																																	
Hydroxypropionic acid, 2-	-> see: Lactic acid																																	
Hydroxypropionic acid ethyl ester, 2-	-> see: Ethyl lactate																																	
Hydroxytoluene	-> see: Cresol (-mixtures)																																	
Iminodiethanol	-> see: Diethanolamine																																	
Ginger	—	—	grinded	?		0/0	0/0	(2)	(2)	(2)	0/0	(1)	(2)	4/4	0/0	0/0	0/0	3/3	0/0	(1)	(1)	(1)	(2)	(1)	(2)	0/0	(1)	(1)	(1)					
Isoamyl alcohol	C ₅ H ₁₂ O	000123-51-3		Xn	X	0/0	0/0	(2)	3/0	1/0	0/0	1/0	1/1	1/3	0/0	0/0	0/0	1/3	0/0	(1)	1/1	1/1	3/0	2/4	3/3	0/0	(1)	(1)	(1)					
Isobutanol	C ₄ H ₁₀ O	000078-83-1		Xn	X	1/1	1/1	(2)	1/2	(2)	1/2	1/0	1/1	2/2	1/2	1/2	0/0	3/4	1/1	1/1	(1)	1/1	1/0	1/0	3/4	0/0	1/0	(1)	(1)	0/0				
Isobutyl acetate	C ₆ H ₁₂ O ₂	000110-19-0		F	X	0/0	0/0	(2)	(4)	0/0	(4)	1/0	(3)	4/4	0/0	3/0	4/4	0/0	0/0	(1)	1/0	(2)	2/0	4/4	4/4	0/0	(1)	(1)	(1)					
Isobutyl alcohol	-> see: Isobutanol																																	
Isobutyl ketone	-> see: Diisobutyl ketone																																	
Isobutyl methyl ketone	C ₆ H ₁₂ O	000108-10-1		F	X	1/2	2/3	1/0	4/4	(4)	3/3	(2)	2/4	4/4	4/4	4/4	4/4	4/4	2/3	1/1	1/1	(3)	4/4	4/4	4/4	0/0	(1)	(1)	(1)	0/0				
Isobutyltrimethylmethane	-> see: Iso-octane																																	
Iso-octane	C ₈ H ₁₈	000540-84-1	tech. pure	F, Xn	X	1/3	1/3	1/0	(2)	1/0	(4)	1/0	1/3	3/4	1/0	1/0	4/4	1/1	0/0	(1)	1/1	1/1	4/4	1/0	1/0	0/0	1/1	1/1	1/1	0/0				
Isooctanol	-> see: Ethylhexanol-1																																	
Isooctyl alcohol	-> see: Ethylhexanol-1																																	
Isopropyl	C ₃ H ₈ O	000067-63-0	tech. pure	F	X	1/1	1/1	1/0	1/2	1/0	1/2	1/0	1/1	2/2	1/2	1/2	4/4	1/4	1/1	1/1	1/1	1/1	1/0	1/1	3/3	0/0	(2)	(1)	(1)	0/0				
Isopropyl-4-methylbenzene, 1-	-> see: Cymene, p-																																	
Isopropyl-5-methylcyclohexanol, 2-	-> see: Menthol																																	
Isopropyl-5-methylphenol, 2-	-> see: Thymol																																	
Isopropyl acetate	C ₅ H ₁₀ O ₂	000108-21-4		F, Xi	X	1/2	2/3	1/0	4/4	(3)	2/3	1/0	2/3	4/4	4/4	4/4	4/4	0/0	1/2	1/1	1/1	(3)	3/0	4/4	4/4	0/0	(1)	(1)	(1)	0/0				
Isopropyl acetone	-> see: Isobutyl methyl ketone																																	
Isopropyl alcohol	-> see: Isopropyl																																	
Isopropylbenzene	-> see: Cumene																																	
Isopropylbenzol	-> see: Cumene																																	
Isopropyl chloride	C ₃ H ₇ Cl	000075-29-6		F, Xn	X	0/0	0/0	(2)	(4)	0/0	(4)	(2)	(3)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	1/0	4/4	0/0	(3)	0/0	0/0					
Isopropyl ether	C ₆ H ₁₄ O	000108-20-3	tech. pure	F	X	3/4	3/4	4/4	(4)	1/0	(4)	(1)	3/4	4/4	1/0	4/4	4/4	0/0	0/0	(1)	1/1	1/3	4/4	4/4	4/4	0/0	1/1	(1)	(1)	0/0				
Isopropylidene acetone	-> see: Mesityl oxide																																	

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	Thermoplastics										Fluoroplastics					Elastomers					Metals					REMARK		
					FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A		Hastelloy C	
Isopropyl methyl ketone	C ₃ H ₁₀ O	000563-80-4		T	X	0/0	0/0	(2)	4/4	(4)	(4)	(2)	(3)	4/4	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(3)	3/0	4/4	4/4	0/0	(1)	(1)	(1)			
Jasminaldehyde	-> see: α-pentylcinnamaldehyde																															
Iodine potassium	-> see: Potassium iodide																															
Iodoform	CHJ ₃	000075-47-8	100 %	Xn		3/0	3/0	(3)	3/0	0/0	0/0	(2)	3/0	3/0	0/0	4/4	4/4	0/0	0/0	(1)	1/0	(2)	1/0	1/0	(3)	0/0	(3)	(1) ¹⁾	(1) ¹⁾	1/1	¹⁾ Water-free! If even traces of hydrochloric acid (HCl) are split off by moisture, there is a risk of pitting, crevice and stress corrosion cracking.	
Iodine pentafluoride	JF ₅	007783-66-6		(T, C)		0/0	0/0	4/4	(4)	(4)	0/0	4/4	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(2)	(3)	4/4	4/4	4/4	4/4	0/0	(3)	0/0	0/0			
Tincture of iodine	I ₂	007553-56-2		Xn	(X)	1/3	1/3	4/4	3/4	0/0	1/1	1/1	1/2	3/3	0/0	4/4	4/4	3/3	1/1	0/0	1/1	1/1	2/0	1/1	3/3	0/0	1/0	2/0L	1/0L	1/1		
Cocoa	—	—	(—)	—		1/1	1/1	(2)	(1)	(2)	0/0	1/1	(2)	1/1	0/0	0/0	0/0	0/0	1/1	1/1	(1)	(1)	(2)	(1)	(2)	0/0	(1)	(1)	(1)			
Cocoa butter	—	008002-31-1	—	—		0/0	0/0	1/0	(1)	1/0	0/0	1/1	(2)	0/0	0/0	0/0	0/0	0/0	0/0	1/1	(1)	4/4	1/0	4/4	0/0	(1)	1/1	1/1				
Potash alum	-> see: Potassium aluminium sulphate																															
Potash lye	-> see: Potassium hydroxide																															
Potassium peroxodisulphate	-> see: Potassium persulphate																															
Potassium nitrate	-> see: Potassium nitrate																															
Potassium (hexa)cyanoferrate-(II)	-> see: Potassium hexacyanoferrate (II)																															
Potassium (hexa)cyanoferrate-(III)	-> see: Potassium hexacyanoferrate (III)																															
Potassium acetate	C ₂ H ₃ KO ₂	000127-08-2	aqueous	Xi		1/1	1/1	1/0	(1)	(2)	0/0	1/1	1/1	0/0	0/0	1/0	1/0	0/0	1/1	1/1	1/0	1/1	1/1	3/0	3/3	0/0	1/3	1/1	1/1	0/0		
Potassium aluminium sulphate	KAl(SO ₄) ₂ x 12H ₂ O	010043-67-1	diluted	Xi		1/1	1/1	1/0	1/0	(2)	0/0	3/4	1/1	1/1	1/0	1/3	1/3	1/1	1/1	1/1	1/1	1/1	1/1	3/0	3/3	0/0	1/0	1/1	1/1	1/1	1/1	
Potassium aluminium sulphate	KAl(SO ₄) ₂ x 12H ₂ O	010043-67-1	saturated	Xi		1/1	1/1	1/0	1/0	(2)	0/0	3/4	1/1	1/0	1/0	1/3	1/3	0/0	1/1	1/1	1/1	1/1	1/1	1/0	3/3	0/0	1/0	(1)	(1)	0/0		
Potassium bicarbonate	-> see: Potassium hydrogen carbonate																															
Potassium bichromate	-> see: Potassium dichromate																															
Potassium bisulphate	-> see: Potassium hydrogen sulphate																															
Potassium bitartrate	-> see: Potassium hydrogentartrate																															
Potassium borate	KBO ₂	012228-88-5	10 %	(Xn)		1/1	1/1	1/0	(2)	(2)	0/0	1/1	1/1	0/0	0/0	1/3	0/0	0/0	1/1	1/1	1/1	1/0	1/0	1/0	1/1	0/0	(3)	0/0	0/0	0/0		
Potassium borate	KBO ₂	012228-88-5	aqueous	(Xn)		1/1	1/1	1/0	(2)	(2)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/0	1/0	1/1	0/0	(3)	0/0	0/0	0/0		
Potassium bromate	KBrO ₃	007758-01-2	saturated	O, T		1/3	1/3	(2)	1/0	0/0	0/0	(2)	1/1	1/1	0/0	1/3	0/0	1/1	0/0	(1)	1/1	1/1	1/0	1/1	1/1	0/0	(2)	0/0	0/0	0/0		
Potassium bromate	KBrO ₃	007758-01-2	aqueous	O, T		0/0	0/0	(2)	(2)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/1	1/1	0/0	(2)	0/0	0/0	0/0	0/0		
Potassium bromide	KBr	007758-02-3	any	Xn		1/1	1/1	3/0	1/0	(1)	1/0	1/1	1/1	1/1	0/0	1/3	1/0	1/1	0/0	1/1	1/1	1/1	1/0	1/1	1/1	0/0	1/0	1/0L	1/0L	1/1		
Potassium carbonate	K ₂ CO ₃	000584-08-7	saturated	Xn		1/1	1/1	1/1	3/3	(2)	1/1	1/1	1/1	1/1	0/0	1/1	1/1	1/1	0/0	1/1	1/1	1/3	1/0	1/0	1/1	0/0	4/4	1/1	1/1	1/1	1/1	
Potassium carbonate	K ₂ CO ₃	000584-08-7	aqueous	Xn		1/1	1/1	1/0	(2)	(2)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/0	1/1	0/0	4/4	1/1	1/1	1/1	1/1		
Potassium chlorate	KClO ₃	003811-04-9	saturated	O, Xn		1/1	0/0	1/0	(2)	0/0	0/0	2/0	1/1	1/0	0/0	1/1	0/0	0/0	(1)	1/1	1/1	1/0	1/1	4/4	0/0	1/1	1/1	1/1	1/1	1/1		
Potassium chlorate	KClO ₃	003811-04-9	aqueous	O, Xn		1/1	0/0	1/0	(2)	0/0	0/0	2/0	1/1	1/0	0/0	1/1	0/0	0/0	(1)	1/1	1/1	1/0	1/1	4/4	0/0	1/1	1/1	1/1	1/1	1/1	1/1	
Potassium chloride	KCl	007447-40-7	aqueous	Xi		1/1	1/1	1/0	1/0	1/0	1/0	1/1	1/1	1/1	1/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	1/3	1/1L	1/1L	1/1	1/1		
Potassium chromate	K ₂ CrO ₄	007789-00-6	saturated	T		1/0	1/1	2/0	(2)	0/0	1/0	(2)	1/1	1/1	0/0	1/1	1/0	1/1	0/0	(1)	1/1	1/1	1/0	1/0	3/3	0/0	1/1	(1)	(1)	1/1		
Potassium chromate	K ₂ CrO ₄	007789-00-6	aqueous	T		0/0	0/0	(2)	(2)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/0	3/3	0/0	1/1	(1)	(1)	1/1	1/1		
Potassium cyanide	KCN	000151-50-8	saturated	T+		1/1	1/1	1/0	4/4	0/0	0/0	3/0	1/1	0/0	0/0	1/3	4/4	0/0	0/0	1/1	1/1	1/3	1/0	1/1	3/3	0/0	3/4	1/0	1/0	1/1		
Potassium cyanide	KCN	000151-50-8	aqueous	T+		1/1	1/1	1/0	4/4	0/0	0/0	3/0	1/1	0/0	0/0	1/3	1/4	0/0	0/0	1/1	1/1	1/3	1/0	1/1	3/3	0/0	3/4	1/0	1/0	1/1		
Potassium dichromate	K ₂ Cr ₂ O ₇	007778-50-9	saturated	T		1/1	1/0	4/4	3/0	3/0	1/0	3/0	1/1	1/3	0/0	1/3	1/0	1/3	0/0	(1)	1/1	1/1	1/0	2/0	3/3	0/0	1/1	1/1	1/1	1/1		
Potassium dichromate	K ₂ Cr ₂ O ₇	007778-50-9	aqueous	T		0/0	0/0	3/0	1/0	3/0	0/0	3/0	1/1	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	2/0	3/3	0/0	1/1	1/1	1/1	1/1	1/1		
Potassium iron (II) cyanide	-> see: Potassium hexacyanoferrate (III)																															
Potassium iron (III) cyanide	-> see: Potassium hexacyanoferrate (II)																															
Potassium fluoride	KF	007789-23-3		T		1/1	1/1	1/0	(2)	(2)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	(1)	(1)	1/0	(1)	0/0	1/1	1/1	1/1	1/1	0/0	
Potassium hydrogen carbonate	CHKO ₃	000298-14-6	saturated	—		1/1	1/1	1/0	(2)	(2)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/1	0/0	4/4	(1)	(1)	1/1	1/1		
Potassium hydrogen sulphate	KHSO ₄	007646-93-7	aqueous	(C)		1/1	1/1	4/4	1/0	(2)	0/0	2/0	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/0	1/1	0/0	1/0	4/4	4/4	1/1		
Potassium hydrogen sulphate	KHSO ₄	007646-93-7		C		1/1	1/1	4/4	1/0	0/0	0/0	2/0	1/1	1/1	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/0	1/1	0/0	1/0	4/4	4/4	?			
Potassium hydrogentartrate	C ₄ H ₄ KO ₆	000868-14-4	saturated	Xi		1/1	1/1	(2)	(2)	0/0	0/0	(2)	1/1	0/0	0/0	1/0	1/0	0/0	1/1	1/1	1/1	1/1	(2)	(1)	(1)	0/0	(4)	1/3	1/2	0/0		
Potassium hydroxide	KHO	001310-58-3	10 %	C+		1/1	1/1	1/0	4/4	4/4	0/0	1/1	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1												

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	Thermoplastics										Fluoroplastics					Elastomers					Metals					Hastelloy C	REMARK
					FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMMA	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A		
Potassium iodide	KJ	007681-11-0	aqueous	(Xn)		1/1	1/1	1/0	(2)	(2)	0/0	1/1	1/1	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/1	1/3	0/0	1/1	1/1L	1/1L	1/1		
Potassium nitrate	KNO ₃	007757-79-1	50 %	O, Xn		1/1	1/1	1/0	1/0	(1)	1/0	1/1	1/1	1/1	1/0	1/1	1/0	1/1	1/1	1/1	1/0	1/1	1/1	0/0	1/1	1/1	1/1	1/1	1/1		
Potassium nitrate	KNO ₃	007757-79-1	aqueous	O, Xn		1/1	1/1	1/0	1/0	(1)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/1	1/1	0/0	1/1	1/1	1/1	1/1	1/1		
Potassium perchlorate	KClO ₄	007778-74-7	saturated	O, Xn		1/1	1/1	(1)	1/0	(1)	1/0	1/1	1/1	0/0	0/0	1/3	3/0	0/0	1/1	1/1	1/1	1/0	1/1	1/3	0/0	1/1	1/1	1/1	1/1		
Potassium perchlorate	KClO ₄	007778-74-7	aqueous	O, Xn		1/1	1/1	(1)	1/0	(1)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/1	4/4	0/0	1/1	1/1	1/1	1/1		
Potassium permanganate	KMnO ₄	007722-64-7	aqueous	O, Xn		0/0	0/0	4/4	1/0	(2)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/0	1/1	4/4	0/0	1/1	1/1	1/1	1/1	1/1	hypermanganic potash	
Potassium permanganate	KMnO ₄	007722-64-7		O, Xn		1/3	1/1	4/4	1/0	(2)	1/1	1/1	1/1	1/3	0/0	1/3	0/0	1/3	1/1	1/1	1/1	1/0	1/1	4/4	0/0	1/1	1/1	1/1	1/1	hypermanganic potash	
Potassium persulphate	K ₂ (SO ₄) ₂	007727-21-1	any	O, Xn		1/1	1/1	4/4	1/0	0/0	1/0	(3)	1/1	1/0	0/0	1/3	1/0	1/1	0/0	(1)	1/1	1/1	1/0	1/1	4/4	0/0	4/4	1/0	1/0	1/1	
Potassium sulphate	K ₂ SO ₄	007778-80-5	aqueous	Xn		1/1	1/1	1/0	(1)	(1)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/1	1/1	1/1		
Potassium sulphide	K ₂ S	001312-73-8	diluted	(C)		1/1	1/1	1/0	(2)	(2)	1/0	(2)	1/1	1/1	0/0	1/0	1/0	1/1	0/0	(1)	1/1	1/1	(1)	(1)	2/0	0/0	3/4	1/1	1/1	0/0	
Potassium sulphite	K ₂ SO ₃	010117-38-1	saturated	(Xi)		1/1	1/1	(1)	(2)	(2)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/0	1/0	0/0	1/0	1/0	1/0	0/0		
Potassium thiosulphate	K ₂ S ₂ O ₃	010233-00-8	saturated	Xi		1/1	1/1	(1)	(2)	(1)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	(1)	(1)	(1)	3/3	0/0	(1)	(1)	(1)		
Lime, burnt	-> see: Calcium oxide																														
Hydrated lime	-> see: Calcium hydroxide																														
Lime nitrate	-> see: Calcium nitrate																														
Lime water	-> see: Calcium hydroxide																														
Cardamom	—	—		?		0/0	0/0	(2)	(2)	(2)	0/0	(2)	(2)	4/4	0/0	0/0	0/0	0/0	1/1	0/0	(1)	(1)	(1)	(2)	(1)	(2)	0/0	(1)	(1)	(1)	
Rubber (caoutchouc) dispersion	—	—		?		0/0	0/0	1/0	(2)	(2)	0/0	2/3	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	(3)	(1)	(2)	0/0	(3)	(1)	(1)		Latex
Kerosene	—	008008-20-6		(Xn)		2/2	3/4	(1)	4/4	1/1	2/3	1/1	3/3	4/4	2/3	1/1	0/0	0/0	2/3	1/1	1/1	1/1	4/4	1/0	1/0	0/0	1/1	1/1	1/1	0/0	Lamp oil, light petroleum
Pine needle oil	—	008023-99-2		?		0/0	0/0	1/0	(3)	0/0	(4)	(2)	1/1	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(3)	4/4	1/0	1/0	0/0	1/1	(1)	(1)	0/0	Pinus sylvestris
Silicofluoric acid	H ₂ SiF ₆	016961-83-4	32 %	C		1/1	1/1	4/4	1/0	4/4	0/0	4/4	1/1	0/0	0/0	1/1	0/0	0/0	1/1	1/1	1/1	1/1	3/0	2/2	3/4	0/0	4/4	(2)	1/1	1/1	
Silicic acid	SiO ₂	001343-98-2	any	—		1/1	1/1	(1)	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	(1)	1/1	1/1	1/1		
Silicic acid tetraethylester	-> see: Tetraethylorthosilicate																														
Bone oil	—	008001-85-2		—		0/0	0/0	(1)	(2)	1/0	0/0	(2)	1/1	1/1	0/0	0/0	0/0	1/1	0/0	(1)	1/1	(1)	4/4	1/0	1/0	0/0	(1)	1/1	1/1		
Common salt	-> see: Sodium chloride																														
Carbon (substance) disulphide	-> see: Carbon disulphide																														
Carbon dioxide	CO ₂	000124-38-9	saturated	?		1/3	1/1	1/0	1/0	1/1	1/0	1/1	1/1	1/0	1/0	1/3	1/0	0/0	0/0	(1)	1/1	1/1	1/0	1/1	1/1	0/0	3/3	1/1	1/1	1/1	
Carbon dioxide, moist	CO ₂	000124-38-9	tech. pure	?		1/1	1/1	1/0	(1)	1/1	0/0	1/1	1/1	0/0	0/0	1/3	0/0	1/1	0/0	(1)	1/1	1/1	2/0	1/1	1/1	0/0	3/3	1/1	1/1	1/1	
Carbon dioxide, dry	CO ₂	000124-38-9	tech. pure	?		1/1	1/1	1/0	(1)	1/1	0/0	1/1	1/1	0/0	0/0	1/1	0/0	1/1	0/0	(1)	1/1	1/1	2/0	1/1	1/1	0/0	3/3	1/1	1/1	1/1	
Carbonic acid	-> see: Carbon dioxide																														
Carbonic acid dichloride	-> see: Phosgene																														
Carbon tetrabromide	-> see: Carbon tetrabromide																														
Carbon tetrachloride	-> see: Carbon tetrachloride																														
Coconut fat	—	—		—		0/0	0/0	1/0	(2)	1/0	0/0	(2)	(2)	1/1	0/0	0/0	0/0	1/1	0/0	(1)	1/1	1/1	4/4	1/1	1/0	0/0	(1)	1/1	1/1		
Coconut oil alcohol	—	068425-37-6	tech. pure	(Xi)		1/0	0/0	(1)	(2)	1/0	0/0	(2)	1/3	0/0	0/0	1/3	0/0	0/0	0/0	(1)	1/1	1/1	3/0	1/1	1/1	0/0	(1)	1/1	1/1		
Coconut oil	—	008001-31-8	tech. pure	—		1/3	1/3	1/0	(2)	1/0	0/0	(2)	1/1	0/0	0/0	1/3	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/1	1/1	0/0	(1)	1/1	1/1		
Aqua regia	HNO ₃ + HCl	008007-56-5		C		4/4	4/4	4/4	4/4	4/4	3/3	4/4	4/4	4/4	4/4	4/4	4/4	3/4	1/1	(2)	1/1	3/0	4/4	4/4	4/4	0/0	4/4	4/4	4/4	4/4	Aqua regia = Nitric acid + hydrochloric acid
Fuel + 20% ethanol	—	—		F, T	X	0/0	0/0	(1)	4/4	0/0	(4)	2/2	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	3/0	3/0	0/0	(1)	1/1	1/1		
Fuel + 20% methanol	—	—		F, T	X	0/0	0/0	(1)	4/4	0/0	(4)	2/2	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	(3)	4/4	0/0	(1)	1/1	1/1		
Fuel, Normal	—	—		F, T	X	0/0	0/0	1/0	3/0	1/1	(4)	2/2	3/4	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	1/0	3/0	0/0	1/1	1/1	1/1		
Fuel, Super	—	—		F, T	X	0/0	0/0	1/0	4/4	(2)	(4)	2/2	3/4	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	1/0	3/0	0/0	1/1	1/1	1/1		
Chalk	CaCO ₃	—		—		1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	Calcium carbonate	
Creosote	—	—		(T)		1/1	1/1	3/0	(3)	0/0	0/0	(3)	3/4	0/0	1/0	3/0	4/4	0/0	0/0	(1)	1/1	(3)	4/4	(3)	1/0	0/0	(2)	1/1	1/1	0/0	
Cresol (-mixtures)	C ₇ H ₈ O	001319-77-3		T, C		3/4	4/4	4/4	4/4	4/4	4/4	4/4	2/3	4/4	4/4	4/4	4/4	3/4	1/2	1/1	1/1	1/1	4/4	1/0	4/4	0/0	1/1	1/0	1/0	1/1	
Carum	—	—	grinded	?		0/0	0/0	(2)	(2)	(1)	0/0	1/1	(2)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	(1)	(2)	0/0	4/4	(1)	(1)			
Kupfer-(I)-chlorid	CuCl	007758-89-6	aqueous	Xn		0/0	0/0	(3)	(2)	(2)	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/1	1/0	0/0	4/4	4/4	4/4	1/1	
Kup																															

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	Thermoplastics										Fluoroplastics				Elastomers				Metals				Hastelloy C	REMARK			
					FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI			AL	V2A	V4A
Nitrous oxide	N ₂ O	010024-97-2		(O)		0/0	0/0	(2)	(2)	(1)	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	2/0	1/0	1/0	0/0	1/1	(1)	(1)		Nitrous oxide, "nitrogen oxydul"
Lactam	—	—		?		0/0	0/0	0/0	0/0	0/0	0/0	(2)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	0/0	4/4	4/4	4/4	0/0	(2)	(1)	(1)		cyclic carboxylic acid amides
Lactobiosis	-> see: Lactose																														
Lactose	C ₁₂ H ₂₂ O ₁₁	000063-42-3	aqueous	—		1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	(1)	1/1	1/1	0/0		
Lanolin	—	008006-54-0	tech. pure	—		3/3	3/3	1/0	1/0	1/0	0/0	(2)	3/3	1/1	0/0	3/3	3/3	1/1	0/0	(1)	1/1	1/1	4/4	1/1	1/1	0/0	(1)	1/1	1/1	1/1	
Latex	—	—		?		0/0	0/0	1/0	(2)	(2)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(1)	(3)	(1)	(2)	0/0	(2)	(1)	(1)	1/1	Rubber dispersion	
Lauryl alcohol	C ₁₂ H ₂₆ O	000112-53-8	100 %	Xi		0/0	0/0	(2)	(2)	1/0	0/0	(2)	1/1	1/1	0/0	1/1	0/0	1/1	0/0	(1)	1/1	1/1	3/0	1/0	3/3	0/0	(1)	(1)	(1)	0/0	
Lauryl chloride	C ₁₂ H ₂₅ Cl	000112-52-7	100 %	(Xi)		0/0	0/0	(2)	(3)	0/0	0/0	(2)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/0	(1)	4/4	(1)	(3)	0/0	(3)	0/0	0/0		
Lavender oil	—	008000-28-0		(Xi)		0/0	0/0	(2)	(3)	0/0	(4)	(2)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	1/0	3/0	0/0	(1)	(1)	(1)		
Cod liver oil	—	008001-69-2		—		1/3	1/3	(2)	1/0	(2)	0/0	(2)	1/3	1/1	0/0	1/0	0/0	1/1	0/0	(1)	1/1	1/1	3/0	1/0	1/0	0/0	1/0	(1)	(1)	1/1	
Glue (bone glue)	—	—	any	—		1/0	1/1	(1)	1/1	1/0	(2)	1/1	0/0	0/0	1/3	0/0	0/0	0/0	(1)	1/1	(1)	(1)	1/0	1/0	0/0	(3)	1/1	1/1	0/0		
Linseed oil	—	008001-26-1	tech. pure	—		1/1	1/3	1/0	1/0	1/0	1/0	1/1	1/1	1/1	0/0	1/3	1/0	1/1	0/0	(1)	1/1	1/1	4/4	1/1	1/1	0/0	(1)	1/1	1/1	1/1	
Lemongrass oil	—	008007-02-1		(Xi)		0/0	0/0	(2)	(3)	0/0	(4)	(2)	(3)	4/4	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(3)	4/4	(3)	(4)	0/0	(1)	(1)	(1)		
Luminous gas, benzene-free	—	—		F+, T	X	1/0	1/0	1/0	1/0	(2)	1/0	(2)	1/0	1/0	0/0	1/0	1/0	0/0	0/0	(1)	1/0	1/0	4/4	1/0	3/0	0/0	1/1	1/1	1/1	0/0	
Ligroin	—	008032-32-4		F, Xn	X	0/0	0/0	(2)	1/0	(2)	(4)	(2)	(3)	3/3	0/0	0/0	0/0	1/1	0/0	(1)	1/1	1/1	4/4	1/0	1/0	0/0	1/1	1/1	1/1		Light petrol
Liqueurs	—	—		—		1/0	0/0	(2)	1/0	1/0	0/0	(2)	1/0	0/0	0/0	1/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/0	1/1	0/0	(1)	1/1	1/1	1/1	
Limonene, DL-	C ₁₀ H ₁₆	000138-86-3		Xn	X	0/0	0/0	(1)	(3)	(2)	(4)	(1)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	4/4	1/0	3/3	0/0	1/1	1/1	1/1		
Lindane	-> see: Hexachlorocyclohexane																														
Lithium bromide	LiBr	007550-35-8		Xn		1/1	1/1	(3)	(2)	1/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(1)	1/0	1/0	1/0	0/0	(3)	0/0	0/0		
Laurel	—	—	grinded	?		0/0	0/0	(2)	(2)	(2)	0/0	(2)	(2)	1/1	0/0	0/0	1/1	0/0	(1)	(1)	(2)	(1)	(2)	0/0	(1)	(1)	(1)				
Lysol	—	—		T		0/0	0/0	(4)	(3)	0/0	0/0	(3)	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	(3)	(3)	(3)	0/0	(3)	1/1	1/1		Disinfectant, cresol + soap
Magnesite	-> see: Magnesium carbonate																														
Magnesium bromide	MgBr ₂	007789-48-2		Xi		1/1	1/1	(2)	(2)	(1)	0/0	1/1	1/1	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/1	(1)	(2)	0/0	(3)	0/0	0/0	
Magnesium carbonate	MgCO ₃	000546-93-0	saturated	—		1/1	1/1	1/0	1/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	
Magnesium chloride	MgCl ₂	007786-30-3	aqueous	Xi		1/1	1/1	1/0	1/0	1/0	1/0	1/2	1/1	1/1	1/0	1/1	1/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/0L	1/0L	1/1	
Magnesium chlorite	Mg(ClO ₂) ₂	??		O		0/0	0/0	0/0	0/0	0/0	0/0	1/1	0/0	0/0	0/0	0/0	0/0	1/1	0/0	0/0	1/1	0/0	0/0	0/0	0/0	1/1	0/0	0/0	0/0		
Magnesium hydroxide	Mg(HO) ₂	001309-42-8	saturated	—		1/1	1/1	1/0	(2)	1/1	1/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	2/0	1/1	1/1	1/1	1/1	1/1	0/0	
Magnesium iodide	MgI ₂	010377-58-9		(Xn)		1/1	1/1	(2)	(2)	(2)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	(1)	1/1	(1)	(1)	(2)	0/0	(2)	0/0	0/0		
Magnesium nitrate	Mg(NO ₃) ₂	010377-60-3	saturated	O, Xi		1/1	1/1	1/0	(2)	(1)	1/0	1/1	1/1	1/0	0/0	1/1	1/0	0/0	1/1	1/1	1/1	1/1	1/1	(1)	(2)	0/0	1/0	1/0	1/0	1/1	
Magnesium sulphate	MgSO ₄	007487-88-9	any	—		1/1	1/1	1/0	1/0	1/0	1/0	1/0	1/1	1/1	1/0	1/1	1/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	2/0	0/0	1/1	1/1	1/1	1/1	
Magnesium sulphate heptahydrate	-> see: Epsom salt																														
Maize germ oil	—	008001-30-7	tech. pure	—		1/3	0/0	(2)	(1)	1/0	0/0	(2)	1/3	1/1	0/0	3/0	0/0	1/1	0/0	(1)	1/1	1/1	4/4	1/1	1/0	0/0	(1)	1/1	1/1	1/1	Maize oil
Maleic acid	C ₄ H ₄ O ₄	000110-16-7	saturated	Xn		1/1	1/1	4/4	(3)	0/0	0/0	(3)	1/1	0/0	0/0	1/3	1/0	0/0	1/1	1/1	1/1	1/1	4/4	1/1	4/4	0/0	1/1	1/1	1/1	1/1	
Maleic acid	C ₄ H ₄ O ₄	000110-16-7	aqueous	Xn		1/1	1/1	4/4	(3)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	4/4	1/1	1/0	0/0	1/1	1/1	1/1	1/1	
Malonic ester	-> see: Diethylmalonate																														
Malonic acid diethyl ester	-> see: Diethylmalonate																														
Almond oil	—	008007-69-0		—		0/0	0/0	(2)	(1)	1/0	0/0	(2)	(2)	3/4	0/0	0/0	0/0	1/1	0/0	(1)	1/1	1/1	4/4	(1)	(2)	0/0	(1)	1/1	1/1		
Margarine	—	—		—		0/0	0/0	(2)	1/0	1/0	0/0	(2)	1/1	1/0	0/0	0/0	0/0	1/1	0/0	(1)	1/1	1/1	4/4	1/0	1/0	0/0	(1)	1/1	1/1		
Marmalade	—	—		—		1/1	1/1	(1)	1/1	1/1	0/0	(2)	1/1	1/1	0/0	1/3	0/0	1/1	1/1	1/1	1/1	1/1	(2)	(1)	(1)	0/0	(2)	1/1	1/1	1/1	1/1
Machine oil	—	—	100 %	?		0/0	1/4	(1)	(2)	1/0	0/0	1/1	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	1/0	0/0	1/1	1/1	1/1		
Matrium metabisulphite	-> see: Sodium disulphite																														
Matrium pyrochromate	-> see: Sodium dichromate																														
Marine water	-> see: Salt water, seawater																														
Molasses	—	—		—		1/1	1/1	1/0	(1)	1/0	0/0	2/0	1/1	0/0	0/0	1/3	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/0	1/1	0/0	1/0	1/0	1/0	3/4	
Molasses seasoning	—	—		?		1/1	1/1	1/0	(2)	(2)	0/0	(2)	1/1	0/0	0/0	1/1	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/0	1/1	0/0	(2)	(1)	(1)		
Menthadiene-1,8, p-	-> see: Limonene, DL-						</																								

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	FLAMMABLE	Thermoplastics																Fluoroplastics				Elastomers				Metals				REMARK
						HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FKM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C				
Methanol	CH ₃ O	000067-56-1		F, T	X	1/1	1/1	2/0	4/4	1/0	1/1	1/1	1/1	3/4	3/3	1/3	3/3	3/4	1/1	1/1	1/1	1/1	1/0	3/4	3/3	0/0	1/0	1/1	1/1	0/0				
Methanoic acid	-> see: Formic acid																																	
Methenamine	-> see: Hexamethylenetetramine																																	
Methoxybenzene	-> see: Anisole																																	
Methoxybutanol	C ₅ H ₁₂ O ₂	—	100 %	?	X	0/0	1/3	(2)	(3)	0/0	0/0	(2)	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(2)	3/0	1/0	/0	0/0	(1)	(1)	(1)		Isomer not specified in the source			
Methoxyethanol	-> see: Methyl glycol																																	
Methoxyethyl acetate	-> see: Methyl glycol acetate																																	
Methoxyethyl oleate	C ₂₁ H ₄₀ O ₃	000111-10-4		?		1/1	1/2	(2)	3/4	(2)	1/2	(2)	1/2	4/4	4/4	4/4	0/0	0/0	1/1	1/1	(1)	(1)	4/4	(2)	4/4	0/0	(1)	(1)	(1)		Plasticiser			
Methoxypropanol	-> see: Propylene glycol methyl ether																																	
Methyl ethyl ether	C ₃ H ₈ O	000540-67-0	100 %	(F+)	X	0/0	3/0	(1)	(4)	0/0	(4)	(2)	(3)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	1/0	(2)	4/4	4/4	4/4	0/0	1/1	(1)	(1)					
Methyl 2-hydroxybenzoate	-> see: Methyl salicylate																																	
Methyl 2-methyl propionate	-> see: Methyl methacrylate																																	
Methyl acetate	-> see: Acetic acid methyl ester																																	
Methacrolein	-> see: Crotonaldehyde																																	
Methyl acrylate	C ₄ H ₆ O ₂	000096-33-3		F, Xn	X	0/0	0/0	(2)	4/4	(4)	(4)	(2)	(2)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(3)	4/4	4/4	4/4	0/0	(1)	(1)	(1)					
Methylacrylic acid	-> see: Methacrylic acid																																	
Methyl alcohol	-> see: Methanol																																	
Methylamine, (Mono-)	CH ₃ N	000074-89-5	32 %	F+, C	X	1/0	1/0	4/4	4/4	0/0	0/0	1/0	1/0	0/0	0/0	3/0	4/4	0/0	0/0	(1)	1/0	3/0	1/0	4/4	4/4	0/0	1/0	1/0	1/0	0/0				
Methylbenzene	C ₇ H ₈	000108-88-3		F, Xn	X	3/4	3/4	1/0	4/4	1/0	3/3	1/3	3/4	4/4	4/4	4/4	4/4	1/1	1/1	1/0	1/1	4/4	3/3	4/4	0/0	1/1	1/1	1/1	1/1					
Methyl bromide	-> see: Bromomethane																																	
Methylbutanol	C ₅ H ₁₂ O	—		Xn	X	0/0	0/0	(2)	(2)	1/0	0/0	1/0	1/1	0/0	0/0	0/0	0/0	1/3	0/0	(1)	1/1	1/1	3/0	2/2	3/3	0/0	(1)	(1)	(1)		Isomer not specified in the source			
Methylbutanol, 3-	-> see: Isoamyl alcohol																																	
Methylbutanone-2, 3-	-> see: Isopropyl methyl ketone																																	
Methyl butyl alcohol	-> see: Methylbutanol																																	
Methyl butyl ketone	C ₆ H ₁₂ O	000591-78-6		F, T	X	0/0	0/0	(2)	(4)	(4)	(4)	(2)	(3)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(3)	1/0	4/4	4/4	0/0	(1)	(1)	(1)					
Methyl cellosolve	-> see: Methyl glycol																																	
Methyl chloroacetate	C ₃ H ₅ ClO ₂	000096-34-4	tech. pure	T/Xi	X	1/1	0/0	(3)	4/4	(4)	(4)	(3)	1/1	4/4	0/0	3/0	0/0	0/0	0/0	(1)	(1)	1/4	3/0	4/4	4/4	0/0	3/4	0/0	0/0	0/0				
Methyl chloride	-> see: Chloromethane																																	
Methyl chloroform	-> see: Trichloroethane-1,1,1																																	
Methyl cyanide	-> see: Acetonitrile																																	
Methylcyclohexane	C ₇ H ₁₄	000108-87-2		F, Xn	X	3/0	3/0	(2)	(2)	1/0	(4)	(2)	3/0	0/0	0/0	0/0	0/0	1/1	0/0	(1)	1/0	(1)	4/4	(1)	4/4	0/0	1/1	1/1	1/1	0/0				
Methylcyclopentane	C ₆ H ₁₂	000096-37-7		F	X	0/0	0/0	(2)	(2)	1/0	(4)	(2)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	4/4	1/0	4/4	0/0	1/1	1/1	1/1					
Methyl dichloroacetate	C ₃ H ₄ Cl ₂ O ₂	000116-54-1		(Xn)		1/1	0/0	(3)	(4)		(4)	(3)	1/1	0/0	0/0	4/4	0/0	0/0	0/0	(1)	1/1	3/3	4/4	4/4	4/4	0/0	(3)	0/0	0/0					
Methylene(di)chloride	-> see: Dichloromethane																																	
Methylene chlorobromide	-> see: Bromochloromethane																																	
Methyl ether	-> see: Dimethyl ether																																	
Methyl ethyl ketone (MEK)	C ₄ H ₈ O	000078-93-3		F	X	1/3	3/4	1/0	4/4	4/4	4/4	1/2	1/3	4/4	4/4	4/4	4/4	4/4	2/3	1/1	1/1	3/4	3/0	4/4	4/4	0/0	(1)	(1)	(1)	0/0				
Methyl formate	C ₂ H ₄ O ₂	000107-31-3		F+	X	0/0	0/0	(2)	4/4	0/0	(4)	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(3)	2/0	4/4	4/4	0/0	(1)	(1)	(1)	0/0				
Methyl glycol	C ₃ H ₈ O ₂	000109-86-4	100 %	T	X	1/0	1/1	1/0	3/4	0/0	1/1	1/0	1/1	4/4	3/3	3/4	4/4	0/0	1/1	1/1	1/1	1/1	3/0	4/4	4/4	0/0	(1)	(1)	(1)	0/0				
Methyl glycol acetate	C ₅ H ₁₀ O ₃	000110-49-6		T		0/0	0/0	1/0	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	3/0	4/4	4/4	0/0	(1)	(1)	(1)					
Methyl isobutenyl ketone	-> see: Mesityl oxide																																	
Methyl isobutyl ketone(MIBK)	-> see: Isobutyl methyl ketone																																	
Methyl isopropyl ketone	-> see: Isopropyl methyl ketone																																	
Methyl methacrylate	C ₅ H ₈ O ₂	000080-62-6	100 %	F, Xi	X	0/0	0/0	(2)	4/4	(4)	(4)	(2)	(2)	4/4	0/0	4/4	4/4	0/0	0/0	1/0	1/1	(3)	4/4	4/4	4/4	0/0	1/1	(1)	(1)	0/0				
Methyl methanoate	-> see: Methyl formate																																	
Methyl oleate	C ₁₉ H ₃₆ O ₂	000112-62-9		—		0/0	0/0	(2)	(3)	(2)	(4)	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	3/0	1/0	4/4	0/0	(1)	(1)	(1)					
Methyl oxirane	-> see: Propylene oxide																																	
Methylpent-4-en-2-one, 5-	-> see: Mesityl oxide																																	
Methylpentan-2-one, 4-	-> see: Isobutyl methyl ketone																																	
Methylphenol	-> see: Cresol (-mixtures)																																	
Methylphenyl ether	-> see: Anisole																																	
Methylphenyl ketone	-> see: Acetophenone																																	
Methylpropanol-1, 2-	-> see: Isobutanol																																	
Methylpropanol-2, 2-	-> see: Butyl alcohol, tertiary																																	

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	FLAMMABLE	Thermoplastics														Fluoroplastics				Elastomers				Metals				Hastelloy C	REMARK
						HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A				
Methyl propenoate	-> see: Methyl acrylate																																
Methylpropenoic acid, 2-	-> see: Methacrylic acid																																
Methyl propyl ketone	C ₈ H ₁₀ O	000107-87-9		(F)	X	1/2	2/3	(2)	4/4	(4)	3/3	(2)	2/3	4/4	4/4	4/4	0/0	4/4	1/2	1/1	(1)	(2)	(3)	4/4	4/4	0/0	(1)	(1)	(1)				
Methyl salicylate	C ₈ H ₈ O ₃	000119-36-8		Xn, Xi		0/0	0/0	(3)	(3)	0/0	0/0	(3)	1/0	4/4	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(3)	2/0	(3)	4/4	0/0	(2)	(1)	(1)	0/0	Synthetic Wintergreen Oil/Gaultheria Oil		
Methyl sulphuric acid	CH ₃ SO ₄	000077-78-1	50 %	(C)		0/0	1/1	4/4	(4)	(4)	0/0	4/4	2/4	0/0	0/0	1/3	0/0	0/0	0/0	(1)	1/1	(2)	1/0	4/4	4/4	0/0	(4)	0/0	0/0	4/4			
Methyl sulphuric acid	CH ₃ SO ₄	000077-78-1	aqueous	(C)		0/0	0/0	4/4	(4)	(4)	0/0	4/4	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(2)	1/0	4/4	4/4	0/0	(4)	0/0	0/0	4/4			
Milk	—	—		—		1/1	1/1	1/0	1/0	1/1	1/0	1/1	1/1	1/1	1/0	1/1	1/1	1/1	1/1	1/1	1/1	3/0	1/0	1/0	0/0	(1)	1/1	1/1	1/1				
Lactic acid	C ₃ H ₆ O ₃	000050-21-5	3 %	?		1/1	1/2	(3)	1/2	1/0	1/2	2/4	1/2	2/2	1/1	2/3	0/0	1/1	1/1	1/1	1/1	3/4	1/1	(2)	0/0	(1)	1/1	1/1	1/1	Lactol			
Lactic acid	C ₃ H ₆ O ₃	000050-21-5	80 %	C		1/1	1/1	3/4	1/2	0/0	1/2	3/4	1/1	1/1	1/1	2/3	2/3	1/1	1/2	1/1	1/1	1/3	3/4	1/1	1/4	0/0	1/0	1/3	1/2	1/1	Lactol		
Lactic acid	C ₃ H ₆ O ₃	000050-21-5	85 %	C		1/1	1/1	3/4	1/2	0/0	1/2	3/4	1/2	2/2	1/1	2/3	2/3	1/1	1/2	1/1	1/1	1/3	3/4	1/1	1/4	0/0	1/0	1/3	1/2	1/1	Lactol		
Lactic acid ethyl ester	-> see: Ethyl lactate																																
Milk sugar	-> see: Lactose																																
Mineral oil	—	008012-95-1		(Xn)		1/1	2/4	(1)	1/2	1/1	1/2	1/1	1/3	1/1	1/1	1/2	0/0	0/0	1/1	1/1	1/1	1/1	4/4	1/1	2/2	0/0	1/1	1/1	1/1	0/0			
Mineral water	—	—		—		1/1	1/1	(1)	1/0	1/1	0/0	1/1	1/1	0/0	0/0	1/1	0/0	0/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	(1)	(1)	(1)	1/1			
Mohr's salt	-> see: Ammonium iron (II) sulphate																																
Whey	—	—		—		1/1	0/0	(2)	(1)	(1)	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	(1)	(3)	(1)	(2)	0/0	(2)	1/1	1/1				
Monobromobenzene	-> see: Bromobenzene																																
Monochlorobenzene	-> see: Chlorobenzene																																
Monochloroacetic acid	-> see: Chloroacetic acid																																
Monochloroacetic acid ethyl ester	-> see: Ethyl chloroacetate																																
Monochloroacetic acid methyl ester	-> see: Methyl chloroacetate																																
Monoethanolamine	-> see: Ethanolamine																																
Monofluorodichloromethane	-> see: Dichlorofluoromethane																																
Monopotassium tartrate	-> see: Potassium hydrogentartrate																																
Monopentyl phthalate	-> see: Phthalic acid monoamyl ester																																
Morpholine	C ₄ H ₉ NO	000110-91-8	tech. pure	C, Xn	X	1/1	1/1	(3)	(3)	0/0	0/0	(2)	1/1	0/0	0/0	4/4	4/4	0/0	0/0	(1)	1/1	1/3	3/0	2/3	4/4	0/0	1/0	(1)	(1)	0/0			
Engine oil	—	—		?		0/0	0/0	1/0	(2)	(1)	0/0	1/1	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	1/1	4/4	1/0	1/0	0/0	1/1	1/1	1/1				
Mowilith D	—	—		?		1/0	0/0	(2)	0/0	(2)	0/0	(2)	1/0	0/0	0/0	1/0	0/0	0/0	0/0	(1)	1/1	1/0	(2)	(2)	(2)	0/0	(2)	(1)	(1)	0/0	Polyvinylacetatdispersion; Clariant		
Nutmeg	—	—	grinded	?		0/0	0/0	(2)	4/4	(2)	0/0	(2)	2/2	4/4	0/0	0/0	0/0	3/3	0/0	(1)	(1)	(2)	(2)	(2)	(2)	0/0	(1)	(1)	(1)				
Nutmeg oil	—	008008-45-5		(Xn)		0/0	0/0	(2)	4/4	0/0	0/0	(2)	(2)	4/4	0/0	0/0	0/0	3/4	0/0	(1)	(1)	(2)	(4)	(3)	(3)	0/0	(1)	(1)	(1)				
Nail varnish remover	—	—		?	(X)	0/0	0/0	(2)	4/4	0/0	(4)	(2)	1/3	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	(3)	(3)	4/4	0/0	(1)	(1)	(1)	0/0			
Naphtha	—	008032-32-4		(Xn)		1/3	3/4	1/0	(2)	(1)	1/0	1/0	1/3	3/0	1/0	1/0	4/4	0/0	0/0	(1)	1/1	1/1	4/4	1/1	4/4	0/0	1/1	1/1	1/1	0/0	Petroleum gasoline		
Naphthalene	C ₁₀ H ₈	000091-20-3	100 %	F, Xn	X	0/0	1/3	1/0	(3)	0/0	0/0	1/2	1/3	3/4	1/0	4/4	4/4	1/4	0/0	(1)	1/1	1/3	4/4	1/1	4/4	0/0	1/1	1/1	1/1	0/0			
Naphthalene (in alcohol)	—	—		F, Xn	X	1/4	1/4	(2)	(3)	0/0	0/0	1/2	1/3	3/4	0/0	0/0	0/0	3/4	0/0	(1)	1/1	(2)	4/4	(3)	(3)	0/0	(1)	(1)	(1)	0/0			
Naphthene	-> see: Cyclohexane																																
Sodium acetate	C ₂ H ₃ NaO ₂	000127-09-3	any	—		1/1	1/1	1/0	1/2	(1)	1/1	1/1	1/1	2/2	1/1	2/3	3/0	1/1	1/1	1/1	1/1	1/0	(3)	3/3	0/0	1/1	1/1	1/1	1/1	1/1			
Sodium aluminium sulphate	NaAl(SO ₄) ₂	010102-71-3		?		1/1	1/1	(3)	(2)	(1)	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	(1)	(2)	0/0	1/3	(1)	(1)				
Sodium benzoate	C ₇ H ₅ NaO ₂	000532-32-1	36 %	Xn		1/1	1/1	1/0	(2)	(2)	0/0	(1)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	(1)	1/1	0/0	(1)	(1)	(1)	1/1			
Sodium benzoate	C ₇ H ₅ NaO ₂	000532-32-1	aqueous	Xn		1/1	1/1	(2)	(2)	(1)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/0	1/1	0/0	1/1	1/0	1/0	1/1			
Sodium benzoate	C ₇ H ₅ NaO ₂	000532-32-1		Xn		1/1	1/1	1/0	(2)	(1)	0/0	1/1	1/1	1/1	0/0	1/3	0/0	1/1	1/1	1/1	1/1	1/1	1/0	1/0	1/1	0/0	1/1	1/0	1/0	1/1			
Sodium bicarbonate	NaHCO ₃	000144-55-8	aqueous	—		1/1	1/1	1/0	1/0	1/0	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/0	1/1	1/1			
Sodium bichromate	-> see: Sodium dichromate																																
Sodium bisulphate	NaHSO ₄	007681-38-1	10 %	(C)		1/1	1/1	4/4	1/0	1/0	0/0	2/0	1/1	0/0	0/0	1/3	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/0	1/3	0/0	1/3	1/2	1/1	1/1			
Sodium bisulphate	NaHSO ₄	007681-38-1	any	(C)		1/1	1/1	1/0	1/0	0/0	0/0	(3)	1/1	1/3	0/0	1/4	0/0	1/1	1/1	1/1	1/1	1/1	1/0	1/0	1/3	0/0	1/3	(2)	1/1	1/1			
Sodium bisulphite	NaHSO ₃	007631-90-5	aqueous	Xn		1/1	1/1	1/0	(2)	1/0	0/0	4/4	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/0	1/0	0/0	1/0	1/1	1/1	1/1			

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	Thermoplastics										Fluoroplastics				Elastomers				Metals				REMARK																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																										
					FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI		AL	V2A	V4A	Hastelloy C																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																						
Sodium chloride	NaCl	007647-14-5	aqueous	—		1/1	1/1	1/1	1/1	1/1	1/1	1/2	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	

24 of 34

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	FLAMMABLE	Thermoplastics										Fluoroplastics				Elastomers				Metals				Hastelloy C	REMARK	
						HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL			V2A
Sweet orange juice	-> see: Orange juice																													
Sweet orange peel oil	-> see: Orange peel oil																													
Ortho-silicic acid tetraethyl ester	-> see: Tetraethylorthosilicate																													
Orthophosphoric acid	-> see: Phosphoric acid																													
Oxabutyl acetate	-> see: Methyl glycol acetate																													
Oxalic acid	C ₂ H ₂ O ₄ x 2H ₂ O	000144-62-7	aqueous	Xn		1/1	1/1	4/4	(2)	(2)	0/0	4/4	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	(2)	1/0	1/1	3/3	0/0	1/0	2/3	1/3	1/2
Oxalic acid	C ₂ H ₂ O ₄ x 2H ₂ O	000144-62-7		Xn		1/1	1/1	3/4	1/0	0/0	1/1	4/4	1/1	1/1	1/0	1/1	1/1	1/1	1/1	1/1	1/3	1/0	1/1	3/3	0/0	1/0	2/3	1/3	1/3	
Oxalic acid sodium salt	-> see: Sodium oxalate																													
Oxalic acid ammonium salt	-> see: Ammonium oxalate																													
Oxirane	-> see: Ethylene oxide																													
Oxolane	-> see: Tetrahydrofuran																													
Oxydiacetic acid	-> see: Diglycolic acid																													
Oxymethylfurfural, 5-	C ₆ H ₆ O ₃	000067-47-0		Xi		0/0	0/0	(3)	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(3)	(3)	(3)	4/4	0/0	(1)	(1)	(1)		
Ozone	O ₃	010028-15-6		(O, T)		3/4	3/4	4/4	1/2	0/0	1/1	4/4	3/4	2/2	1/1	1/2	0/0	1/1	1/1	1/1	(1)	1/3	1/0	1/0	4/4	0/0	(2)	0/0	0/0	0/0
Ozone-air mixture-Luft-Gemisch	—	—		(O, T)		0/0	0/0	4/4	(2)	0/0	0/0	4/4	3/4	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	(2)	1/0	1/0	4/4	0/0	(2)	0/0	0/0	0/0
Palmitic acid	C ₁₆ H ₃₂ O ₂	000057-10-3	tech. pure	Xi		3/3	2/2	1/1	(2)	1/0	0/0	1/0	3/4	1/1	0/0	1/1	3/0	1/1	0/0	(1)	1/1	1/1	4/4	1/1	3/3	0/0	1/1	1/1	1/1	1/1
Palmityl alcohol	-> see: Cetyl alcohol																													
Palm seed oil	—	008023-79-8		—		0/0	0/0	1/0	(2)	1/0	0/0	(2)	1/3	1/1	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	1/1	0/0	(1)	1/1	1/1	1/1
Palm oil	—	008002-75-3		—		1/3	0/0	1/0	(2)	1/0	0/0	(2)	1/3	0/0	0/0	1/0	0/0	1/1	0/0	(1)	1/1	1/1	4/4	1/0	1/1	0/0	(1)	1/1	1/1	
Paraffins	C _n H _{2n+2}	—	100 %	?		1/0	1/1	1/0	1/0	1/0	1/0	1/1	1/1	1/0	1/0	1/0	0/0	0/0	(1)	1/1	(1)	4/4	1/0	1/3	0/0	1/1	1/1	1/1	1/1	1/1
Paraffin emulsion	—	—		?		1/3	0/0	1/0	(2)	(2)	0/0	(2)	1/3	0/0	0/0	1/0	0/0	0/0	0/0	(1)	1/1	1/1	(4)	1/0	1/1	0/0	(2)	(1)	(1)	0/0
Paraffin wax	—	008002-74-2	melted	(—)		0	0	0	(2)	0	0	(2)	(2)	0	0	0	0	0	0	(1)	1	0	4	(2)	1	0	1	1	1	
Paraform	-> see: Paraformaldehyde																													
Paraformaldehyde	(CH ₂ O) _n H ₂ O	030525-89-4		F, T	X	0/0	0/0	0/0	(2)	1/0	0/0	(2)	1/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	3/0	1/0	3/3	0/0	(1)	(1)	(1)	
Perfumes	—	—		?		3/0	3/0	1/0	(3)	1/0	0/0	(2)	1/0	4/4	0/0	1/0	3/0	0/0	0/0	(1)	(1)	(1)	(3)	(2)	(3)	0/0	(1)	(1)	(1)	
Pectin	—	009000-69-5	aqueous	—		1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	(1)	1/1	1/1	Pectin
Pectin	—	009000-69-5		—		1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	(1)	1/1	1/1	Pectin
Penicillin	—	—		Xn		(1)	(1)	(2)	(1)	(1)	0/0	(1)	(2)	0/0	0/0	0/0	1/1	(1)	1/1	(1)	(1)	(1)	(2)	(1)	(2)	0/0	(1)	(1)	(1)	Antibiotic
Pentachlorodiphenyl	C ₁₂ H ₅ Cl ₅	—		Xn		0/0	0/0	1/0	(3)	0/0	0/0	(2)	4/4	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(2)	4/4	3/0	4/4	0/0	(1)	0/0	0/0		a PCB
Pentamethyleneimine	-> see: Piperidine																													
Pentane	C ₅ H ₁₂	000109-66-0		F	X	1/3	1/3	1/0	1/0	1/1	(3)	1/0	(3)	3/0	0/0	0/0	0/0	1/0	0/0	(1)	(1)	(1)	4/4	1/0	1/2	0/0	1/1	1/1	1/1	
Pentanone, 2-	-> see: Methyl propyl ketone																													
Pentanone, 3-	-> see: Diethyl ketone																													
Pentanethiol, 1-	C ₅ H ₁₂ S	000110-66-7		Xn	X	0/0	0/0	(2)	(3)	0/0	(4)	(2)	(2)	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	4/4	(3)	(4)	0/0	(2)	(1)	(1)		
Pentylacetate, n-	-> see: Amylacetate, n-																													
Pentyl alcohol	-> see: Amyl alcohol, n-																													
Pentyl chloride	-> see: Amyl chloride																													
Pentylcinnamaldehyde, a-	-> see: α-pentylcinnamaldehyde																													
Perchlorobutadiene	-> see: Hexachlorobutadiene																													
Perchloroethene	-> see: Perchloroethylene																													
Perchloroethylene (PER)	C ₂ Cl ₄	000127-18-4		Xn		4/4	4/4	4/4	4/4	3/4	4/4	1/3	4/4	4/4	4/4	4/4	3/3	1/1	1/1	1/1	1/1	4/4	2/3	4/4	0/0	(3)	0/0	0/0	0/0	
Perchloric acid	HClO ₄	007601-90-3	70 %	E, O, C+		2/4	3/4	4/4	4/4	(4)	2/4	4/4	4/4	2/3	4/4	3/4	4/4	0/0	1/2	1/1	1/1	1/1	3/0	1/1	4/4	0/0	4/4	0/0	0/0	?
Perchloric acid	HClO ₄	007601-90-3	20 %	Xi		0/0	1/3	4/4	3/0	0/0	0/0	4/4	1/3	0/0	0/0	1/3	3/0	0/0	0/0	1/1	1/1	1/1	2/0	1/1	4/4	0/0	4/4	0/0	0/0	1/1
Perfluoropropane	C ₃ F ₈	000076-19-7		?		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	1/0	1/0	0/0	(3)	0/0	0/0		
Perhydroxic acid	-> see: Hydrogen peroxide 30 %																													
Petrolatum, petroleum jelly	-> see: Vaseline																													
Petroleum ether	—	008032-32-4	tech. pure	(F, Xn)	X	1/3	1/3	1/0	3/0	1/0	1/0	1/1	1/3	4/4	1/0	1/1	3/3	3/3	0/0	(1)	1/1	1/1	4/4	1/0	1/3	0/0	1/1	1/1	1/1	1/1
Petroleum	—	—	tech. pure	Xn, N	X	1/3	3/4	1/0	3/0	(1)	0/0	1/1	1/3	4/4	1/0	1/0	3/0	3/4	0/0	(1)	1/1	1/1	4/4	1/0	1/1	0/0	1/1	1/1	1/1	1/1
Pepper	—	—	grinded	?		0/0	0/0	(2)	1/0	(1)	0/0	(2)	(2)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	(2)	(2)	(2)	0/0	(1)	(1)	(1)	
Vegetable oils	—	—		—		0/0	0/0	0/0	(2)	1/0	0/0	(2)	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	1/0	0/0	(1)	1/1	1/1	
Phenacetin	C ₁₀ H ₁₃ NO ₂	000062-44-2		Xn		0/0	0/0	0/0	0/0	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	1/1	0/0	(1)	(1)	(1)	(2)	(2)	(2)	0/0	(2)	(1)	(1)	
Phenetole	-> see: Phenylethylether																													

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	Thermoplastics													Fluoroplastics				Elastomers				Metals				Hastelloy C	REMARK	
					FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A			
Phenyl-2-propenal, trans-3-	-> see: Cinnamaldehyde																															
Phenylamine	-> see: Aniline																															
Phenylaniline, N-	-> see: Diphenylamine																															
Phenyl bromide	-> see: Bromobenzene																															
Phenylcarbinol	-> see: Benzyl alcohol																															
Phenyl chloride	-> see: Chlorobenzene																															
Phenylethanol	C ₈ H ₁₀ O	000060-12-8		Xn		0/0	0/0	3/0	4/4	0/0	0/0	(2)	1/0	0/0	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	(3)	(2)	4/4	0/0	(1)	(1)	(1)			
Phenyl ether	-> see: Diphenyl ether																															
Phenylethyl alcohol	-> see: Phenylethanol																															
Phenyl ethyl ether	C ₈ H ₁₀ O	000103-73-1		?		0/0	0/0	(2)	(4)	0/0	(3)	(2)	(3)	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	4/4	4/4	0/0	(1)	(1)	(1)				
Phenylhydrazine	C ₆ H ₈ N ₂	000100-63-0	tech. pure	T		3/0	0/0	(3)	(3)	0/0	0/0	(2)	3/4	0/0	0/0	4/4	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/3	4/4	0/0	(2)	0/0	0/0	0/0		
Phenylhydrazine chlorohydrate	-> see: Phenylhydrazine-HCl																															
Phenylhydrazine-HCl	C ₆ H ₈ N ₂ -HCl	000059-88-1		T		0/0	0/0	(3)	(2)	0/0	0/0	(3)	1/3	0/0	0/0	3/0	0/0	0/0	0/0	(1)	1/1	1/1	(3)	1/3	1/3	0/0	(4)	(4L)	(4L)			
Phenylpropane	-> see: Cumene																															
Phenyl sulphonate	—	70528-83-5		?		0/0	1/1	0/0	0/0	0/0	0/0	0/0	1/1	0/0	0/0	0/0	0/0	0/0	(1)	(1)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0				
Phenylsulfonic acid	-> see: Benzenesulfonic acid																															
Phosgene	COCl ₂	000075-44-5	liquid	T+, C		0/0	0/0	1/0	(3)	0/0	0/0	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(3)	(3)	1/0	3/0	0/0	(3)	3/4	3/4	0/0			
Phosgene	COCl ₂	000075-44-5	gaseous	T+, C		0/0	3/0	1/0	(3)	0/0	0/0	(2)	3/4	0/0	0/0	4/4	0/0	0/0	0/0	(1)	1/1	(3)	(3)	(3)	3/0	0/0	(3)	3/4	3/4	0/0		
Phosphates	—	—	aqueous	?		1/1	1/1	0/0	0/0	(1)	0/0	(2)	3/4	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	(1)	(1)	(2)	0/0	0/0	(1)	(1)		Salts of phosphoric acid	
Phosphine	PH ₃	007803-51-2	concentrated	F+, T+	X	0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	1/0	0/0	0/0	0/0	0/0	1/0	1/1	1/0	1/0	4/4	0/0	(1)	0/0	0/0	0/0		
Phosphorus (III) chloride	-> see: Phosphorus trichloride																															
Phosphorus oxychloride	POCl ₃	010025-87-3	100 %	T, C		0/0	1/0	4/4	4/4	0/0	0/0	4/4	1/3	0/0	0/0	4/4	4/4	0/0	0/0	0/0	1/1	(2)	1/0	1/1	4/4	0/0	1/3	1/3L	1/3L	1/1		
Phosphorus oxychloride	POCl ₃	010025-87-3		T, C		0/0	1/0	4/4	4/4	0/0	0/0	4/4	1/3	0/0	0/0	4/4	4/4	0/0	0/0	0/0	1/1	(2)	1/0	1/1	4/4	0/0	1/3	1/3L	1/3L	1/1		
Phosphorus pentachloride	PCl ₅	010026-13-8		T+, C		0/0	1/0	4/4	4/4	0/0	0/0	4/4	1/1	0/0	0/0	4/4	4/4	0/0	0/0	0/0	1/1	1/1	(3)	(3)	4/4	0/0	1/1	1/3L	1/3L	0/0		
Phosphorus pentoxide	P ₂ O ₅	001314-56-3	tech. rein	C		1/0	0/0	(4)	(3)	0/0	0/0	4/4	1/0	0/0	0/0	1/0	0/0	0/0	0/0	(1)	1/0	1/1	(3)	(2)	3/4	0/0	1/1	1/0	1/0	0/0		
Phosphorus perchloride	-> see: Phosphorus pentachloride																															
Phosphoric acid	H ₃ PO ₄	007664-38-2	30 %	C		1/1	1/1	4/4	1/0	0/0	0/0	4/4	1/1	1/1	0/0	0/0	0/0	1/1	0/0	1/1	1/1	1/1	1/0	1/1	3/3	0/0	4/4	1/3	1/2	1/1		
Phosphoric acid	H ₃ PO ₄	007664-38-2	85 %	C		1/1	1/1	4/4	1/2	0/0	1/2	4/4	1/2	1/2	1/1	1/2	1/1	1/1	1/1	1/1	1/1	3/0	1/1	4/4	0/0	4/4	2/4	1/3	1/1	1/1		
Phosphoric acid	H ₃ PO ₄	007664-38-2	1-5 %	Xi		1/1	1/1	(3)	1/1	1/0	1/1	3/4	1/1	2/2	1/1	1/1	0/0	1/1	1/1	1/1	1/1	1/1	1/0	1/1	2/3	0/0	(4)	1/1	1/1	1/1		
Phosphoric acid	H ₃ PO ₄	007664-38-2	20%	Xi		1/1	1/1	4/4	(2)	0/0	0/0	4/4	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/1	3/3	0/0	4/4	1/3	1/2	1/1		
Phosphoric anhydride	-> see: Phosphorus pentoxide																															
Phosphoric acid chloride	-> see: Phosphorus pentachloride																															
Phosphoric acid tritolyester	-> see: Tricresyl phosphate																															
Phosphorus trichloride	PCl ₃	007719-12-2		T, C		3/3	3/3	4/4	4/4	0/0	0/0	4/4	1/3	0/0	0/0	4/4	4/4	0/0	0/0	1/0	1/1	1/1	1/0	3/4	4/4	0/0	1/1	0/0	0/0	1/1		
Hydrogen phosphide	-> see: Phosphine																															
Phosphoryl chloride	-> see: Phosphorus oxychloride																															
Phthalic acid	C ₆ H ₄ O ₄	000088-99-3	saturated	Xi		1/1	1/1	3/3	(3)	1/0	0/0	1/0	1/1	1/0	0/0	1/4	0/0	1/1	0/0	1/1	1/1	1/1	1/0	2/3	4/4	0/0	1/1	1/1	1/1	1/1		
Phthalic acid amyl ester	C ₁₈ H ₂₆ O ₄	000131-18-0	100 %	(T)		0/0	1/3	(1)	(4)	0/0	0/0	(2)	(2)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	3/0	3/0	4/4	0/0	(1)	(1)	(1)	0/0		
Phthalic acid dibutyl ester	-> see: Dibutyl phthalate																															
Phthalic acid dicyclohexyl ester	-> see: Dicyclohexyl phthalate																															
Phthalic acid dimethyl ester	-> see: Dimethyl phthalate																															
Phthalic acid dinonyl ester	-> see: Dinonyl phthalate																															
Phthalic acid monoamyl ester	C ₁₃ H ₁₆ O ₄	??		(Xn)		0/0	0/0	(3)	(3)	0/0	0/0	(3)	(2)	0/0	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	(2)	(2)	(3)	0/0	(1)	(1)	(1)			
Picric acid	C ₆ H ₃ N ₃ O ₇	000088-89-1	1 % aqueous	T		1/0	1/0	3/0	(3)	0/0	0/0	(3)	1/1	0/0	0/0	1/0	4/4	0/0	0/0	1/0	1/0	1/1	3/0	1/0	3/4	0/0	1/0	1/0	1/0	1/0		
Pimenta, allspice	—	—	grinded	?		0/0	0/0	(2)	4/4		0/0	(2)	(2)	4/4	0/0	0/0	0/0	3/3	0/0	(1)	(1)	(1)	(2)	(2)	(2)	0/0	(1)	(1)	(1)			
Piperidine	C ₅ H ₁₁ N	000110-89-4		F, T, C		0/0	0/0	(3)	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	4/4	4/4	0/0	(1)	(1)	(1)			
Polyester resins	—	—		(Xn)	(X)	3/4	3/4	1/0	4/4	1/0	0/0	(2)	3/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	(3)	4/4	0/0	(1)	(1)	(1)			
Polyethylene glycol	HO-(C ₂ H ₄ O) _n -H	025322-68-3	100 %	(—)		1/1	1/1	(3)	0/0	0/0	0/0	1/0	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	(2-3)	(2)	(3)	0/0	(1)	(1)	(1)	0/0		
Polyglycol	-> see: Polyethylene glycol																															
Polyoxyethylene	-> see: Polyethylene glycol																															
Polyoxymethylene	-> see: Paraformaldehyde																															
Polyran M25 N	—	—																														

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	FLAMMABLE	Thermoplastics										Fluoroplastics			Elastomers			Metals			REMARK						
						HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM		NBR	SI	AL	V2A	V4A	Hastelloy C
Bitter orange oil	—	068916-04-1	—	?	2/3	3/4	(2)	3/3	1/0	3/3	(2)	2/3	4/4	3/3	3/4	0/0	0/0	0/0	1/1	1/1	(1)	(2)	4/4	(2)	(4)	0/0	(1)	(1)	(1)		
Potash	-> see: Potassium carbonate																														
Compressed air	—	—	oily	—	1/0	0/0	(2)	(2)	(1)	0/0	(1)	3/0	0/0	0/0	3/0	0/0	0/0	0/0	(1)	1/1	1/1	(3)	(1)	(2)	0/0	1/1	1/1	1/1			
Prontosil	—	—	—	(Xn)	0/0	0/0	(2)	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	1/0	0/0	(1)	(1)	(2)	(2)	(2)	(2)	0/0	(1)	0/0	0/0		Chemotherapeutic agent; Bayer - no longer on the market	
Prop-2-enyl acetate	-> see: Allyl acetate																														
Propane	C ₃ H ₈	000074-98-6	liquid	F+	X	1/0	1/0	1/0	1/0	1/0	0/0	1/1	1/0	0/0	1/0	1/0	3/0	1/0	0/0	(1)	1/1	1/1	4/4	1/0	(2)	0/0	1/1	1/1	1/1	0/0	
Propane	C ₃ H ₈	000074-98-6	gaseous	F+	X	3/4	4/4	1/0	3/4	1/0	4/4	1/1	2/4	4/4	3/3	1/2	0/0	0/0	1/1	1/1	1/1	1/1	4/4	1/0	1/0	0/0	1/1	1/1	1/1	0/0	
Propandiol, 1,2-	-> see: Propylene glycol																														
Propanol	C ₃ H ₈ O	000071-23-8	—	F	X	1/1	1/1	1/1	1/0	1/0	0/0	1/1	1/1	3/0	0/0	2/2	3/3	1/4	0/0	1/1	1/1	1/1	1/0	1/1	3/3	0/0	1/1	(1)	(1)	0/0	
Propanol, 2-	-> see: Isopropyl																														
Propanone, 2-	-> see: Acetone																														
Propanoic acid	-> see: Propionic acid																														
Propanetriol	-> see: Glycerine																														
Propargyl alcohol	C ₃ H ₄ O	000107-19-7	7 %	Xn	1/1	1/1	(3)	1/0	0/0	0/0	(2)	1/1	0/0	0/0	1/1	1/0	0/0	0/0	(1)	1/1	1/3	1/0	1/1	1/1	0/0	1/0	(1)	(1)	0/0		
Propene	C ₃ H ₆	000115-07-1	—	F+	X	1/1	1/1	1/0	(3)	1/0	0/0	1/0	1/1	4/4	0/0	3/4	4/4	0/0	0/0	(1)	1/1	(1)	4/4	1/0	4/4	0/0	1/1	1/1	1/1		
Propene-1-ol, 2-	-> see: Allyl alcohol																														
Propene acid ethyl ester	-> see: Ethyl acrylate																														
Propyn-1-ol, 2-	-> see: Propargyl alcohol																														
Propionic acid	C ₃ H ₆ O ₂	000079-09-4	50 %	C, F	X	1/3	1/3	3/3	4/4	0/0	0/0	4/4	1/1	4/4	4/4	1/3	3/3	0/0	0/0	(1)	1/1	1/1	3/0	1/1	4/4	0/0	1/1	(1)	(1)	1/1	
Propionic acid	C ₃ H ₆ O ₂	000079-09-4	—	C, F+	X	1/3	1/3	3/3	4/4	0/0	0/0	4/4	1/3	4/4	4/4	4/4	0/0	0/0	1/0	1/1	1/1	4/4	3/0	4/4	0/0	1/1	1/2	1/1	1/1		
Propyl acetate	C ₃ H ₁₀ O ₂	000109-60-4	—	F	X	0/0	0/0	(1)	4/4	0/0	(4)	1/0	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	3/0	4/4	4/4	0/0	(1)	(1)	(1)		
Propyl alcohol	-> see: Propanol																														
Propylamine, n-	C ₃ H ₉ N	000107-10-8	—	F, C, Xn	X	0/0	0/0	0/0	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	4/4	4/4	0/0	(1)	(1)	(1)		
Propylene	-> see: Propene																														
Propylene(di)chloride	-> see: Dichloropropane																														
Propylene glycol	C ₃ H ₈ O ₂	000057-55-6	—	—	1/1	1/1	4/4	2/3	(2)	1/1	1/0	1/1	1/1	2/2	3/4	0/0	1/1	1/1	1/1	1/1	1/1	1/0	1/1	1/3	0/0	1/1	(1)	(1)	1/1		
Propylene glycol methyl ether	C ₄ H ₁₀ O ₂	—	—	—	X	0/0	0/0	(3)	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	(3)	(3)	4/4	0/0	(1)	(1)	(1)		Isomer not specified in the source	
Propylene oxide	C ₃ H ₆ O	000075-56-9	—	F+, T	X	1/1	1/2	(3)	2/3	0/0	1/2	(2)	1/2	4/4	2/2	3/4	0/0	4/4	3/4	1/1	1/0	1/4	3/0	4/4	4/4	0/0	(1)	(1)	(1)	0/0	
Propylidinitris(methanol)	-> see: Trimethylol propane																														
Propyl nitrate	C ₃ H ₇ NO ₃	000627-13-4	—	(E, Xn)	(X)	0/0	0/0	(3)	(3)	0/0	0/0	(3)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(3)	3/0	4/4	4/4	0/0	(2)	(1)	(1)		
Pseudocumene	C ₉ H ₁₂	000095-63-6	—	Xn	X	0/0	0/0	(1)	(4)	0/0	0/0	(2)	3/3	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	(2)	4/4	0/0	1/1	1/1	1/1		
Pydraul C (312, 540)	—	—	—	(Xn)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	4/4	1/0	4/4	0/0	0/0	(1)	(1)		Base phosphoric acid ester; Monsanto	
Pydraul E (29, 30, 50, 65, 90, 11)	—	—	—	(Xn)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	1/0	4/4	0/0	0/0	(1)	(1)		Base phosphoric acid ester; Monsanto	
Pyridine	C ₅ H ₅ N	000110-86-1	—	F, Xn	X	1/3	0/2	1/0	4/4	0/0	0/2	1/1	3/3	4/4	4/4	4/4	4/4	1/1	(2)	1/1	1/3	4/4	4/4	4/4	0/0	1/1	1/1	1/1	0/0		
Pyridine-3-carboxylic acid	-> see: Nicotinic acid																														
Pyrogallol	C ₆ H ₆ O ₃	000087-66-1	—	Xn	0/0	0/0	1/0	(3)	0/0	0/0	3/4	1/0	3/0	0/0	0/0	0/0	1/3	0/0	(1)	(1)	1/1	(3)	(3)	(3)	0/0	1/1	1/1	1/1	1/1		
Pyrosulphite	-> see: Sodium disulphite																														
Pyrrrole	C ₄ H ₅ N	000109-97-7	—	Xn	X	0/0	0/0	(3)	(4)	0/0	0/0	(2)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(3)	4/4	4/4	4/4	0/0	(1)	(1)	(1)		
Mercury	Hg	007439-97-6	pure	T	1/1	1/1	1/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	3/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	(3)	1/1	1/1	1/1	
Mercury (II) chloride	HgCl ₂	007487-94-7	aqueous	T+, C	1/1	1/1	4/4	1/0	(2)	1/1	3/0	1/1	1/3	1/0	1/3	1/0	1/1	1/1	1/1	1/1	1/1	1/1	1/0	1/1	1/3	0/0	4/4	(4)	(4)	1/1	
Mercury (II) cyanide	C ₂ HgN ₂	000592-04-1	saturated	T+	1/1	1/1	(3)	(2)	(2)	0/0	(3)	1/1	0/0	0/0	1/3	0/0	0/0	(1)	1/1	1/1	1/1	(1)	1/1	(2)	0/0	4/4	1/0	1/0	1/1		
Mercury (II) nitrate	-> see: Mercury nitrate																														
Mercury nitrate	Hg(NO ₃) ₂	010045-94-0	saturated	(T+)	1/1	1/1	1/0	(2)	(2)	0/0	(3)	1/1	1/0	0/0	1/3	1/0	0/0	(1)	1/1	1/1	1/1	1/0	1/1	1/3	0/0	4/4	1/1	1/1	1/1		
Mercuric nitrate	-> see: Mercury nitrate																														
Ramasit	—	—	—	?	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	1/1	0/0	0/0	0/0	0/0	(1)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	Hydrophobing agent for textiles; BASF	
Resorcinol	C ₆ H ₆ O ₂	000108-46-3	5 %	—	1/1	1/1	4/4	2/3	0/0	1/1	(3)	1/1	2/3	4/4	2/4	0/0	3/3	1/3	1/1	(1)	(3)	(3)	(3)	(3)	0/0	(2)	0/0	0/0			
Resorcinol	C ₆ H ₆ O ₂	000108-46-3	saturated	Xn	1/1	1/1	4/4	2/3	0/0	1/1	(3)	1/1	2/3	4/4	3/4	0/0	0/0	1/1	(1)	(1)	(3)	(3)	(3)	(3)	0/0	(2)	0/0	0/0			
Beef tallow	—	061789-97-7	—	—	0/0	0/0	1/0	1/0	(1)	0/0	1/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	4/4	1/1	1/1	0/0	(1)	1/1	1/1			
Beef tallow emulsion	—	—	sulphurised	(—)	1/0	0/0	(2)	(2)	0/0	0/0	0/0	1/0	0/0	0/0	1/0	0/0	1/1	0/0	(1)	1/1	1/1	4/4	(2)	(2)	0/0	(2)	(1)	(1)	0/0		
Castor oil	—	008001-79-4	100 %	Xi	1/1	1/1	1/0	1/0	(1)	1/0	(2)	1/1	1/1	0/0	1/0	3/0	1/1	0/0	(1)	1/1	1/1	3/0	1/0	1/0	0/0	(1)	1/1	1/1	1/1		
Crude oil	—	—	100 %	(N)	0/0	1/3	1/0	(3)	1/0	0/0	1/0	1/3	3/0	1/0	1/0	3/0	0/0	(1)	1/1	1/1	4/4	1/0	3/3	0/0	(2)	(1)	(1)				

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	Thermoplastics										Fluoroplastics					Elastomers					Metals					Hastelloy C	REMARK
					FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A		
Rose oil	—	008007-01-0	—	?		0/0	0/0	(2)	(3)	0/0	0/0	(2)	(2)	4/4	0/0	0/0	0/0	3/0	0/0	(1)	(1)	(2)	(3)	(3)	(3)	0/0	(1)	(1)	(1)		
Roasting gases	—	—	any	(T)		0/0	0/0	(2)	0/0	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	1/0	1/0	4/4	0/0	(4)	(2)	(2)	0/0	
Colza oil	—	008002-13-9	—	—		0/0	0/0	(2)	(2)	1/0	0/0	(2)	1/3	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/0	1/3	0/0	(1)	1/1	1/1			
Rum flavouring	—	008030-89-5	—	?		0/0	0/0	(2)	(3)	0/0	0/0	(2)	(2)	4/4	0/0	0/0	0/0	1/0	0/0	(1)	(1)	(3)	(3)	(4)	(3)	0/0	(1)	(1)	(1)		
Sagrotan	—	—	liquid	?		1/2	1/3	0/0	3/0	0/0	0/0	(3)	1/3	3/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	1/0	1/0	3/0	0/0	(2)	(1)	(1)		Disinfectants; Schülke & Mayr
Salicylaldehyde	C ₇ H ₆ O ₂	000090-02-8	—	Xn, Xi		1/1	1/2	(3)	2/3	0/0	1/2	(3)	1/2	4/4	3/3	3/4	0/0	0/0	1/4	1/1	(1)	(3)	(3)	(3)	4/4	0/0	(2)	(1)	(1)		
Salicylic acid	C ₇ H ₆ O ₃	000069-72-7	saturated	(Xn, Xi)		1/1	1/1	1/0	1/2	1/0	1/1	4/4	1/1	1/2	1/1	2/3	0/0	1/1	1/1	1/1	1/0	1/1	1/0	1/0	3/3	0/0	1/0	1/0	1/0	1/1	
Salicylic acid	C ₇ H ₆ O ₃	000069-72-7	Powder	Xn, Xi		1/1	1/1	1/0	1/2	(1)	1/2	(3)	1/1	1/1	1/1	2/3	0/0	0/0	1/1	1/1	1/0	1/1	1/0	1/0	3/3	0/0	1/0	1/0	1/0	1/1	
Salicylic acid methyl ester	-> see: Methyl salicylate																														
Salammoniac	-> see: Ammonium chloride																														
Ammonia solution	-> see: Ammonium hydroxide																														
Nitric acid	HNO ₃	007697-37-2	1-10 %	C		1/1	1/1	4/4	1/2	(2)	1/1	4/4	1/1	2/4	1/3	1/2	0/0	1/3	1/1	1/1	1/1	1/1	2/0	1/1	4/4	0/0	3/4	1/1	1/1	1/1	
Nitric acid	HNO ₃	007697-37-2	50 %	C+		2/4	3/4	4/4	4/4	(2)	2/4	4/4	3/4	4/4	2/3	2/3	0/0	0/3	1/1	1/1	1/1	1/1	4/4	1/0	4/4	0/0	4/4	1/2	1/2	1/2	
Nitric acid	HNO ₃	007697-37-2	66 %	C+		2/4	3/4	4/4	4/4	(4)	2/3	4/4	4/4	4/4	4/4	3/4	0/0	0/0	1/1	1/1	1/1	1/1	4/4	1/0	4/4	0/0	4/4	1/2	1/2	1/2	
Nitric acid	HNO ₃	007697-37-2	100 %	O, C+		4/4	4/4	4/4	4/4	(4)	0/0	4/4	4/4	0/0	0/0	4/4	0/0	4/4	0/0	1/1	4/4	4/4	4/4	4/4	4/4	0/0	1/1	2/3	3/3	?	
Nitric acid	HNO ₃	007697-37-2	70 %	O, C+		2/4	3/4	4/4	4/4	(4)	2/3	4/4	4/4	4/4	4/4	3/4	0/0	0/0	1/1	1/1	1/1	1/1	4/4	2/3	4/4	0/0	4/4	1/2	1/2	1/2	
Hydrochloric acid	HCl	007647-01-0	1-5 %	—		1/1	1/1	4/4	1/1	(2)	1/2	4/4	1/1	1/1	1/1	1/1	0/0	1/3	1/1	1/1	1/1	1/0	1/1	3/4	0/0	4/4	4/4	4/4	4/4	1/1	
Hydrochloric acid	HCl	007647-01-0	35 %	C		1/1	1/1	4/4	4/4	(4)	1/2	4/4	1/2	3/3	1/1	2/3	3/3	1/3	1/1	1/1	1/1	1/1	3/0	1/2	4/4	0/0	4/4	4/4	4/4	1/1	
Hydrochloric acid	HCl	007647-01-0	konz.	C		1/1	1/1	4/4	4/4	(4)	1/2	4/4	1/2	3/3	1/1	2/3	3/3	1/3	1/1	1/1	1/1	1/1	3/0	1/2	4/4	0/0	4/4	4/4	4/4	1/1	
Hydrochloric acid	HCl	007647-01-0	20 %	Xi		1/1	1/1	4/4	2/3	3/0	1/2	4/4	1/1	1/1	1/1	1/3	0/0	0/3	1/1	1/1	1/1	1/1	1/0	1/1	4/4	0/0	4/4	4/4	4/4	1/1	Hydrochloric acid
Hydrochloric acid aluminium salt, anhydrous	-> see: Aluminium chloride																														
Salt brine	NaCl	007647-14-5	saturated	—		1/1	1/1	1/0	(1)	(1)	0/0	1/2	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/1	1/1	0/0	3/4	1/3	1/2	0/0	
Salt water, seawater	—	—	—	—		1/1	1/1	1/0	1/1	1/1	0/0	1/1	1/1	1/1	0/0	1/3	1/3	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	3/4	1/3L	1/2L	1/1		
Saturated steam condensate	—	—	?	?		0/0	0/0	(2)	(2)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(2)	(2)	(2)	(2)	0/0	(2)	1/1	1/1			
Oxygen	O ₂	007782-44-7	tech. pure	O		1/3	1/3	2/0	1/0	(1)	0/0	1/0	1/3	1/0	0/0	1/1	1/0	0/0	1/1	1/1	1/1	1/0	1/0	3/3	0/0	(2)	(1)	(1)	0/0		
Lubricating oils	—	—	?	?		1/3	2/3	(2-3)	(1)	(2)	0/0	(2)	3/0	0/0	0/0	1/1	1/3	0/0	0/0	(1)	1/1	1/1	4/4	1/1	1/0	0/0	1/1	1/1	1/1	0/0	
Lubricating soap	—	—	diluted	?		1/3	1/1	(2-3)	(2)	(1)	0/0	1/1	1/1	0/0	0/0	1/3	0/0	0/0	1/1	1/1	(1)	(2)	(1)	1/1	0/0	(2)	(1)	(1)	0/0		
Sulphur	S ₈	007704-34-9	tech. pure	Xi		1/1	1/1	1/0	1/0	(2)	0/0	1/0	1/1	1/1	0/0	3/0	3/4	1/1	0/0	(1)	1/1	1/1	3/0	1/1	4/4	0/0	(1)	1/1	1/1	1/1	Sulphur, net sulphur, sulphur bloom
Sulphur, melted, 121 °C	S ₈	007704-34-9	?	?		0	0	(4)	(3)	0	4	4	4	4	0	0	0	4	0	0	(1)	0	4	1	4	0	(3)	1	1	0/0	
Sulphur chloride	S ₂ Cl ₂	010025-67-9	—	C		0/0	0/0	4/4	(3)	0/0	0/0	4/4	4/4	0/0	0/0	0/0	0/0	0/0	1/0	1/1	1/0	4/4	1/0	4/4	0/0	3/4	(1/1L) ¹⁾	(1/1L) ¹⁾	0/0		¹⁾ Water-free! If even traces of hydrochloric acid (HCl) are split off by moisture, there is a risk of pitting, crevice and stress corrosion cracking.
Sulphur dioxide	SO ₂	007446-09-5	moist	T, C		1/1	1/1	(3)	(3)	0/0	1/1	4/4	1/3	3/4	2/2	1/2	0/0	0/0	1/1	1/1	1/1	1/4	1/0	4/4	4/4	0/0	3/4	1/1	1/1	1/0	with H2O -> Sulphurous acid
Sulphur dioxide	SO ₂	007446-09-5	liquid	T, C		3/4	4/4	(3)	3/4	0/0	4/4	4/4	4/4	4/4	2/2	3/4	0/0	0/0	1/2	1/1	1/1	4/4	1/0	4/4	4/4	0/0	(3)	(1)	(1)	1/0	with H2O -> Sulphurous acid
Sulphur dioxide, aqueous solution	-> see: Sulphurous acid																														
Sulphur ether	-> see: Ethyl ether																														
Sulphur hexafluorod	SF ₆	002551-62-4	—	—		0/0	0/0	1/0	(2)	1/0	0/0	1/0	(2)	0/0	0/0	0/0	0/0	1/0	0/0	0/0	(1)	(2)	1/0	3/0	1/0	0/0	(1)	(1)	(1)		
Carbon disulfide	CS ₂	000075-15-0	—	F+, T	X	4/4	4/4	3/0	4/4	0/0	4/4	2/0	4/4	4/4	4/4	4/4	4/4	4/4	1/3	1/1	1/0	1/1	4/4	1/0	4/4	0/0	1/1	1/1	1/1	1/0	
Sulphur monochloride	-> see: Sulphur chloride																														
Sulphur sodium	-> see: Sodium sulphide																														
Sulphuric acid	H ₂ SO ₄	007664-93-9	40 %	C+		1/1	1/1	4/4	2/0	(4)	1/2	4/4	1/1	2/0	3/0	1/3	1/3	1/1	1/1	1/1	1/1	1/1	(3)	1/1	4/4	0/0	3/4	2/3	2/3	0/0	
Sulphuric acid	H ₂ SO ₄	007664-93-9	60 %	C+		1/3	1/3	4/4	3/3	(4)	1/2	4/4	1/3	2/4	1/1	1/2	0/0	0/0	1/1	1/1	1/1	1/1	4/4	1/1	4/4	0/0	4/4	4/4	3/4	0/0	
Sulphuric acid	H ₂ SO ₄	007664-93-9	80 %	C+		1/1	1/1	4/4	3/4	4/4	1/2	4/4	1/1	3/4	3/0	1/1	1/3	0/0	1/1	1/1	1/1	1/1	4/4	1/1	4/4	0/0	4/4	2/4	2/3	0/0	
Sulphuric acid	H ₂ SO ₄	007664-93-9	95 %	C+		3/4	3/4	4/4	4/4	4/4	2/2	4/4	3/4	4/4	4/4	2/4	0/0	4/4	1/1	1/1	1/1	1/1	4/4	1/1	4/4	0/0	4/4	1/3	1/3	0/0	
Sulphuric acid	H ₂ SO ₄	007664-93-9	fuming	C+		4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	0/0	0/0	(1)	1/0	4/4	4/4	1/0	4/4	0/0	(3)	1/2	1/1	0/0	Oleum
Sulphuric acid																															

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	Thermoplastics										Fluoroplastics					Elastomers					Metals					REMARK	
					FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A		Hastelloy C
Sebacic acid dibenzyl ester	-> see: Dibenzyl sebacate																														
Sebacic acid dibutyl ester	-> see: Dibutylsebacat																														
Sebacic acid diethyl ester	-> see: Diethylsebacate																														
Ocean water, seawater	-> see: Salt water, seawater																														
Soap solution	—	—	any	(—)		1/1	0/0	4/4	(2)	1/1	0/0	1/1	1/1	0/0	0/0	1/3	0/0	0/0	1/1	1/1	1/1	(1)	(1)	1/0	1/1	1/0	0/0	(3)	1/1	1/1	1/1
Mustard	—	—	—	—		0/0	0/0	(2)	1/0	(1)	0/0	1/0	1/1	1/1	0/0	0/0	0/0	1/1	0/0	1/1	(1)	(1)	(2)	1/0	1/0	0/0	(2)	1/0L	1/0L		
Mustard oil	-> see: Allyl mustard oil																														
Silver acetate	C ₂ H ₃ AgO ₂	000563-63-3		Xi		1/1	1/1	(2)	1/2	(2)	1/1	(2)	1/1	2/2	1/1	2/2	0/0	0/0	1/1	1/1	(1)	(1)	(1)	(1)	(2)	(3)	0/0	(4)	0/0	0/0	0/0
Silver cyanide	CAgN	000506-64-9		T		1/1	1/1	(2)	(2)	(2)	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	0/0	1/1	(1)	(1)	(1)	(1)	(3)	0/0	(4)	0/0	0/0	0/0
Silver nitrate	AgNO ₃	007761-88-8	aqueous	C		1/1	0/0	1/0	1/1	(2)	0/0	1/0	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/1	3/3	0/0	4/4	1/1	1/1	1/1	1/1	
Silver nitrate	AgNO ₃	007761-88-8		C		1/1	1/2	1/0	1/1	(2)	1/1	1/0	1/2	2/3	1/1	1/2	1/3	1/2	1/1	1/1	1/1	1/1	1/0	1/1	3/3	0/0	4/4	1/1	1/1	1/1	
Silicon dioxide	-> see: Silicic acid																														
Silicone fats	—	—		(—)		0/0	0/0	1/0	1/0	1/0	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	(1)	(1)	1/0	1/0	1/1	0/0	1/1	1/1	1/1	1/1		
Silicone oil	—	—		?		1/1	1/1	1/0	1/0	1/1	1/1	1/1	1/1	3/3	1/0	1/4	0/0	1/1	0/0	1/1	1/1	(1)	1/0	1/1	1/1	0/0	1/1	1/1	1/1	1/1	Polysiloxan
Skydrol 500 (B4)	—	—		(Xn)		0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	1/1	(1)	0/0	1/0	4/4	4/4	0/0	0/0	(1)	(1)			Basis Phosphorsäurester; Solutia
Skydrol 7000	—	—		(Xn)		0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	0/0	1/0	2/0	4/4	0/0	0/0	(1)	(1)			Basis Phosphorsäurester; Solutia
Soda	-> see: Sodium carbonate																														
Soya oil	—	008001-22-7		—		0/0	0/0	(2)	(1)	1/0	0/0	2/0	1/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	4/4	1/1	1/0	0/0	(1)	1/1	1/1	1/1	1/1	
Spindle oil	—	—		?		3/3	2/3	(2)	(2)	1/0	0/0	(2)	1/4	0/0	0/0	3/0	0/0	0/0	0/0	(1)	1/1	1/1	(4)	1/1	1/1	0/0	1/1	1/1	1/1	1/1	
Spinning bath acids	—	—	100mg CS ₂ /l	?		1/0	0/0	4/4	(3)	0/0	0/0	4/4	1/0	0/0	0/0	1/0	0/0	0/0	0/0	(1)	1/1	1/0	(3)	(2)	4/4	0/0	(4)	3/4	2/4	0/0	
Spinning solution, viscous -	—	—		(Xn, Xi)		1/1	1/1	4/4	(3)	0/0	0/0		1/1	0/0	0/0	1/1	1/1	0/0	0/0	(1)	1/1	1/1	(3)	(2)	4/4	0/0	(3)	3/4	2/4	0/0	
Spirits	C ₂ H ₆ O	—		—		1/1	1/0	1/0	1/1	1/1	0/0	1/2	1/1	0/0	1/0	1/1	0/0	0/0	1/1	1/1	1/1	1/0	1/0	1/1	0/0	1/1	1/1	1/1	1/1	0/0	Ethanol 40 %
Spirit	C ₂ H ₆ O	—		F	X	1/0	1/3	1/0	1/3	1/1	1/2	1/2	1/1	3/4	1/2	1/3	3/0	1/3	1/1	1/1	1/1	1/1	1/0	3/0	3/3	0/0	1/1	1/1	1/1	0/0	Ethanol
Rinsing agent	—	—	aqueous	?		1/1	1/1	(2)	(2)	1/0	0/0	1/0	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	(2)	(2)	(2)	0/0	(3)	(1)	(1)	0/0		
Starch gum	-> see: Dextrin																														
Starch solution	(C ₆ H ₁₀ O ₅) _n	—	any	—		1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/1	0/0	0/0	1/1	0/0	0/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/1	1/1	0/0	
Starch syrup	—	—		—		1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/1	0/0	0/0	1/1	0/0	0/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/1	1/1	0/0	
Stauffer's grease	—	—		(—)		0/0	0/0	(2)	(2)	(1)	0/0	(1)	(2)	1/4	0/0	0/0	0/0	0/0	1/1	0/0	(1)	1/1	(1)	4/4	(1)	(2)	0/0	(1)	1/1	0/0	
Stearic acid	C ₁₈ H ₃₆ O ₂	000057-11-4	fuming	Xi		1/3	1/3	1/0	1/2	1/0	1/1	1/0	1/3	1/2	2/2	1/2	1/1	1/1	1/1	1/1	1/1	1/1	3/0	1/1	3/3	0/0	1/1	1/1	1/1	1/1	
Stearic acid zinc salt	-> see: Zinc stearate																														
Stearic acid butyl ester	C ₂₂ H ₄₄ O ₂	000123-95-5	100 %	Xi		0/0	0/0	(1)	(3)	1/0	0/0	(2)	(2)	0/0	0/0	1/0	1/0	0/0	0/0	(1)	(1)	(1)	4/4	1/0	4/4	0/0	(1)	1/1	1/1	0/0	
Coal tar oil	—	092045-38-0	100 %	T		1/0	1/3	1/0	(3)	0/0	0/0	1/0	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	3/0	4/4	0/0	(1)	1/1	1/1	1/1	
Nitrogen	N ₂	007727-37-9		—		0/0	0/0	1/0	1/1	1/1	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/1	1/0	0/0	1/1	1/1	1/1	1/1	1/1	
Nitrogen tetroxide	N ₂ O ₄	010544-72-6		(O), T+, C		0/0	0/0	3/0	(3)	1/0	0/0	4/4	1/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(2)	4/4	4/4	4/4	0/0	(2)	(1)	(1)			
Strontium bromide	SrBr ₂	010476-81-0		Xi		1/1	1/1	(2)	(1)	(1)	0/0	(1)	1/1	0/0	0/0	0/0	0/0	1/1	0/0	1/1	1/1	(1)	(1)	(1)	(2)	0/0	(3)	0/0	0/0		
Strychnine	C ₂₁ H ₂₂ N ₂ O ₂	000057-24-9		T+		1/1	1/1	(1)	(1)	(2)	0/0	(2)	(1)	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	(1)	(2)	(2)	0/0	(2)	(1)	(1)			
Styrene	C ₈ H ₈	000100-42-5	100 %	Xn, Xi	X	4/4	3/4	1/1	4/4	1/1	(4)	1/1	3/4	0/0	0/0	4/4	4/4	0/0	0/0	1/0	1/1	(2)	4/4	3/0	4/4	0/0	1/1	1/1	1/1	0/0	
Sulphite lye	-> see: Calcium bisulphite																														
Sulphuryl chloride	Cl ₂ SO ₂	007791-25-5	tech. pure	C		4/4	4/4	4/4	1/0	0/0	0/0	4/4	4/4	0/0	0/0	4/4	4/4	0/0	0/0	0/0	1/0	3/0	3/0	1/0	4/4	0/0	3/4	0/0	0/0		
Tallow	—	—	tech. pure	—		1/1	1/1	1/0	(1)	1/0	0/0	1/0	1/1	0/0	0/0	1/1	1/0	0/0	0/0	(1)	1/1	1/1	3/0	1/1	1/1	0/0	(1)	1/1	1/1	0/0	
Tannin	C ₇₆ H ₅₂ O ₄₆	001401-55-4	10 %	Xi		1/1	1/1	1/0	3/3	0/0	1/1	4/4	1/1	3/3	0/0	1/1	0/0	0/0	0/0	(1)	1/1	1/1	3/0	1/1	3/3	0/0	1/0	1/1	1/1	1/1	
Tannin	C ₇₆ H ₅₂ O ₄₆	001401-55-4		Xi		1/1	1/1	1/0	4/4	0/0	0/0	4/4	1/1	1/1	0/0	0/0	0/0	1/1	0/0	(1)	1/1	1/1	3/0	1/1	3/3	0/0	1/0	1/1	1/1	1/1	
Tar	—	—		T		0/0	1/0	1/0	(3)	1/0	0/0	1/0	(2)	1/0	1/0	1/0	3/0	0/0	0/0	(1)	(1)	(2)	4/4	1/0	4/4	0/0	(1)	(1)	(1)		
Surfactants	-> see: Wetting agent																														
Turpentine substitute	—	—		Xn, N	X	0/0	0																								

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	FLAMMABLE	Thermoplastics														Fluoroplastics				Elastomers				Metals				Hastelloy C	REMARK
						HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A				
Tetrachloroethane	C ₂ H ₂ Cl ₄	—	tech. pure	T+		3/0	3/4	3/0	4/4	(4)	(4)	1/1	3/4	4/4	0/0	4/4	4/4	4/4	0/0	1/0	1/1	1/3	4/4	4/4	4/4	0/0	(3)	0/0	0/0	0/0	Isomer not specified in the source		
Tetrachloroethene	-> see: Perchloroethylene																																
Tetrachloroethylene	-> see: Perchloroethylene																																
Carbon tetrachloride (TETRA)	CCl ₄	000056-23-5		T		4/4	4/4	4/4	4/4	1/4	4/4	2/3	4/4	4/4	4/4	4/4	4/4	1/1	1/1	1/1	1/3	4/4	1/1	4/4	0/0	4/4	(1/1L) ¹⁾	(1/1L) ¹⁾	1/1		¹⁾ Water-free! If even traces of hydrochloric acid (HCl) are split off by moisture, there is a risk of pitting, crevice and stress corrosion cracking.		
Methane tetrachloride	-> see: Carbon tetrachloride																																
Tetrachlorotitanium	-> see: Titanium tetrachloride																																
Tetraethyl lead (TEL)	C ₈ H ₂₀ Pb	000078-00-2	techn. rein	T+	X	1/0	1/0	1/4	3/0	(2)	(4)	(2)	2/4	0/0	0/0	1/0	0/0	0/0	(1)	1/0	1/1	4/4	1/0	3/0	0/0	(2)	(1)	(1)	1/1				
Tetraethylorthosilicate	C ₈ H ₂₀ SiO ₄	000078-10-4		Xn	X	0/0	0/0	(2)	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	(3)	(3)	1/0	0/0	(1)	(1)	(1)					
Tetrafluoromethane	CF ₄	000075-73-0		?		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	3/0	1/0	0/0	(3)	0/0	0/0					
Tetrahydro-1,4-oxazine	-> see: Morpholine																																
Tetrahydrofuran (THF)	C ₄ H ₈ O	000109-99-9		F, Xi	X	3/4	4/4	1/0	4/4	1/0	3/4	1/3	3/4	4/4	4/4	4/4	4/4	2/3	1/1	1/0	3/3	4/4	4/4	4/4	0/0	1/1	(1)	(1)	1/1				
Tetrahydrofurfuryl alcohol	C ₆ H ₁₀ O ₂	000097-99-4		Xi		0/0	0/0	(2)	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	(3)	(3)	(4)	0/0	(2)	(1)	(1)					
Tetrahydronaphthalene	C ₁₀ H ₁₂	000119-64-2	tech. pure	Xi		3/4	4/4	1/0	4/4	1/0	(4)	1/0	4/4	4/4	4/4	4/4	0/0	0/0	(1)	1/0	1/0	4/4	1/0	4/4	0/0	1/1	1/1	1/1	0/0				
Tetralin	-> see: Tetrahydronaphthalene																																
Tetramethylene oxide	-> see: Tetrahydrofuran																																
Tetraphosphorus decaoxide	-> see: Phosphorus pentoxide																																
Thiacyclopentadiene	-> see: Thiophene																																
Thiofuran	-> see: Thiophene																																
Thioglycolic acid	C ₂ H ₄ SO ₂	000068-11-1		T, C		0/0	1/1	(3)	(3)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(3)	(3)	(3)	(4)	0/0	3/4	0/0	1/1	1/1	0/0			
Thionyl chloride	Cl ₂ SO	007719-09-7	tech. pure	C		4/4	4/4	4/4	4/4	0/0	4/4	2/0	4/4	4/4	4/4	4/4	4/4	1/1	1/1	1/0	(3)	3/0	1/0	4/4	0/0	3/4	0/0	0/0	0/0	0/0			
Thiophene	C ₂ H ₄ S	000110-02-1		F, Xn	X	3/3	3/3	(2)	4/4	0/0	(4)	(2)	3/4	4/4	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(3)	4/4	4/4	3/0	0/0	(1)	(1)	(1)	0/0			
Thymol	C ₁₀ H ₁₄ O	000089-83-8		C, Xn		0/0	0/0	(3)	(3)	0/0	0/0	(3)	(3)	3/4	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	(4)	1/0	4/4	0/0	(1)	(1)	(1)				
Titanium chloride	-> see: Titanium tetrachloride																																
Titanium tetrachloride	TiCl ₄	007550-45-0		C		0/0	0/0	4/4	(3)	0/0	0/0	(3)	(3)	0/0	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(3)	4/4	(3)	4/4	0/0	(4)	0/0	0/0				
Toluene	-> see: Methylbenzene																																
Toluol	-> see: Methylbenzene																																
Toluenesulphone chloramide sodium, p-	-> see: Chloramine T																																
Tragacanth	—	009000-65-1		—		1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	(1)	1/1	1/1					
Transformer oil	—	—		?		1/3	3/3	1/0	(3)	1/1	1/0	3/3	1/3	1/3	1/0	1/0	0/0	1/3	0/0	(1)	1/1	(3)	4/4	2/3	3/3	0/0	1/1	(1)	(1)	0/0			
Grape sugar	-> see: Glucose																																
Triacetin	C ₉ H ₁₄ O ₆	000102-76-1		Xn		0/0	0/0	0/0	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	1/0	4/4	3/3	0/0	(1)	(1)	(1)					
Tribromomethane	-> see: Bromoform																																
Tributyl citrate	C ₁₈ H ₃₂ O ₇	000077-94-1		—		1/2	2/3	(2)	4/4	0/0	2/3	(2)	2/3	4/4	3/3	3/4	0/0	0/0	1/2	1/1	(1)	(2)	(3)	(3)	(3)	0/0	(1)	(1)	(1)				
Tributyl phosphate (TBP)	C ₁₂ H ₂₇ PO ₄	000126-73-8	tech. pure	Xn		1/1	1/1	1/0	(3)	0/0	0/0	(2)	1/3	0/0	0/0	4/4	4/4	0/0	0/0	(1)	1/1	1/0	3/0	4/4	4/4	0/0	(1)	(1)	(1)	1/1			
Trichloroacetaldehyde	C ₂ HCl ₃ O	000075-87-6	100 %	T/Xi		1/1	1/1	4/4	(3)	(4)	0/0	(3)	1/1	0/0	0/0	4/4	4/4	0/0	0/0	(1)	0/0	(4)	3/0	(4)	4/4	0/0	4/4	0/0	0/0	0/0			
Trichloroacetaldehyde hydrate	-> see: Chloral hydrate																																
Trichloraldehyde hydrate	-> see: Chloral hydrate																																
Trichlorobenzene	C ₆ H ₃ Cl ₃	—	100 %	(Xn)		4/4	4/4	(3)	(3)	0/0	(4)	(2)	4/4	4/4	0/0	4/4	4/4	4/4	0/0	(1)	(2)	(3)	(4)	(3)	4/4	0/0	(2)	0/0	0/0	0/0	Isomer not specified in the source		
Trichloroacetic acid (TCA)	C ₂ HCl ₃ O ₂	000076-03-9		C+		1/4	3/4	4/4	4/4	4/4	0/0	4/4	1/1	4/4	0/0	4/4	4/4	0/0	0/0	1/0	1/1	1/4	3/0	4/4	4/4	0/0	1/3	3/0L	2/0L	1/1			
Trichloroethane	C ₂ H ₃ Cl ₃	—		Xn		3/4	4/4	3/0	4/4	4/4	4/4	(2)	4/4	4/4	4/4	4/4	4/4	4/4	1/2	1/1	(1)	1/3	4/4	1/0	4/4	0/0	4/4	0/0	0/0	0/0	Isomer not specified in the source		
Trichloroethene	-> see: Trichloroethylene																																
Trichloroethylene (TRI)	C ₂ HCl ₃	000079-01-6	100 %	Xn		3/4	4/4	3/0	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	0/4	1/2	1/1	1/0	1/1	4/4	1/3	4/4	0/0	1/3	(1/1L) ¹⁾	(1/1L) ¹⁾	1/0		¹⁾ Water-free! If even traces of hydrochloric acid (HCl) are split off by moisture, there is a risk of pitting, crevice and stress corrosion cracking.		
Trichlorofluoromethane	CCl ₃ F	000075-69-4		N		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	(3)	(1)	0/0	4/4	2/0	1/0	0/0	(3)	0/0	0/0	0/0				
Trichloromethane	-> siehe: Chloroform																																
Trichloromonofluoromethane	-> siehe: Trichlorfluormethan																																

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	FLAMMABLE	Thermoplastics														Fluoroplastics				Elastomers				Metals				Hastelloy C	REMARK
						HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FKM / FKM	NBR	SI	AL	V2A	V4A				
Trichlorophenol	C ₆ H ₃ Cl ₃ O	—		(Xn, Xi)		0/0	0/0	(3)	(4)	0/0	0/0	(3)	(3)	0/0	0/0	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(3)	(4)	(3)	(4)	0/0	(3)	0/0	0/0		Isomer not specified in the source	
Trichlorophosphine	-> see: Phosphorus trichloride																																
Trichlorophosphine oxide	-> see: Phosphorus oxychloride																																
Trichlorophosphorus oxide	-> see: Phosphorus oxychloride																																
Trichlorotrifluoroethane	C ₂ Cl ₃ F ₃	000076-13-1		?		0/0	0/0	1/0	(3)	1/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/0	4/4	3/0	1/0	0/0	(3)	0/0	0/0				
Triethanolamine (TEA)	C ₆ H ₁₅ NO ₃	000102-71-6	tech. pure	Xi		1/1	1/2	(2)	(2)	1/0	0/0	2/2	1/1	1/1	0/0	3/0	4/4	1/1	0/0	1/1	1/0	1/0	2/0	4/4	4/4	0/0	(1)	(1)	(1)	0/0			
Triethylamine (TEA)	C ₆ H ₁₅ N	000121-44-8	tech. pure	F, C, Xn	X	0/0	0/0	(2)	(3)	0/0	0/0	1/1	4/4	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	3/4	4/4	3/0	3/4	0/0	(1)	(1)	(1)	0/0			
Triethylene glycol	-> see: Triglycol																																
Triethylene glycol diacetate	-> see: Triglycol acetate																																
Trifluorotrichloroethane	C ₂ Cl ₃ F ₃	—	100 %	?		4/4	3/4	1/0	3/0	0/0	0/0	1/0	4/4	4/4	1/0	3/4	4/4	3/3	0/0	0/0	(1)	1/0	4/4	3/0	1/0	0/0	(3)	0/0	0/0		Isomer not specified in the source		
Triglycol	C ₆ H ₁₄ O ₄	000112-27-6		Xi		1/1	1/1	(3)	1/2	0/0	1/1	1/0	1/1	1/2	1/1	2/3	0/0	1/1	1/1	1/1	(1)	(2)	(2)	(1)	(3)	0/0	(1)	(1)	(1)	0/0			
Triglycol acetate	C ₁₀ H ₁₈ O ₆	000111-21-7		?		0/0	0/0	(3)	(3)	0/0	0/0	1/0	(2)	0/0	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(3)	(3)	(4)	(4)	0/0	(1)	(1)	(1)				
Trihydroxybenzoic acid, 3,4,5-	-> see: Gallic acid																																
Trihydroxybenzene, 1,2,3-	-> see: Pyrogallol																																
Trihydroxybutane	-> see: Butanetriol																																
Trihydroxypurine, 2,6,8-	-> see: Uric acid																																
Trihydroxytriethylamine	-> see: Triethanolamine																																
Triiodomethane	-> see: Iodoform																																
Triisopropylbenzene	C ₁₅ H ₂₄	000717-74-8		—		0/0	0/0	(2)	(3)	0/0	(4)	(2)	(3)	4/4	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	1/0	1/0	0/0	1/1	(1)	(1)			
Tricresyl phosphate (TCF)	C ₂₁ H ₂₁ PO ₄	—	tech. pure	T/Xn, N		1/1	1/1	1/0	4/4	1/0	0/0	1/0	1/3	4/4	0/0	4/4	4/4	4/4	0/0	(1)	1/1	(3)	3/0	3/4	4/4	0/0	1/1	1/1	1/1	1/1	Isomer not specified in the source		
Trimethylbenzene, 1,3,4-	-> see: Pseudocumene																																
Trimethylolpropane	C ₆ H ₁₄ O ₃	000077-99-6	aqueous	—		0/0	0/0	(2)	(2)	(2)	0/0	1/0	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	(1)	(2)	(2)	0/0	(1)	(1)	(1)				
Trimethylpentane, 2,2,4-	-> see: Iso-octan																																
Trisodium phosphate	Na ₃ PO ₄	007601-54-9		Xi		1/1	1/1	1/0	(2)	(2)	0/0	1/0	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/1	1/1	0/0	(4)	1/1	1/1				
Trisodium phosphate, tribasic	-> see: Sodium phosphate																																
Trinitrophenol, 2,4,6-	-> see: Picric acid																																
Trioctyl phosphate	C ₂₄ H ₅₄ PO ₄	000078-42-2	tech. pure	(Xn)		3/0	1/0	1/0	(3)	0/0	0/0	(2)	1/3	0/0	0/0	4/4	0/0	0/0	0/0	(1)	1/1	(3)	3/0	3/4	4/4	0/0	(1)	(1)	(1)	0/0			
Triphen	-> see: Hexachlorobutadiene																																
Tripropylene glycol (TPG)	C ₉ H ₂₀ O ₄	024800-44-0		(—)		1/1	1/1	(3)	1/2	0/0	1/1	1/0	1/1	1/1	1/1	2/3	0/0	0/0	1/1	1/1	1/1	(2)	(3)	(2)	(3)	0/0	(1)	(1)	(1)				
Tris(2-ethylhexyl) phosphate	-> see: Trioctyl phosphate																																
Tris(hydroxyethyl)-amine	-> see: Triethanolamine																																
Tris(hydroxymethyl)propane	-> see: Trimethylolpropane																																
Tropic acid tropylester sulphate	-> see: Atropine sulphate																																
Tung oil	-> see: Wood oil																																
Turbine oil (mineral oil base)	—	—		?		0/0	0/0	(1)	(2)	1/0	0/0	(2)	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	4/4	(2)	1/0	0/0	1/1	1/1	1/1				
Superchloric acid	-> see: Perchloric acid																																
Undecanol	-> see: Undecyl alcohol																																
Undecyl alcohol	C ₁₁ H ₂₄ O	000112-42-5		Xi		1/2	1/3	(1)	2/3	(1)	1/2	1/0	1/2	2/2	3/3	1/3	0/0	1/1	1/2	1/1	1/1	(1)	(3)	(1)	(2)	0/0	(1)	(1)	(1)				
Urine	—	—		—		1/1	1/1	1/0	1/0	1/0	0/0	1/1	1/1	3/0	0/0	1/3	1/0	0/0	1/1	1/1	1/1	1/1	1/0	1/0	1/1	0/0	(2)	1/1	1/1	1/1			
Urotropine	-> see: Hexamethylenetetramine																																
Vaseline	—	008009-03-8	tech. pure	(—)		3/4	2/3	1/0	1/0	1/0	0/0		1/3	1/1	0/0	3/0	0/0	1/1	0/0	(1)	1/1	1/1	3/0	1/1	1/1	0/0	1/1	1/1	1/1	1/1			
Vaseline oil	—	008012-95-1	100 %	?		0/0	1/3	1/0	(2)	1/0	1/0		1/3	1/0	1/0	1/0	3/0	0/0	0/0	(1)	(1)	(1)	3/0	1/0	1/0	0/0	1/1	1/1	1/1	1/1	Paraffin oil		
Vaseline oil	—	008012-95-1		?		1/1	1/3	1/0	1/0	1/0	0/0	1/1	1/3	1/1	0/0	1/3	1/0	1/1	0/0	(1)	1/1	1/1	4/4	1/1	1/3	0/0	1/1	1/1	1/1	1/1	Paraffin oil		
Vinyl acetate	C ₄ H ₆ O ₂	000108-05-4	tech. pure	F	X	0/0	1/1	1/0	4/4	(3)	(4)		1/4	0/0	0/0	4/4	4/4	0/0	0/0	1/0	1/0	1/1	1/0	3/0	3/3	0/0	(1)	(1)	(1)	0/0			
Vinylbenzene	-> see: Styrene																																
Vinylcarbinol	-> see: Allyl alcohol																																
Vinyl chloride	-> see: Chloroethylene																																
Vinyl cyanide	-> see: Acrylonitrile																																
Vinyl ethylene	-> see: Butadiene, 1,3-																																
Vinylidene chloride	C ₂ H ₂ Cl ₂	000075-35-4		F+, Xn	X	4/4	4/4	(2)	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	0/0	2/3	1/1	(1)	(2)	4/4	3/0	4/4	0/0	(3)	0/0	0/0	0/0			
Vitamin C	C ₆ H ₈ O ₆	000050-81-7	liquid	—		1/1	1/1	(2)	(2)	(1)	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	(1)	(1)	(1)	0/0	1/1	(1)	(1)				
Wax alcohol	—	—	tech. pure	(—)		3/4	3/4	(2)	(2)	1/0	0/0		3/4	0/0	0/0	1/1	3/4	0/0	0/0	(1)	1/1	1/1	4/4	1/1	1/1	0/0	(1)	(1)	(1)	0/0			
Waxes	—	—		—		0/0	1/3	1/1	1/1	1/1	0/0		1/3	1/1	0/0	0/0	1/1	0/0	(1)	1/1	1/1	(4)	1/0	1/1	0/0	1/1	(1)	1/1	1/1				

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	Thermoplastics														Fluoroplastics				Elastomers				Metals				Hastelloy C	REMARK
					FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A			
Walnut oil	—	008024-09-7	—	—	—	0/0	0/0	(2)	(2)	1/0	0/0	1/3	3/3	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	(3)	(1)	(2)	0/0	(1)	1/1	1/1	1/1			
Spermaceti	—	008002-23-1	—	—	—	0/0	1/3	(1)	1/1	1/0	0/0	1/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	1/0	0/0	(1)	1/1	1/1	1/1	1/1			
Detergent	—	—	?	?	?	1/1	1/1	1/0	1/1	1/1	0/0	1/1	0/0	0/0	1/3	0/0	0/0	(1)	1/1	1/1	1/0	1/1	(2)	0/0	1/1	1/1	1/1	1/1	1/1			
Water	H ₂ O	007732-18-5	—	—	—	1/1	1/1	1/0	1/1	1/1	1/0	1/1	1/1	1/0	1/3	1/3	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/1	1/1	1/1			
Water, distilled ~	H ₂ O	007732-18-5	—	—	—	1/1	1/1	1/0	1/1	1/1	1/0	1/1	1/1	1/0	1/3	1/3	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/1	1/1	1/1			
Water glass	Na ₂ Si ₂ O ₇	001344-09-8	saturated	C, Xn	—	1/1	1/1	1/0	1/0	1/0	0/0	0/0	1/1	1/1	0/0	1/3	1/4	1/1	0/0	1/1	1/1	1/3	1/0	1/1	1/1	0/0	1/1	1/1	1/1	Aqueous solution of alkali silicates		
Hydrogen	H ₂	001333-74-0	tech. pure	F+	X	1/1	1/1	1/0	1/0	0/0	0/0	1/1	1/0	0/0	1/1	1/1	0/0	0/0	(1)	1/1	1/1	1/0	1/0	1/1	0/0	1/1	1/1	1/1	1/1			
Hydrogen peroxide	H ₂ O ₂	007722-84-1	30 %	C	—	1/1	1/2	4/4	1/1	1/0	1/2	4/4	1/3	1/2	1/1	1/1	0/0	1/0	1/1	1/1	1/1	3/0	1/1	4/4	0/0	(3)	1/1	1/1	1/1			
Hydrogen peroxide	H ₂ O ₂	007722-84-1	100 %	O, C	—	1/4	1/4	4/4	0/0	0/0	0/0	4/4	4/4	4/4	0/0	0/0	0/0	(1)	(1)	(2)	(3)	(2)	4/4	0/0	(3)	(1)	(1)	?				
Hydrogen peroxide	H ₂ O ₂	007722-84-1	90 %	O, C	—	1/1	1/2	4/4	1/1	0/0	1/2	4/4	1/3	1/2	1/1	1/2	0/0	0/0	1/1	1/1	1/1	1/0	3/0	1/3	4/4	0/0	(3)	1/1	1/1	?		
Hydrogen peroxide	H ₂ O ₂	007722-84-1	3 %	Xi	—	1/1	1/1	(3)	1/1	1/0	1/1	1/0	1/1	1/2	1/1	1/1	0/0	1/1	1/1	1/1	1/1	1/0	1/0	3/4	0/0	(3)	1/1	1/1	1/1			
Oxygenated water	-> see: Hydrogen peroxide																															
Plasticiser	—	—	?	?	?	1/3	1/3	(2)	(3)	0/0	0/0	(2)	1/3	0/0	0/0	0/0	3/3	0/0	(1)	(1)	0/0	(2-3)	0/0	4/4	0/0	(1)	(1)	(1)				
Wines	—	—	—	—	—	1/1	1/1	1/0	1/1	1/1	1/0	1/1	1/1	1/0	1/1	1/1	0/0	0/0	1/1	1/1	1/1	1/0	1/0	1/0	0/0	(4)	1/1	1/1	1/1			
Spirit of wine	C ₂ H ₆ O	—	50 %	(F)	X	1/0	1/1	1/0	1/1	1/1	1/0	1/2	1/1	1/0	1/0	1/0	3/0	0/0	0/0	1/1	1/1	1/1	1/0	(2)	1/1	0/0	1/1	1/1	1/1	Ethanol		
Spirit of wine	C ₂ H ₆ O	—	96 %	F	X	1/0	1/3	1/0	1/1	1/3	1/2	1/2	1/1	3/4	1/2	1/3	3/0	1/3	1/1	1/1	1/1	1/0	3/0	3/3	0/0	1/1	1/1	1/1	1/1	Ethanol		
Tartaric acid	C ₄ H ₆ O ₆	000087-69-4	aqueous	Xi	—	1/1	1/1	3/3	1/2	0/0	0/0	(3)	1/1	0/0	1/1	0/0	0/0	0/0	1/1	1/1	1/1	3/0	1/1	1/1	0/0	(4)	1/3	1/2	1/1			
Tartaric acid	C ₄ H ₆ O ₆	000087-69-4	—	Xi	—	1/1	1/1	4/4	1/2	0/0	1/1	(3)	1/1	2/2	1/1	1/2	1/3	1/1	1/1	1/1	1/1	3/0	1/1	1/1	0/0	(4)	1/3	1/2	1/1			
Cream of tartar	-> see: Potassium hydrogentartate																															
Whiskey	—	—	—	—	—	0/0	0/0	1/0	1/1	1/1	0/0	1/2	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/0	1/1	0/0	1/1	1/1	1/1	1/1	Whisky, Scotch, Bourbon		
White spirit	—	008042-47-5	—	Xn	—	1/0	1/0	(1)	(3)	1/0	(4)	1/0	1/3	0/0	0/0	1/0	0/0	0/0	(1)	1/1	(2)	4/4	1/0	(2)	0/0	1/1	1/1	1/1				
Wool grease	-> see: Lanolin																															
Xenon	Xe	007440-63-3	—	—	—	0/0	0/0	1/0	(1)	1/1	0/0	1/1	(2)	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/1	1/0	1/0	0/0	1/1	1/1	1/1				
Xylol	-> see: Xylene																															
Xylene	C ₈ H ₁₀	001330-20-7	—	(F), Xn	X	3/4	3/4	1/0	4/4	0/0	3/4	1/2	4/4	4/4	4/4	4/4	4/4	4/4	1/2	1/1	1/0	1/3	4/4	1/3	4/4	0/0	1/1	1/1	1/1	1/1		
Cedar oil	—	008000-27-9	?	?	?	3/4	4/4	(2)	2/3	0/0	4/4	(2)	4/4	4/4	3/3	3/4	0/0	0/0	1/2	1/1	(1)	(2)	(4)	(2)	(3)	0/0	(1)	(1)	(1)			
Cinnamon	—	—	grinded	?	?	0/0	0/0	(2)	1/0	(2)	0/0	(2)	2/0	3/0	0/0	0/0	0/0	1/1	0/0	(1)	(1)	(1)	(2)	(2)	(2)	0/0	(1)	(1)	(1)			
Cinnamaldehyde	C ₉ H ₈ O	000104-55-2	—	Xn, Xi	—	0/0	0/0	(2)	(3)	0/0	(4)	(2)	(3)	4/4	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	1/0	1/0	4/4	0/0	(1)	(1)	(1)			
Cinnamon oil	—	008007-80-5	—	Xn, Xi	—	3/4	4/4	(2)	2/3	0/0	4/4	(2)	4/4	4/4	3/3	4/4	0/0	0/0	1/2	1/1	(1)	(2)	(3)	(3)	4/4	0/0	(1)	(1)	(1)			
Zinc acetate	C ₄ H ₇ ZnO ₄	000557-34-6	aqueous	Xn, Xi	—	1/1	1/1	(2)	(2)	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	(3)	3/3	0/0	(3)	(1)	(1)			
Zinc bromide	ZnBr ₂	007699-45-8	—	C, Xn	—	1/1	1/1	4/4	(2)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	1/1	0/0	1/1	1/1	(1)	(2)	(1)	(2)	0/0	(3)	0/0	0/0			
Zinc carbonate	ZnCO ₃	003486-35-9	saturated	?	?	1/1	1/1	(1)	1/1	1/1	0/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	(2)	(1)	(1)	0/0	No chemical effect expected due to low solubility		
Zinc chloride	ZnCl ₂	007646-85-7	aqueous	(C, Xn)	—	1/1	1/1	3/4	(2)	0/0	0/0	2/0	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/1	1/1	0/0	3/4	1/4L	1/3L	1/1			
Zinc chloride	ZnCl ₂	007646-85-7	10 %	C, Xn	—	1/1	1/1	3/4	1/0	0/0	1/1	2/0	1/1	1/3	0/0	1/3	1/0	1/1	1/1	1/1	1/1	1/0	1/1	1/1	0/0	3/4	1/4L	1/3L	1/1			
Zinc nitrate	Zn(NO ₃) ₂	007779-88-6	—	O, C, Xn	—	1/1	1/1	1/4	(2)	0/0	0/0	(2)	1/1	1/0	1/0	1/0	1/0	1/1	0/0	1/1	1/1	(1)	1/0	(1)	(2)	0/0	(3)	(1)	(1)	0/0		
Zinc oxide	ZnO	001314-13-2	solid	Xn, Xi	—	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	(2)	1/1	1/1		No chemical effect expected due to low solubility		
Zinc phosphate	Zn ₃ (PO ₄) ₂	007779-90-0	saturated	?	?	1/1	1/1	(1)	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	(2)	(1)	(1)	0/0			
Zinc ointment	—	—	?	?	?	0/0	0/0	(1)	(2)	(2)	0/0	(2)	(2)	1/1	0/0	0/0	0/0	1/1	0/0	(1)	1/1	(2)	(4)	(2)	(2)	0/0	(2)	(1)	(1)			
Zinc sludge	—	—	?	?	?	0/0	0/0	0/0	0/0	0/0	0/0	0/0	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(2)	0/0	0/0	0/0	0/0	0/0	(3)	0/0	0/0			
Zinc stearate	C ₃₆ H ₇₀ ZnO ₄	000557-05-1	—	Xi	—	1/1	1/1	(1)	1/1	0/0	1/1	1/1	1/1	1/1	1/2	1/1	1/1	1/1	1/1	1/1	1/1	1/1	(2)	1/1	(2)	0/0	(2)	(1)	(1)			
Zinc sulphate	ZnSO ₄	007733-02-0	10 %	—	—	1/1	1/1	(3)	1/0	(2)	1/0	2/0	1/1	1/1	0/0	1/1	1/0	1/1	1/1	1/1	1/1	1/1	1/0	1/1	1/0	0/0	3/4	1/1	1/1	1/1		
Zinc vitriol	-> see: Zinc sulphate																															
Tin (II) chloride	SnCl ₂	007772-99-8	aqueous	(C, Xn)	—	1/1	1/1	(4)	(2)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0															

MEDIUM	FORMULA	CAS NO.	CONCENTRATION	HAZARD INFORMATION	FLAMMABLE	Thermoplastics														Fluoroplastics		Elastomers		Metals				Hastelloy C	REMARK	
						HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HARD	PVC SOFT	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL			V2A
Sugar beet juice	—	—	—	—	1/1	1/1	1/0	1/0	0/0	1/0	1/1	1/1	1/0	0/0	1/0	1/0	0/0	1/1	1/1	1/1	1/1	1/0	1/0	1/1	0/0	(2)	(1)	(1)		
Sugar acid	—	—	saturated	(Xi)	1/1	1/1	(3)	(2)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	1/0	(1)	(1)	0/0	(3)	0/0	0/0		
Sugar syrup	—	—	—	—	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/3	0/0	0/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1
Two-stroke oil	—	—	100 %	—	0/0	1/3	1/0	(2)	1/0	0/0	1/1	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	1/0	0/0	1/1	1/1	1/1		1/1

Two values are given for each medium:
left number = value at +20°C / right number = value at +50°C

Resistance

Two values are given for each medium:
left number = value at +20°C / right number = value at +50°C

0	no information available/no statement possible
1	very good resistance/suitable
2	good resistance/suitable
3	limited resistance
4	not resistant
K	no general information possible
L	Risk of pitting or stress corrosion cracking
()	Estimated value

Hazard preventions

E	explosive
O	oxidising
F	inflammatory
F+	extremely inflammable
T	toxic
T+	very toxic
C	caustic
Xn	harmful to health
Xi	irritant
N	environmentally hazardous

Name of materials

Thermoplastics

HDPE	High density polyethylene
LDPE	Low density polyethylene
PA	Polyamide (nylon)
PC	Polycarbonate
PETG	Polyethylene terephthalate glycol (co-
PMP	polyester) Polymethylpentene (TPX)
POM	Polyoxymethylene
PP	Polypropylene
PS	Polystyrene
PSU	Polysulfone
PVC	Polyvinyl chloride
SAN	Styrene acrylonitrile

Fluoroplastics

E-CTFE	Ethylene-chlorotrifluoroethylene (Halar)
ETFE	Ethylene tetrafluoroethylene
FEP	Tetrafluoroethylene-perfluoropropylene (Teflon,
PTFE	FEP) Polytetrafluoroethylene (Teflon)
PVDF	Polyvinylidene fluoride

Elastomers

EPDM	Ethylene propylene terpolymer rubber
FPM/FKM	Fluoropolymer (Viton)
NBR	Nitrile rubber
SI	Silicone rubber

Metals

Al	Aluminium
V2A	Stainless steel 1.4301 (AISI 304)
V4A	Stainless steel 1.4401 (AISI 316)
Hastelloy C	Nickel-chromium-molybdenum alloy